FFD-28SW-L103 Rotary/Friction Damper

| | SPECIFICATIONS | | | | | |
|-------------------|--------------------------|--------------------------|--------|------------------------|-----------------------|--------------|
| | Model | Max Torque | | Max Reverse Torque | Max Rotation Speed | |
| | FFD-28SW-L103 | 1±0.1 Nm (10±1 kgfcm) | | Counter- clockwise | 30 RPM | |
| Max Cycle Rate | Operating Temperature | | Weight | Body & Cap Material | | Cap Color |
| 13 cycles/min. | -10 ~ 60°C (90%RH) | | 25±2g | POM | | White |

* Rated torque is measured at a rotation speed of 20rpm at 20-25°C

HOW TO USE THE DAMPER

- The damper generates torque in both the clockwise and counter-clockwise directions.
 (A one-way clutch is built in inside the damper.)
- 2. Please make sure that the shaft attached to a damper has a bearing, as the damper itself is not fitted with one.

| Shaft's external dimensions | Ø8 -0.03 | | |
|--|-----------------------------------|--|--|
| Surface hardness | HRC55 or higher | | |
| Quenching depth | 0.5mm or higher | | |
| Surface roughness | 1.0Z or lower | | |
| Chamfer end (Damper insertion side) | <u>C0.2~C0.3</u> (orR0.2~R0.3) | | |

- 3. It can be used as a free-stop for a load that is smaller than the rated torque.
- 4. Please refer to the recommended dimensions in the chart when creating a shaft for attachment to the damper. Using a shaft outside of the recommended dimensions may cause the shaft to slip out.
- 5. To insert a shaft into the damper, insert the shaft while spinning it in the opposite direction of the damper's direction of torque generation.(Do not force the shaft in from a regular direction. This may damage the built-in oneway clutch.)