

# MPC5748G Low Cost EVB User Guide

# Contents

1.	INTRODUCTION.....	3
2.	LCEVB FEATURES.....	3
2.1.	Differences to the Customer EVB .....	4
3.	CONFIGURATION OVERVIEW.....	6
4.	INITIAL SETUP .....	7
4.1.	Power Supply Configuration.....	7
4.1.1.	Power Input Connector .....	7
4.1.2.	Power Switch.....	7
4.1.3.	Power Status LED.....	8
4.1.4.	MCU and Peripheral Voltage Configuration .....	8
4.2.	Reset Control (SW3).....	8
4.2.1.	Reset LEDs .....	9
4.3.	MCU Clock Configuration .....	10
4.4.	Debug Connector (P1) .....	10
4.4.1.	Debug Connector Pinout.....	10
5.	COMMUNICATIONS & MEMORY INTERFACES:.....	11
5.1.	CAN Interfaces (P2, P3) .....	11
5.2.	LIN Interfaces (P6, P7).....	12
5.3.	USB RS232 Serial Interface (P11) .....	12
5.4.	USB HOST Interface (P4) .....	12
5.5.	Ethernet Interface (P5).....	13
5.6.	FlexRay (P8, P9, P10).....	13
6.	USER INTERFACE (I/O).....	14
6.1.	GPIO Matrix .....	14
6.2.	User Switches (SW4, SW5).....	15
6.3.	Hex Encoded Switch (SW1) .....	15
6.4.	User LED's (DS1, DS2, DS3, DS4) .....	16
6.5.	ADC Input Potentiometer (RVAR, RV1).....	16
7.	MCU PORT PIN LCEVB FUNCTIONS.....	17
8.	APPENDIX.....	18

# 1. Introduction

This user guide details the setup and configuration of the NXP MPC5748G Low Cost Evaluation Board (hereafter referred to as the LCEVB). The LCEVB is intended to provide a mechanism for easy evaluation of the MPC5748G family of microcontrollers, and to facilitate basic hardware and software development.

Note that the LCEVB has a limited feature set compared to the main MPC574xG customer EVB and is intended for evaluation purposes. Customers moving to serious development activities are recommended to purchase the fully functional customer EVB which also has device specific daughter cards.

The LCEVB is intended for bench / laboratory use and has been designed using normal temperature specified components (+70° C).

This product contains components that may be damaged by electrostatic discharge. Observe precautions for handling electrostatic sensitive devices when using the LCEVB.

The user guide is intended to be read alongside the respective MCU documentation available at [www.nxp.com](http://www.nxp.com) and includes:

- Reference Manuals
- Product Data Sheets
- Application notes
- Device Errata

# 2. LCEVB Features

The LCEVB provides the following key features:

- Single 5 V DC external power supply input with on-board 3.3 V regulator. Power is supplied via a 2.1 mm barrel style power jack.
- Simple jumperless configuration (enhanced configuration is possible via 0 Ohm Resistors and optional jumpers if required).
- Master power switch and regulator status LED.
- USB Serial interface.
- 2 x High Speed CAN transceiver routed to 3-way headers.
- 2 x LIN interfaces routed to 3-way headers.
- Main clock supplied from on board crystal.
- User reset switch with reset status LED's.
- Ethernet PHY and RJ45 socket (configured for MII mode).
- USB Type A Host interface.
- 2 x FlexRay interfaces with standard 2-pin connectors.
- 14-pin JTAG connector.

- 4 user LED's wired to MCU ports.
- 2 user pushbutton switches wired to MCU ports.
- Hexadecimal encoded switch wired to 4 MCU ports.
- Simple potentiometer connected to analogue input channel.

## 2.1. Differences to the Customer EVB

Note that the GPIO pins used for peripherals on the LCEVB are the same as those used on the customer EVB. This ensures maximum code compatibility between the 2 boards, making it easy to migrate from one board to the other

**Table 1. Customer EVB vs LCEVB features**

Feature	Customer EVB	LCEVB
MCU Support	Custom MCU Daughtercards for multiple devices (socketed)	Soldered 176QFP MPC5748G
Power Supply	External 12 V	<b>External 5 V (Caution)</b>
On Board Regulators (and LED's)	5 V, 3.3 V, 1.25 V (combination of Linear and /or Switching regulators)	3.3 V Switching Regulator
Master Power Switch	Yes	Yes
Reset Control	Reset button with MCU and External Reset LED's	Reset button with MCU and External Reset LED's
USB FTDI Serial Interface	Yes	Yes
CAN Physical Interfaces	2 (routed to 0.1" headers)	2 (routed to 0.1" headers)
LIN Physical Interfaces	2 (routed to Molex headers)	2 (routed to 0.1" headers)
FlexRay Physical Interfaces	2 (routed to 0.1" headers)	2 (routed to 0.1" headers)
Ethernet Physical Interface	1 (MII and RMII Support)	1 (MII only mode)
USB Physical Interface	2 (USB Host and OTG)	1 (USB Host)
MLB Daughtercard Connector	Yes	No
SAI Audio / TWRPI Connectors	Yes	No
SDHC Connector	Full Size SDHC Socket	No
Fast External Osc (FXOSC)	Daughtercard Crystal * and SMA input connector	40 MHz Crystal
Slow External Osc (SXOSC)	Daughtercard Crystal *	32.768 KHz Crystal
CLKOUT signals available	Yes (GPIO Matrix)	Yes (Standalone pads)
User LEDs	4	4
User Pushbutton Switches	4	2
Hex Encoded Switch	Yes	Yes
Test Potentiometer for ADC	Yes	Yes
GPIO Matrix	All Available Pins not otherwise used for peripherals	Selection of Pins available from 5 GPIO Ports
Debug	14 Pin JTAG and 50 pin Nexus	14 Pin JTAG
Configuration	Highly configurable via jumper shunts	Fixed (limited configuration via 0 ohm resistors)

\* Daughtercard crystals are typically 40 MHz for FXOSC and 32.768 KHz for SXOSC but may vary between daughtercards.

The figure below shows the customer EVB (left) next to the LCEVB(right).




Figure 1. Customer and LCEVB side by side

### 3. Configuration Overview

Out of the box, there is no configuration required for the LCEVB to function. Unlike the customer EVB, the LCEVB is primarily designed for a single mode of operation with no requirement for user configuration. If you wish to have a more flexible configuration the recommendation is that the fully configurable customer EVB is purchased.

There are however some jumper footprints and zero ohm resistors populated in positions that would normally have jumper headers fitted (for example on the MCU power supply lines and tracking to the peripheral interfaces). If required these can be de-soldered to modify functionality. Any such modification is done at the full risk of the user and no support or warranty repairs will be provided for a board that has been modified. Modifications should only be attempted by appropriately trained personnel using the correct equipment and Personal Protective Apparel

The diagram below gives an overview of the functional blocks of the LCEVB





Figure 2. EVB Functional Blocks

## 4. Initial Setup

This section details the power, reset, clocks, and debug configuration which is the minimum configuration needed in order to power ON the LCEVB.

### 4.1. Power Supply Configuration

*The Power supply section is located in the bottom left corner of the LCEVB*



The LCEVB requires an external power supply voltage of 5 V DC, minimum 1 A. There is a single 3.3 V switching regulator on the LCEVB providing MCU and peripheral power.


#### CAUTION

**Connecting a power supply with a voltage greater than 5 V will result in irrecoverable board damage. Check the power supply voltage before connecting the plug to the LCEVB.**

#### 4.1.1. Power Input Connector

Power is supplied to the LCEVB via a 2.1 mm connector from the wall-plug mains adapter as shown below. Note – if a replacement or alternative adapter is used, care must be taken to ensure the 2.1 mm plug uses the correct polarisation as shown below:

**Figure 3. 2.1 mm Power Connector**



#### 4.1.2. Power Switch

Slide switch SW2 can be used to isolate the power supply input from the EVB voltage regulators if required.

- Moving the slide switch to the right (away from the power connector) will turn the EVB ON.
- Moving the slide switch to the left (towards the power connector) will turn the EVB OFF.

### 4.1.3. Power Status LED

When power is applied to the LCEVB, two green LED's adjacent to the regulator and power connector show the presence of the supply voltages as follows:

- LED DS5 – Indicates that the 5.0 V supply voltage is present
- LED DS6 – Indicates that the 3.3 V switching regulator is functioning

If no LED's are illuminated when power is supplied to the LCEVB and the power switch is in the “ON” position, the power adapter may be faulty or there may be a fault with the LCEVB. If only one LED is illuminated there may be a short in that power supply rail – check there is nothing shorting on the EVB. If you continue to have problems, contact NXP for support.

#### CAUTION

In the event of a short on the regulator output (in which case one of the LED's would be off or dimly illuminated), the regulator and/or the shorted component will likely be hot.

### 4.1.4. MCU and Peripheral Voltage Configuration


The following MCU supply rails are connected to the 3.3 V switching regulator:

- VDD\_HV\_ADC0
- VDD\_HV\_ADC1
- VDD\_HV\_ADC1\_REF
- VDD\_HV\_A
- VDD\_HV\_B
- VDD\_HV\_FLA
- External Ballast Transistor Supply

Similarly all of the peripheral interfaces (or the I/O power in the peripheral interface) are supplied from 3.3 V as is the reset circuitry and the voltage sense wire on the JTAG connector.

## 4.2. Reset Control (SW3)

The reset circuitry is located in the bottom left quarter of the LCEVB next to the power switch



The MCU has a single bi-directional open drain Reset pin. Rather than connect multiple devices to the reset pin directly, a reset-in and reset-out buffering scheme has been implemented on the LCEVB as shown in [Figure 4](#). The reset “in” from the reset switch (SW3) and the debug connectors are logically OR'd together using an AND gate and then connected to the buffer to provide an open-drain output.

The “reset-out” circuitry provides a buffered reset signal that can be used to drive any circuitry requiring a reset control from the MCU.

This scheme is not required if it is guaranteed that anything driving the reset pin has an open drain drive and that there is no significant output load on the MCU reset pin.




Figure 4. EVB Reset Control

#### 4.2.1. Reset LEDs

As can be seen above, there are two reset LED's that can be used to identify the source / cause of a reset:  
RED LED DS8 (titled “MCU”) will illuminate if:

- The MCU issues a reset (in this condition ONLY this LED will be illuminated and LED DS1 will be off)
- There is a target reset (ie from the reset switch or from the debugger in which case LED DS1 will be ON)

YELLOW LED DS7 (titled “EXT”) will illuminate when an external hardware device issues a reset to the MCU:

- The reset switch is pressed
- There is a reset being driven from one of the debug connectors

Table 2. Reset LED Decoding

LED DS7 (Yellow)	LED DS8 (Red)	Description
OFF	OFF	No Reset being issued from MCU or external logic
OFF	ON	MCU has issued a reset
ON	OFF	External reset issued from switch or debug BUT not being issued to MCU (check R137 has not been removed)
ON	ON	External reset issued from reset switch or debug and has been issued to MCU.

## 4.3. MCU Clock Configuration

There is an external 40MHz crystal connected to the MCU Fast External Oscillator (FXOSC) pins EXTAL and XTAL.


There is also a 32.768 crystal connected to the MCU Slow External Oscillator (SXOSC) pins OSC32K\_EXTAL and OSC32K\_XTAL. This can be used for accurate time keeping.

There are 2 pads PG6 and PG7 (located just below the MCU) on the LCEVB to facilitate measurement of the CLKOUT1 and CLKOUT0 signals.

Note – there is no external clock input on the LCEVB

## 4.4. Debug Connector (P1)

The JTAG debug connectors is located in the top left corner of the LCEVB



The LCEVB has a single 14-pin keyed JTAG connector for connection to an external debugger.

Before attaching or removing the debug cable from the LCEVB remove power from the EVB to prevent damage to the LCEVB or debug hardware.

### 4.4.1. Debug Connector Pinout

The following tables list the pinout for the JTAG connector used on the LCEVB

Table 3. 14-Pin JTAG Debug Connector Pinout

Pin No	Function	Connection	Pin No	Function	Connection
1	TDI	PC0	2	GND	GND
3	TDO	PC1	4	GND	GND
5	TCLK	PH9	6	GND	GND
7	EVTI	PL8	8	N/C	---
9	RESET	JTAG-RSTx	10	TMS	PH10
11	VREF	PER_HVA	12	GND	GND
13	RDY	---	14	JCOMP	10K Pulldown

TDI, TDO and TMS have 10K pullup resistors on the LCEVB. TCLK has a 10K pulldown (R147) to facilitate STANDBY exit without any additional code (at the sacrifice of slightly higher STANDBY current), however this can be changed to a pullup if required by removing R147 and fitting the resistor on R56.

**Table 4. JTAG Pins Pull State (from MPC5748G Reference Manual)**


TERMINAL TYPE <sup>1</sup>	POWERUP pad state <sup>2</sup>	RESET pad state	DEFAULT pad state <sup>3</sup>
RESET	strong pull-down	strong pull-down	weak pull-up
PORST <sup>4</sup>	Weak pull down	Weak pull up	weak pull-up
GPIO	high impedance	high impedance	high impedance
ANALOG	high impedance	high impedance	high impedance
EOUT0, EOUT1	high impedance	high impedance	high impedance
TCK	high impedance	weak pull-up	weak pull-up
TMS	high impedance	weak pull-up	weak pull-up
TDI	high impedance	weak pull-up	weak pull-up
TDO	high impedance	high impedance	high impedance

## 5. Communications & Memory Interfaces:

This section details the communication interface and storage peripherals that are implemented on the LCEVB.

### 5.1. CAN Interfaces (P2, P3)

The CAN circuitry is located on the top right edge of the LCEVB



The LCEVB incorporates two identical CAN interface circuits connected to MCU CAN0 and CAN1 using MC33901 transceivers. Both transceivers are configured for high speed operation by pulling pin 8 to GND via a 4.7 KOhm resistor. There are test points to allow the Select pin to be driven high if desired. The MC33901 is pin compatible with other CAN transceivers supporting full CAN FD data rates.

For flexibility, the CAN transceiver I/O is connected to a 0.1" header (P2 for CAN0 / P3 for CAN1) rather than using non-standard DB9 connectors. The pinout of these headers is shown below.





Figure 5. CAN Physical Interface Connectors

## 5.2. LIN Interfaces (P6, P7)


The LIN Physical interface circuits are located on the right edge of the LCEVB



The LCEVB incorporates two LIN transceiver circuits connected to MCU LIN0 and LIN1, using an NXP MC33662 transceiver. The MPC5748G LIN0 supports both master and slave modes whereas LIN1 only supports master mode.

On the LCEVB, the LIN0 transceiver is configured as slave mode by default. Master mode operation is possible by either populating a zero ohm resistor (R143) or buy fitting a jumper header (J2) – see the schematics for details. The LIN0 transceiver is hard wired for master mode.

To save on board space and cost, both LIN transceivers are connected to 0.1" pitch 3x1 headers as shown below rather than the usual LIN Molex header.




**Figure 6. LIN Physical Interface Connector**

*Note that in order for the LIN transceiver to function, external 12v must be supplied via pin 2 of the connector*

## 5.3. USB RS232 Serial Interface (P11)

The USB RS232 interface is on the left hand edge of the board (USB Type B)



The LCEVB incorporates a USB RS232 serial interface providing RS232 connectivity via a direct USB connection between the PC and the EVB. The circuit contains an FTDI FT2232D USB to Serial interface which should automatically install the drivers for two additional COM ports on your PC. Note that only one of these ports is used so you will need to try both (usually the higher numbered COM port is the active one). For more information on the USB drivers and general fault finding, consult the FTDI website at <http://www.ftdichip.com/>

The MCU LIN2 signals are routed to the FTDI transceiver (UART TX and RX). No handshaking signals are implemented and no board configuration is required.

## 5.4. USB HOST Interface (P4)


The USB Host interface is on the top left corner of the LCEVB on the left



The LCEVB includes a Type A (Host) USB interface, routed to a USB type A female connector. The USB circuit contains a USB83340 transceiver with a MIC2026-1YM USB power switch. There is no hardware user configuration required to use the USB circuit.

## 5.5. Ethernet Interface (P5)

*The Ethernet interface is mid-way along the top edge of the LCEVB*




The EVB incorporates a single DP83848c Ethernet transceiver with the circuitry configured for MII mode. The transceiver is connected to a pulse J1011F21PNL RJ45 connector which includes a built-in isolation transformer. There is no hardware configuration needed.

If you require RMII mode or access to both Ethernet ports on the MPC5748G, please purchase the MPC5748G customer EVB and appropriate daughter cards.

Note that the MCU Ethernet signals are all in the VDD\_HV\_B domain. The Ethernet PHY will only function with 3.3 V I/O so if you have made any modifications to the EVB power domain configuration (via the zero ohm resistors), you need to ensure the VDD\_HV\_B domain is at 3.3 V before attempting to use the Ethernet module. If VDD\_HV\_B is set to 5 V, the signals routed to the Ethernet PHY (see the EVB schematics) must be left as tristate to prevent damage to the transceiver.

## 5.6. FlexRay (P8, P9, P10)

*The FlexRay interfaces are midway down the left hand edge of the LCEVB*



The LCEVB incorporates two FlexRay TJA1080TS/N interfaces connected to MCU FlexRay channels A and B and routed to two Molex 1.25 mm pitch PicoBlade shrouded headers (standard on many NXP EVB's). There is no hardware configuration required to use FlexRay.

Note that the LCEVB is supplied with a 40 MHz crystal by default. If FlexRay is configured to use the external clock source, then the crystal should be left at 40 MHz.

## 6. User Interface (I/O)

This section details the user I/O available on the LCEVB and includes the GPIO matrix, switches, LED's and the ADC variable resistor.

### 6.1. GPIO Matrix

The GPIO matrix is on the right hand edge of the LCEVB



A sub-set of available GPIO pins (available pins being those not already routed to LCEVB peripherals) are available at the GPIO matrix as detailed below. The matrix provides an easy to follow, intuitive, space saving grid of 0.1" header through-hole pads. Users can solder wires, fit headers or simply insert a scope probe into the respective pad.

To use the matrix, simply read the port letter from the top or bottom row of text then the pad number from the columns on the left or right of the matrix. For example, the 1<sup>st</sup> pad available on Port B is PB5 as outlined below.

A 16x6 grid representing the GPIO matrix. The columns are labeled A, B, D, F, I at the top and bottom. The rows are numbered 0 through 15 on the left. A red arrow points to the intersection of Row 5 and Column B, which is highlighted with a yellow box. A ground connection is shown at the bottom left.

	A	B	D	F	I	
0	■			■		0
1	■			■		1
2	■			■		2
3				■		3
4				■		4
5		■		■		5
6				■		6
7				■		7
8				■		8
9				■		9
10				■		10
11				■		11
12				■		12
13				■		13
14				■		14
15				■		15
	A	B	D	F	I	
						GND

Figure 7. GPIO Matrix

If a pad is populated in the matrix, it means this is available for exclusive use as GPIO. The exception to this are the port pins detailed below which are also shared with switches or user LED's (shaded red in the matrix diagram above).

- PD0, PD1, PD2, PD3 – HEX Encoder Switch
- PA1, PA2 – User pushbutton Switches

If you require access to all of the available GPIO pads, the customer EVB and daughtercard provides this additional functionality.

## 6.2. User Switches (SW4, SW5)

The user pushbutton switches are in the bottom right corner of the LCEVB



There are two active high (pulled low, driven to 3.3 V) pushbutton switches on the LCEVB connected directly to MCU GPIO ports. No configuration is required to use the switches.

SW4 is connected to port PA1 (which is also the NMI pin) and SW5 is connected to port PA2

### NOTE

The MCU ports used on the user pushbutton switches are also routed to the GPIO matrix.

## 6.3. Hex Encoded Switch (SW1)

The hex encoder switch is located to the left of the GPIO Matrix



There is a single hex encoded 16 position rotary switch on the LCEVB. This outputs a binary encoded hex value (active high) on four MCU ports (Port D[0..3]).

**Table 5. Hex Encoder Switch (SW2)**

Position	HEX_SW4 (PD3)	HEX_SW3 (PD2)	HEX_SW2 (PD1)	HEX_SW1 (PD0)
0	0	0	0	0
1	0	0	0	1
2	0	0	1	0
3	0	0	1	1
4	0	1	0	0
5	0	1	0	1
6	0	1	1	0
7	0	1	1	1
8	1	0	0	0
9	1	0	0	1
A	1	0	1	0
B	1	0	1	1
C	1	1	0	0
D	1	1	0	1
E	1	1	1	0
F	1	1	1	1

Note that POSN 0 will ensure that no voltage is applied to the pads. This allows the pads to be used as normal GPIO (with 10K pulldown) and accessed at the respective pads on the GPIO matrix area.

## 6.4. User LED's (DS1, DS2, DS3, DS4)

The user LED's are above the user switches in the lower right corner




There are four **active low** user LED's, DS1 to DS4, connected directly to 4 MCU ports (PG[2..5]) as shown below. No configuration is required to use the LED's.

**Table 6. Use LED's (DS1, DS2, DS3 and DS4)**

User LED	MCU Pin
DS1	PG2
DS2	PG3
DS3	PG4
DS4	PG5

## 6.5. ADC Input Potentiometer (RVAR, RV1)

The ADC Pot is above the hex switch to the left of the GPIO matrix



There is a small variable resistor RV1 on the LCEVB which routes a voltage between 0v and 3.3 V to MCU pin PB4. This is useful for quick ADC testing. Test point RVAR can be used to probe the voltage with a voltmeter.

Note that this circuit provides a very rough way to evaluate the ADC. There is a small current limiting series resistor network to limit the injection current to around 4.4 mA.

## 7. MCU Port Pin LCEVB Functions

The table below shows what each MCU pin is used for on the LCEVB.

**Table 7. LCEVB 176QFP Port Pin Functions**

No	Port A	Port B	Port C	Port D	Port E	Port F	Port G	Port H
<b>0</b>	GPIO	CAN0	JTAG	GPIO <sup>3</sup>	---	GPIO	Ethernet	Ethernet
<b>1</b>	GPIO <sup>2</sup>	CAN0	JTAG	GPIO <sup>3</sup>	---	GPIO	Ethernet	Ethernet
<b>2</b>	GPIO <sup>2</sup>	LIN0	USB1	GPIO <sup>3</sup>	FlexRay A	GPIO	GPIO <sup>4</sup>	Ethernet
<b>3</b>	Ethernet	LIN0	USB1	GPIO <sup>3</sup>	FlexRay A	GPIO	GPIO <sup>4</sup>	---
<b>4</b>	GPIO	ADC Pot	FlexRay B	GPIO	FlexRay B	GPIO	GPIO <sup>4</sup>	---
<b>5</b>	GPIO	GPIO	FlexRay A	GPIO	FlexRay B	GPIO	GPIO <sup>4</sup>	---
<b>6</b>	GPIO	GPIO	LIN1	GPIO	---	GPIO	GPIO	---
<b>7</b>	Ethernet	GPIO	LIN1	GPIO	---	GPIO	GPIO	---
<b>8</b>	Ethernet	EXTAL32	RS232	GPIO	---	GPIO	---	---
<b>9</b>	Ethernet	XTAL32	RS232	GPIO	---	GPIO	---	JTAG
<b>10</b>	Ethernet	SAI Audio	CAN1	GPIO	---	GPIO	USB1	JTAG
<b>11</b>	Ethernet	GPIO	CAN1		---	GPIO	USB1	USB1
<b>12</b>	GPIO	GPIO	FlexRay	GPIO	Ethernet	GPIO	Ethernet	USB1
<b>13</b>	GPIO	GPIO	FlexRay	GPIO	Ethernet	GPIO	Ethernet	---
<b>14</b>	GPIO	GPIO	FlexRay	GPIO	USB1	Ethernet	USB1	---
<b>15</b>	GPIO	GPIO	FlexRay	GPIO	USB1	Ethernet	USB1	---

No	Port I	Port J
<b>0</b>	GPIO	---
<b>1</b>	GPIO	---
<b>2</b>	GPIO	---
<b>3</b>	GPIO	---
<b>4</b>	USB1	---
<b>5</b>	USB1	
<b>6</b>	GPIO	
<b>7</b>	USB1	
<b>8</b>	GPIO	
<b>9</b>		
<b>10</b>		
<b>11</b>	Ethernet	
<b>12</b>	GPIO	
<b>13</b>	GPIO	
<b>14</b>	GPIO	
<b>15</b>	GPIO	

Key:	
	Pin not bonded out on 176QFP package
---	Pin not accessible on LCEVB

<sup>2</sup> Shared with user switches

<sup>3</sup> Shared with Hex Encoder Switch

<sup>4</sup> Shared with user LED's

## 8. Appendix

The MPC5748G LCEVB schematics, Rev B are shown below.

# MPC5748G Low Cost Evaluation Board (MPC5748G-LCEVB)

## Table Of Contents:

Power - Main input and 3.3V regulator	Sheet 2
Power - MCU Power	Sheet 3
Power - MCU Decoupling	Sheet 4
Reset and JTAG	Sheet 5
Clocks	Sheet 6
MCU GPIO 1	Sheet 7
MCU GPIO 2	Sheet 8
Comms1 - CAN and LIN	Sheet 9
Comms 2 - FTDI RS232 Interface	Sheet 10
Comms 3 - USB Host Interface (device footprints only)	Sheet 11
Comms 4 - Ethernet (MII Mode)	Sheet 12
Comms 5 - FlexRay	Sheet 13
User - Switches, LED's and Potentiometer	Sheet 14
User - GPIO Pin Matrix	Sheet 15

## Revision Information

Rev	Date	Designer	Comments
x1	14 Apr 2015	Alasdair Robertson	Start of capture, Working version (256BGA)
x2	08 May 2015	Alasdair Robertson	Changed to 176 QFP Package and changed peripheral Matrix
x3	18 May 2015	Alasdair Robertson	Changes required for initial placement
x4	19 May 2015	Alasdair Robertson	Tidy Up, Replaced some "hard to source" components
x5	26 May 2015	Alasdair Robertson	Renumber and Back Annotated from Layout
x6	27 May 2015	Alasdair Robertson	Correction to GND on 3v3 Regulator circuit
x7	29 May 2015	Alasdair Robertson	Correction to CAN Test points
x8	31 May 2015	Alasdair Robertson	Few refdes changes after layout tweaks
x9	01 Jun 2015	Alasdair Robertson	Correction to user LED Refdes after re-number
x10	01 Jun 2015	Alasdair Robertson	DNP Jumpers. 0 Ohm resistors added accross LIN jumpers
A	11 Jun 2015	Andrew MacDonald	Prototype Manufacture Release
AX1	29 Sep 2015	Alasdair Robertson	Prodn Build changes (LIN0 default to Slave, LIN1 Master only) PN Changed to MPC5748G-LCEVB
AX2	26 Oct 2015	Alasdair Robertson	Change to JTAG Pulls to meet latest RM Spec
AX3	29 Oct 2015	Alasdair Robertson	Changed RV1 current limit resistor. SW4 / SW5 refdes swap
AX4	09 Dec 2015	Alasdair Robertson	Pull DOWN on TCLK to mitigate against STANDBY exit issue.
AX5	20 Jan 2016	Alasdair Robertson	Updated NXP Logos
B	12 Feb 2016	Alasdair Robertson	Updated NXP Logos

## Caution:

These schematics are provided for reference purposes only.  
As such, NXP does not make any warranty, implied or otherwise, as to the suitability of circuit design or component selection (type or value) used in these schematics for hardware design using the NXP Calypso family of Microprocessors. Customers using any part of these schematics as a basis for hardware design, do so at their own risk and NXP does not assume any liability for such a hardware design.

## Notes:

- All components and board processes are to be ROHS compliant
- All small capacitors are 0402 unless otherwise stated
- All resistors are 0603 5% 0.1w unless otherwise stated. All zero ohm links are 0603
- All connectors and headers are denoted Px and are 2.54mm pitch unless otherwise stated
- All jumpers are denoted Jx. Jumpers are 2mm pitch
- Jumper default positions are shown in the schematics. For 3 way jumpers, default is always posn 1-2. 2 Pin jumpers generally have the "source" on pin 1.
- All switches are denoted SWx
- All test points (SMT wire loop style) are denoted TPx
- Test point Vias (just through hole pads) are denoted TPVx

**Signals (ports) have not been routed via busses as this makes it harder to determine where each signal goes.**

User notes are given throughout the schematics.

Specific PCB LAYOUT notes are detailed in **ITALICS**

3 Different test points used in design:

TPVx - Through Hole Pad small



TPHx - Through Hile Pad Large (for standard 0.1" header).  
Also used on IO Matrix (IOMx)







TPx - Surface Mount Wire Loop



	<b>Automotive Microcontroller Applications East Kilbride, Scotland</b>					
<b>NXP General Business Use</b>						
This document contains information proprietary to NXP and shall not be used for engineering design, procurement or manufacture in whole or in part without the express written permission of NXP Semiconductors.						
Designer: A. Robertson	<b>Drawing Title:</b> <b>MPC5748G-LCEVB</b>					
Drawn by: A. Robertson	<b>Page Title:</b> <b>Index and Title Page</b>					
Approved: A. Robertson	Size B	Document Number SCH-27897 PDF:SPF-27897	Rev B			
<b>Date:</b> Friday, February 12, 2016 <b>Sheet:</b> 1 <b>of:</b> 15						

# Power Input and Linear Voltage Regulators



<b>NXP</b>		Automotive Microcontroller Applications East Kilbride, Scotland NXP General Business Use
Drawing Title:		<b>MPC5748G-LCEVB</b>
Page Title:		<b>Power Input and Linear Voltage Regulators</b>
Size B	Document Number	SCH-27897 PDF: SPF-27897
Date:	Friday, February 12, 2016	Sheet 2 of 15

# Calypso MCU Power Connections


## Power Supply Constraints:

- If VDD\_HV\_A is driven from 3.3V, VDD\_HV\_FLA must also be supplied from 3.3V
- If VDD\_HV\_A is driven from 5V, the VDD\_HV\_FLA pin must be disconnected from 3.3V
- Don't attempt to over drive an analogue pad to 5V when the digital VDD\_HV\_x supply is set to 3.3V. This will trigger the ESD protection on that pad. For example if VDD\_HV\_A is set to 3.3V and the analogue supplies are set to 5V, you cannot drive 5V into a pad in the VDD\_HV\_A domain

## Default Configuration:

- ALL MCU supply voltages are set to 3.3V (ADC0, ADC1, VDD\_HV\_A, VDD\_HV\_B, VDD\_HV\_C, VBallast)
- VDD\_HV\_FLA = External 3.3V supplied (jumper fitted)

The analogue pins can only be driven to the same voltage as the VDD\_HV\_x domain they are situated in (ie max 3.3V) so makes sense for the analogue supply and reference to be 3.3V



### Notes on signal Grounds:

- The scheme shown has the analogue and digital grounds connected to the same plane
- This results in better ADC performance than using an analogue ground plane with single entry point (or ferrite) to digital ground plane.



Automotive Microcontroller  
Applications  
East Kilbride, Scotland  
NXP General Business Use

Drawing Title: MPC5748G-LCEVB



Page Title: Calypso MCU Power

Size B	Document Number SCH-27899	PDF: SPF-27899	Rev B
--------	---------------------------	----------------	-------

Date: Friday, February 12, 2016



Sheet 3 of 15

# Calypso MCU Decoupling and bulk storage




## Capacitor Types:


4700pF	- Ceramic X7R, 50V 10% 0402
0.1uF	- Ceramic X7R, 16V 10% 0402 (Kemet C0402C104K4RAC)
0.68uF	- Ceramic X7R, 16V 10% 0805 (Murata GCM219R71C684KA37)
1uF	- Ceramic X7R, 10V 10% 0603 Low ESR (Taiyo Yuden LMK107B7105KA-T)
2.2uF	- Ceramic X7R, 10V 10% 0603 Low ESR (Taiyo Yuden LMK107B7225KA-TR)



## Ballast Transistor



## LP Internal Reg Cap



<b>NXP</b>		Automotive Microcontroller Applications East Kilbride, Scotland NXP General Business Use
Drawing Title: <b>MPC5748G-LCEVB</b>		A
Page Title: <b>Calypso MCU Decoupling</b>		
Size B	Document Number SCH-27899	Rev B
Date: Friday, February 12, 2016	Sheet 4 of 15	1

# Reset and External Clock In

Reset is in the VDD\_HVA domain.






Table 13-3. Functional terminal state during power-up and reset

TERMINAL TYPE <sup>1</sup>	POWERUP pad state <sup>2</sup>	RESET pad state	DEFAULT pad state <sup>3</sup>	Comments
RESET	strong pull-down	strong pull-down	weak pull-up	functional reset pad.
PORST <sup>4</sup>	Weak pull down	Weak pull up	weak pull-up	power on reset pad.
GPIO	high impedance	high impedance	high impedance	by default, but configurable for STANDBY exit
ANALOG	high impedance	high impedance	high impedance	-
EOUT0, EOUT1	high impedance	high impedance	high impedance	-
TCK	high impedance	weak pull-up	weak pull-up	-
TMS	high impedance	weak pull-up	weak pull-up	-
TDI	high impedance	weak pull-up	weak pull-up	-
TDO	high impedance	high impedance	high impedance	-
TCK_ALT	high impedance	weak pull-up	weak pull-up	-
TMS_ALT	high impedance	weak pull-up	weak pull-up	-
TDI_ALT	high impedance	weak pull-up	weak pull-up	-
TDO_ALT	high impedance	high impedance	high impedance	-

Note TCK needs to be pulled down to allow exit from STANDBY in some corner cases




<b>NXP</b>	Automotive Microcontroller Applications East Kilbride, Scotland NXP General Business Use
Drawing Title: <b>MPC5748G-LCEVB</b>	
Page Title: <b>Reset Circuitry &amp; External Clock In</b>	
Size <b>B</b>	Document Number <b>SCH-27897</b> PDF: <b>SPF-27897</b>
Date: <b>Friday, February 12, 2016</b>	Sheet <b>5</b> of <b>15</b>



<b>NXP</b>		Automotive Microcontroller Applications East Kilbride, Scotland NXP General Business Use
Drawing Title: <b>MPC5748G-LCEVB</b>		A
Page Title: <b>Clocks</b>		A
Size B	Document Number SCH-27899	Rev B
Date: Friday, February 12, 2016	Sheet 6 of 15	1


# Calypso GPIO 1 of 2



		Automotive Microcontroller Applications East Kilbride, Scotland NXP General Business Use
Drawing Title: MPC5748G-LCEVB		
Page Title: Calypso GPIO 1of2		
Size B	Document Number SCH-27899	Rev B
Date: Friday, February 12, 2016	Sheet 7 of 15	1

Key to text colours:

- Purple - Comms Physical Interfaces
- Orange - Other Peripherals and I/O
- Blue - Debug (JTAG & Nexus)
- Black - Clock, Reset and Control
- RED - I/O Matrix and other functions (eg LED)
- Green - I/O Matrix (dedicated)



Calypso 176QFP  
Package 3 of 3 GPIO Pins2


PPC5748GSK0MKU6

		Automotive Microcontroller Applications East Kilbride, Scotland NXP General Business Use
Drawing Title: MPC5748G-LCEVB		A
Page Title: Calypso GPIO 2 of 2		
Size B	Document Number SCH-27899	Rev B
Date: Friday, February 12, 2016	Sheet 8 of 15	1

# CAN & LIN Physical

## CANO Physical Interface

VDD - 5.0V input supply for CAN transceiver (4.5 to 5.5V)  
 VI/O - determines the signal level on MCU TX and RX pins and can range from 2.8 to 5.5V  
 STB - High for Standby mode, pulled low for normal mode.




All CAN and LIN signals are in power domain VDD\_HV\_A.

All interfaces will work at 3.3V or 5.0V (PER\_HVA)

## CANI Physical Interface

VDD - 5.0V input supply for CAN transceiver (4.5 to 5.5V)  
 VI/O - determines the signal level on MCU TX and RX pins and can range from 2.8 to 5.5V  
 STB - High for Standby mode, pulled low for normal mode.




## LINO Physical Interface

Configured as SLAVE by default (LINO Supports Master and Slave)

PER\_HVA  
 LINO-RX 1  
 (Enable) 2  
 (Wake) 3  
 LINO-TX 4  
 RXD 5  
 INH 6  
 VSUP 7  
 LIN 8  
 GND 9  
 TXD 10  
 MC33662BLEF (LEF = 20K Baud)

EN = PER\_HVA enables Transceiver and sets I/O for VDD\_HV\_A  
 WAKE = GND ensures no spurious wakeups

### Master Mode Pullup Enable



MC33662LEF LIN transceiver is newer version of 33661 offering:  

- Full LIN compliance (33661 no longer compliant)
- Improved ESD protection on LIN pin up to 15kV
- Improved ESD on Wake and VSUP Pins
- Other EMC and performance improvements

See freescale.com for more details


## LINI Physical Interface

Configured as MASTER by default (LIN1 only supports Master mode)

PER\_HVA  
 LIN1-RX 1  
 (Enable) 2  
 (Wake) 3  
 LIN1-TX 4  
 RXD 5  
 INH 6  
 VSUP 7  
 LIN 8  
 GND 9  
 TXD 10  
 MC33662BLEF (LEF = 20K Baud)

EN = PER\_HVA enables Transceiver and sets I/O for VDD\_HV\_A  
 WAKE = GND ensures no spurious wakeups

### Master Mode Pullup Enable



Automotive Microcontroller Applications  
 East Kilbride, Scotland  
 NXP General Business Use

Drawing Title: MPC5748G-LCEVB

Page Title: CAN and LIN

Size B Document Number SCH-27897 PDF:SPF-27897 Rev B

Date: Friday, February 12, 2016

Sheet 9 of 15


# USB RS232 (serial) Interface

All Signals are in power domain VDD\_HV\_A.

FTDI interface will work at 3.3V or 5.0V (PER\_HVA)

## FTDI USB <-> Serial Interface

- Self Powered mode. No power is taken from USB
- Device defaults to Dual serial (RS232) mode ie RS232 on both A and B
- Configurable I/O voltage on CHA / CHB via VDDIOA/B




<b>NXP</b>	Automotive Microcontroller Applications East Kilbride, Scotland NXP General Business Use
Drawing Title: <b>MPC5748G-LCEVB</b>	
Page Title: <b>USB RS232 Interface</b>	
Size B	Document Number SCH-27897 PDF: SPF-27897
Rev B	

# USB (Type A Host and Type AB OTG)

USB Signals  
are in  
power  
domain  
**VDD\_HV\_A**

The USB  
interface  
only supports  
3.3V  
operation.  
All I/O  
signals must  
be 3.3V. If  
**VDD\_HVA** is  
set to 5V,  
USB MCU pads  
must be left  
as tri-state  
with no  
pullups.



Automotive Microcontroller  
Applications  
East Kilbride, Scotland  
NXP General Business Use

Drawing Title: MPC5748G-LCEVB

Page Title: USB Type A / Type AB

Size B	Document Number	SCH-27897	PDF: SPF-27897	Rev B
--------	-----------------	-----------	----------------	-------


Date: Friday, February 12, 2016

Sheet 11 of 15

# Ethernet (Configured for MII Mode)

All Ethernet Signals are in power domain VDD\_HVA

The Ethernet interface only supports 3.3V operation. All I/O signals must be 3.3V. If VDD\_HVA is set to 5V, Ethernet MCU pads must be left as tri-state with no pullups.




<b>NXP</b>	Automotive Microcontroller Applications East Kilbride, Scotland NXP General Business Use
Drawing Title: <b>MPC5748G-LCEVB</b>	
Page Title: <b>Ethernet</b>	
Size B	Document Number SCH-27897 PDF: SPF-27897
Date: Friday, February 12, 2016	Sheet 12 of 15

# FlexRAY Physical Interface


All Signals are in power domain VDD\_HV\_A.

FlexRAY interface will work at 3.3V or 5.0V (PER\_HVA)




Note on VBAT:  
- Operational range is 6.5v to 60V  
- Undervoltage detection is max 4.5v

On EVB this is supplied from 5v, In theory this should be to battery with 60uS delay between applying Vbat and I/O voltages. If necessary, 12V can be externally supplied by removing the resistor and connecting pad to 12v







BGE: Bus Guardian Enable. Pull high to enable transmitter  
STBN: Standby Input. Pull High for non standby mode  
EN: Enable Input. Pull high to enable




## FlexRAY A

Decoupling Caps for BOTH IC's. Place next to power pins.



Bus voltage +/- 12V (VBAT = 12v)  
Components spec'd for 12V operation



Bus voltage +/- 12V (VBAT = 12v)  
Components spec'd for 12V operation

MODE	EN	STBN
Normal	1	1
Rec Only	0	1
Go to Sleep	1	0
Sleep	0	0



Automotive Microcontroller Applications  
East Kilbride, Scotland  
NXP General Business Use

Drawing Title: MPC5748G-LCEVB

Page Title: FlexRAY Physical Interface





Size B Document Number SCH-27897 PDF: SPF-27897 Rev B

Date: Friday, February 12, 2016

Sheet 13 of 15

# User Peripherals (Led's, Switches and ADC Pot)


Switches are hard wired to 3.3V rather than 5V so it's not possible to drive 5V into a 3.3V pad (which would cause damage)  
 Similarly, the LED's are active low with 3.3v supply so can be safely coupled to pads on either 3.3V or 5V domains  
 The ADC input is limited to 3.3V, again to prevent driving 5V into a 3.3V pad which would cause damage



		Automotive Microcontroller Applications East Kilbride, Scotland NXP General Business Use
Drawing Title: <b>MPC5748G-LCEVB</b>		
Page Title: <b>User Peripherals</b>		
Size B	Document Number	SCH-27897 PDF: SPF-27897
Rev B		
Date: Friday, February 12, 2016	Sheet 14 of 15	1

# GPIO Pin Matrix

All pads are DNP (Do Not Populate) 0.1" pitch headers placed on a 0.1" grid



		Automotive Microcontroller Applications East Kilbride, Scotland NXP General Business Use
Drawing Title: <b>MPC5748G-LCEVB</b>		A
Page Title: <b>GPIO Pin Matrix</b>		
Size B	Document Number SCH-27897 PDF: SPF-27897	Rev B
Date: Friday, February 12, 2016	Sheet 15 of 15	1

**How to Reach Us:**

**Home Page:**  
[nxp.com](http://nxp.com)

**Web Support:**  
[nxp.com/support](http://nxp.com/support)

Information in this document is provided solely to enable system and software implementers to use NXP products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits based on the information in this document. NXP reserves the right to make changes without further notice to any products herein.

NXP makes no warranty, representation, or guarantee regarding the suitability of its products for any particular purpose, nor does NXP assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in NXP data sheets and/or specifications can and do vary in different applications, and actual performance may vary over time. All operating parameters, including "typicals," must be validated for each customer application by customer's technical experts. NXP does not convey any license under its patent rights nor the rights of others. NXP sells products pursuant to standard terms and conditions of sale, which can be found at the following address: [nxp.com/SalesTermsandConditions](http://nxp.com/SalesTermsandConditions).

NXP, the NXP logo, NXP SECURE CONNECTIONS FOR A SMARTER WORLD, COOLFLUX, EMBRACE, GREENCHIP, HITAG, I2C BUS,ICODE, JCOP, LIFE VIBES, MIFARE, MIFARE CLASSIC, MIFARE DESFire, MIFARE PLUS, MIFARE FLEX, MANTIS, MIFARE ULTRALIGHT, MIFARE4MOBILE, MIGLO, NTAG, ROADLINK, SMARTLX, SMARTMX, STARPLUG, TOPFET, TRENCHMOS, UCODE, Freescale, the Freescale logo, AltiVec, C-5, CodeTEST, CodeWarrior, ColdFire, ColdFire+, C-Ware, the Energy Efficient Solutions logo, Kinetis, Layerscape, MagniV, mobileGT, PEG, PowerQUICC, Processor Expert, QorIQ, QorIQ Qonverge, Ready Play, SafeAssure, the SafeAssure logo, StarCore, Symphony, VortiQa, Vybrid, Airfast, BeeKit, BeeStack, CoreNet, Flexis, MXC, Platform in a Package, QUICC Engine, SMARTMOS, Tower, TurboLink, and UMEMS are trademarks of NXP B.V. All other product or service names are the property of their respective owners. ARM, AMBA, ARM Powered, Artisan, Cortex, Jazelle, Keil, SecurCore, Thumb, TrustZone, and  $\mu$ Vision are registered trademarks of ARM Limited (or its subsidiaries) in the EU and/or elsewhere. ARM7, ARM9, ARM11, big.LITTLE, CoreLink, CoreSight, DesignStart, Mali, mbed, NEON, POP, Sensinode, Socrates, ULINK and Versatile are trademarks of ARM Limited (or its subsidiaries) in the EU and/or elsewhere. All rights reserved. Oracle and Java are registered trademarks of Oracle and/or its affiliates. The Power Architecture and Power.org word marks and the Power and Power.org logos and related marks are trademarks and service marks licensed by Power.org.

© 2016 NXP B.V.



Document Number: MPC5748GLCEVBUG  
Rev. 0  
05/2016

