

AS7421 Evaluation Kit

Quick Start Guide

AS7421 Evaluation Kit

Quick Start Guide

AS7421 EVK Contents

AS7421 Sensor Board

Setup

AS7421 PC Software



Contents of the AS7421 Evaluation Kit

AS7421 Evaluation Kit - Out of the box




Fig. 1: AS7421 Evaluation Kit content

Out of the box

- 1 Flex cable
- 2 AS7421 Sensor board
- 3 Unicom Board
- 4 micro USB to USB cable
- 5 Reference Target
- 6 USB Flash Drive



Contents of the AS7421 Evaluation Kit

AS7421 Evaluation Kit

The AS7421 Evaluation (Eval) Kit is designed to evaluate all the functions of the AS7421 64-Channel Spectral NIR sensor.

The Eval Kit contains two boards: the AS7421 sensor board (2 in Fig. 1) and the Unicom microcontroller board (3 in Fig. 1). The sensor board is connected to the Unicom microcontroller board via a flex cable (1 in Fig. 1).

The Eval Kit works with a USB connection (4 in Fig. 1) to the PC and comes with a Windows GUI, which enables the user to change measurement settings, perform spectral measurements, and see/export measurement results.

The kit comes with firmware flashed on the STM32 ARM Cortex microcontroller.

AS7421 Sensor Board

Introduction




Fig. 2: Top view of the AS7421 sensor board with installed optomechanical parts




Fig. 3: Bottom view of the AS7421 sensor board with installed optomechanical parts

Setup

Getting Started





Fig. 4: Unicom microcontroller board

- 1. Connect the AS7421 sensor board with the Unicom microcontroller board via the flex cable provided.
- 2. To install the "AS7421 Windows Demo GUI" software on your computer, start the executable "Setup.exe" and follow the installation instructions¹.
- 3. Then, connect the Unicom microcontroller board to a PC via the micro USB cable.
- 4. Both green LEDs on the Unicom microcontroller board will light up, signaling a correct operation.
- 5. Finally, start the Windows GUI on your computer.

^{1 -} If you already have an old Demo software version, please go to the Windows settings, add/remove software, then remove the old version



GUI Overview - Main menu areas




<u>Key</u>

- 1 Settings area
- 2 Header line area
- 3 Plotting area

Fig. 5: AS7421 GUI Overview of the main areas



GUI Overview – Settings Area



Key

- 1 Connection tab
- 2 Settings tab
- 3 Export tab
- 4 Calibration tab
- 5 Measurement/Teaching tab
- 6 Measurement Data tab
- 7 Status bar

Fig. 6: AS7421 GUI Overview of the Settings area



Starting a measurement – connecting the AS7421 Eval board




Fig. 7: AS7421 Demo GUI

- Firstly, connect the evaluation board to your computer using a micro USB cable according to the procedure from the <u>previous page</u> – the board will register as a virtual COM port in Windows.
- 2. Afterward, select the correct COM port in the selection box on the upper left corner of the application and click "Connect".
- 3. The ID field under the "Connect" button will show the unique ID of the AS7421 sensors upon successful connection.
- 4. When connecting to the sensor board for the first time, the software will ask for an appropriate calibration file. The calibration file is named after the unique ID and can be found on the USB drive, which is part of the evaluation kit. If no matching calibration file is present, please contact ams-OSRAM and provide the sensor board ID number.



Starting a measurement




Fig. 8: AS7421 Demo GUI with a measurement

- 5. If the measured data is needed later for evaluation, choose an export path. This saves the data in CSV format.
- 6. Align the sensor board with the measurement target and choose the desired measurement options, such as continuous measurement, or stop after a desired amount of measurements.
- 7. Then, click "Measurement" to start the spectral measurement process.
- 8. Afterward, the software will show the spectrum of the measured target.
- In the lower-left corner it is possible to choose between different measured spectral data drawings and calculations.



Sensing is life

CIM OSRAM