



## RIGHT ANGLE JACKS FOR SEMI-RIGID CABLE


Amphenol Number	A
82-6096-RFX	.138 (3.5)
82-6097-RFX	.138 (3.5)
82-6162	.138 (3.5)
82-6098-RFX	.138 (3.5)
82-6099-RFX	.138 (3.5)
82-6163-RFX	.138 (3.5)
82-5955-RFX	.098 (2.5)
82-5956-RFX	.138 (3.5)
82-6124	.157 (4.0)




**Step 1** All parts of the connector are shown.




**Step 2** Strip the inner conductor, dielectric, and jacket as per "RECOMMENDED CABLE STRIPPING DIM'S" in catalog.



**Step 3** Slide the INSULATOR onto inner conductor against the jacket. Then insert inner conductor into the CONTACT PIN and solder it as shown.



**Step 4** Slide the SOLDER NUT onto cable.



**Step 5** Insert cable and parts into the MAIN BODY, then screw the SOLDER NUT until it is tight and solder it as shown.