




STRAIGHT SQUARE FLANGE JACK CRIMP TYPE CABLE 5.5/50D





Technical Data Sheet

STRAIGHT SQUARE FLANGE JACK CRIMP TYPE CABLE 5.5/50D

PAGE 2/3	ISSUE 19-10-15D	SERIES TNC	PART NUMBER R143297700
-----------------	------------------------	------------	-------------------------------

PACKAGING

1	Contact us	Contact us
Standard	Unit	Other

ELECTRICAL CHARACTERISTICS

Impedance 50 Frequency 0-6 GHz **VSWR** 1.2 0,0000 x F(GHz) Maxi √F(GHz) dB Maxi Insertion loss 0.06 RF leakage 57* - F(GHz)) dB Maxi - (500 Voltage rating Veff Maxi Dielectric withstanding voltage 1500 Veff mini Insulation resistance 5000 $M\Omega$ mini

MECHANICAL CHARACTERISTICS

Center contact retention

Axial force - Mating End NA N mini Axial force - Opposite end NA N mini N.cm mini NA Torque

Recommended torque

NA Mating N.cm Panel nut NA N.cm Clamp nut N.cm 170 A/F clamp nut 8,0000 mm

Mating life 500 Cycles mini 19,9500 g

Weight

ENVIRONMENTAL

-65/+165 Operating temperature °C Hermetic seal NA Atm.cm3/s Panel leakage NA

SPECIFICATION

ASN-E0461 TC01 - -

CABLE ASSEMBLY

Stripping	а	b	С	d	е	f
mm	9	9	23	0	0	0

Assembly instruction:

Recommended cable(s)

KX 23 RG 142 FTX RG 142 BU RG 400 RG 223

Characteristics indicated on this data sheet are those that can be achieved with the highest performance cable. Intrinsic limitations of the cable may diminish the performance of the

Cable retention

- pull off 180 N mini - torque NA N.cm

TOOLING

Part Number	Description	Hexagon	
282291	CRIMPING TOOL M22520/1-01	2x4 (pos7)	
282997	POSITIONER FOR TOOL 282.291 (M22520/1-13)	rouge	
R282223000	CRIMPING TOOL	5.41	

OTHER CHARACTERISTICS


*Up to 3 GHz





STRAIGHT SQUARE FLANGE JACK CRIMP TYPE CABLE 5.5/50D

PAGE 3/3 ISSUE 19-10-15D SERIES TNC PART NUMBER R143297700




1

Slide onto the cable the heatshrink sleeve and the ferrule

Strip the cable.

Optionally, to facilitate the stripping of the inner cable, the length "a" could be stripped after crimping of the ferrule.





2

Slide the clamp nut onto the crimp sleeve.

Slide sub-assembly under the braid.


Slide ferrule over the braid against clamp nut.(In direction F) Crimp the ferrule with crimping tool + dies





3

The dielectric must be in the same plane as the face of the crimp sleeve. Cut the dielectric flush to crimp sleeve if it exceeds. Clean the dielectric side. Mount insulator against crimp sleeve.



4

Slide the center contact onto the cable inner conductor against insulator.

Crimp the center contact.with the crimping tool and the positioner.



5

Screw sub-assembly into the connector body. (recommended coupling see the connector TDS) Slide sleeve heatshrink over ferrule and put in the place as below

