
# Energy Management Energy Analyzer Type EM112



- Single phase energy analyzer
- Class 1 (kWh) according to EN62053-21
- Class B (kWh) according to EN50470-3
- Accuracy ±0.5% RDG (current/voltage)
- Direct current measurement up to 100AAC
- · Backlit LCD display (3x 8-digit) with integrated touch key-pad
- Energy readout on display: 8 digit
- · Variable readout on display: 4 digit
- Energy measurement: kWh and kvarh (imported/exported); kWh+ by 2 tariffs
- System variables, kW, kvar, V, A, PF, Hz, kWdmd, kWdmd peak
- · Self power supply
- Dimensions: 2-DIN module
- Protection degree (front): IP51
- Pulse output (optional, by open collector PNP)
- RS485 Modbus port (optional)
- M-bus port (optional)
- Digital input (for tariff management)
- Easy connection or wrong current direction detection
- Certified according to MID Directive (option PF only): see
  "how to order" below

### **Product description**

Single-phase energy analyzer with backlit LCD display with integrated touch keypad. Particularly indicated for active energy metering and for cost allocation in applications up to 100 A (direct connection), with dual tariff management availability. It can measure imported and exported energy or be programmed to consider only the imported one. Housing for DIN-rail mounting, with IP51 front degree protection. The analyzer is optionally provided with pulse output proportional to the active energy being measured, RS485 Modbus port or M-bus port.

Certified according to MID Directive, Module B and Module D of Annex II, for legal metrology relevant to active electrical energy meters (see Annex V, MI003, of MID). Can be used for fiscal (legal) metrology.

#### How to order EM112-DIN AVO 1 X O1 PF B

Model	
Range code	
System	
Power supply	
Output	
Option	
Measurement ——	

### **Type Selection**

Rang	Range code System		Pow	Power supply		Output	
AV0: AV1:	(Direct connection)	1:	1-phase 2-wire	X:	Self power supply -30% +20% of the rated measuring input voltage, 50Hz	O1: S1: M1:	pulse output RS485 Modbus port M-bus port
Optic	on			Mea	surement		
PF:	<b>PF:</b> Certified according to MID Directive. Can be used for fiscal (legal) metrology.		<b>A</b> :	The power is always in positive imported and n	egative	e exported power) and	
					the total energy meter i	s certif	ied according to MID.

#### CARLO GAVAZZI



# STANDARD

Not certified according to MID Directive. Cannot be used for fiscal (legal) metrology.

# How to order EM112-DIN AV0 1 X O1 X

L

Model — Range code — System — Power supply – Output —

**Option** 

# **Type Selection**

Rang	e code	Syst	em	Pow	er supply	Outp	out
AV0: AV1:	230VLN AC - 5(100)A (Direct connection) 120VLN AC - 5(100)A (Direct connection)	1:	1-phase 2-wire	<b>X</b> :	Self power supply -30% +20% of the rated measuring input voltage, 45 to 65Hz	O1: S1: M1:	pulse output RS485 Modbus port M-bus port

#### Option

X: none

# Input specifications

Rated Inputs		Memory energy storage	
Current type	1-phase loads, direct	Energy	10^10 cycles. Energy value
	connection		is saved every time the less
Current range	5(100)A		significant digit increases.
Nominal voltage	230VLN AC (AV0 option),	Programming parameters	10^10 cycles. When a
-	120 VLN (AV1 option)		parameter is modified, only
Accuracy			the relevant memory cell is
(@25°C ±5°C, R.H. ≤60%,			overwritten
45 to 65 Hz)		LEDs	Flashing red light pulses
AV1	Imin=0.25A; Ib: 5A, Imax:		according to EN50470-3,
,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	100A; Un: 120VLN -30%		EN62052-11, 1000 imp./
	+30%		kWh (min. period: 90ms,
A) (O			
AV0	Imin=0.25A; Ib: 5A, Imax:		max. frequency: 11 Hz)
	100A; Un: 230VLN -30%		Fix orange light: wrong
	+20%		current direction (only with
Energies			PFB option or with "B"
Active energy	Class 1 according to		measurement selection in
	EN62053-21		case of X option)
	Class B (kWh) according to	Current overloads	
	EN50470-3	Continuous	100A, @ 50Hz
Reactive energy	Class 2 according to	For 10ms	3000 A
35	EN62053-23	Voltage Overloads	3000 A
Start-up current:	40mA (AV0, AV1), positive	Continuous	1.2 Un
	or negative		
	Self-consumption is not	For 500ms	2 Un
	measured.	Input impedance	
Chart un valte ne		Voltage input 230VL-N	1.2Mohm
Start-up voltage	84VLN (AV1), 161VLN	Voltage input 120VL-N	1.2Mohm
	(AV0)	Current inputs: 5(100) A	< 1.25VA
Resolution	Display/serial		
	communication		
Current	0.1/0.001 A		
Voltage	0.1/0.1 V		
Power	0.01 kW or kVar/ 0.1 kW or		
	kvar		
Frequency	0.1 Hz/0.1Hz		
PF	0.01/ 0.001		
Energies (positive)	0.01 kWh or kvarh / 0.1		
	kWh or kvarh		
Energies (negative)	0.01 kWh or kvarh / 0.1		
Energies (negative)	kWh or kvarh		
Energy additional errors	KWII OI KVaIII		
Influence quantities	According to EN62053-21		
Temperature drift	≤200ppm/°C		
Sampling rate	4096 samples/s @ 50Hz		
	4096 samples/s @ 60Hz		
Display and touch key-pad			
Туре	Backlit LCD, 3 rows by		
	8-digit each, h 5 mm		
Read-out	Energy: 8 digit. Variables: 4		
	digit		
Touch key	2 (Enter/DOWN and UP).		
Max. and Min. indication	· · · · · · · · · · · · · · · · · · ·		
Energies	Max. 99 999 999		
	Min. 0.01		
Variables	Max. 9999		
Valiabioo	Min. 0.01		

### **Digital input specifications**

#### **Digital inputs**

Function

Number of inputs Contact measurement voltage Input impedance Contact resistance

Free of voltage contact Tariff management (switch between 7-8) 1 5 ∨ ≤ 1kohm ≥ 1kohm, close contact 100kohm, open contact Overload

In case a voltage is erroneously applied to the digital input, the input is not damaged up to 30 V ac/dc.

### **Output specifications**

RS485 serial port	RS485 by screw	Other	Available functions: wild
	connection.		card, header, initialisation
Function	For communication		SND_NKE, and req_udr
	of measured data,		management. Management
	programming parameters		of primary address
Protocol	Modbus RTU (slave		modification via M-bus.
	function)		VIF, VIFE, DIF and DIFE:
Baud rate	9.6, 19.2, 38.4, 57.6, 115.2		see protocol
	kbaud, even or no parity,	Static output	
Address	1 to 247 (default: 1)	Purpose	For pulse output
Driver input capability	1/8 unit load. Maximum 247		proportional to the active
,	transceivers on the same		energy (kWh)
	bus.	Pulse rate	Selectable in multiple of
Data refresh time	1s		100
Read command	50 words available in 1		Max 500 or 2000
	read command		pulses/kWh according to
Rx/Tx indication	Rx segment on display		pulse ON duration
i bi i k indication	is shown when a valid	Pulse ON duration	Selectable: 30ms or
	Modbus command is sent		100 ms according to
	to that specific meter;		EN62052-31
	Tx segment on display	Output type	open collector PNP
	is shown when a valid	Load	$V_{ON}$ 1 V dc max. 100mA
	Modbus reply is sent back	Loud	$V_{OFF}$ 80 V dc max.
	to the master		V <sub>OFF</sub> 00 V do max.
M-bus port	M-bus by screw		
	connection.		
Function	For communication of		
Function	measured data		
Drotocol			
Protocol	M-bus according to EN13757-3		
Baud rate	0.3, 2.4, 9.6 kbaud		
Meters in the M-bus network	0.3, 2.4, 9.6 Kbaud 250		
	Selectable		
Primary address			
Secondary address	Univocally defined in each unit		
Secondary address range	from 7000 0000 to		
-	7999 9999		

### **General specifications**

Operating temperature	-25 to +65 °C, indoor,	Housing	
	(R.H. from 0 to 90% non-	Dimensions (WxHxD)	35 x 63 x 90 mm
	condensing @ 40°C)	Material	PTB, self-extinguishing: UL
Storage temperature	-30°C to +80°C (R.H. <	<b>o</b>	94 V-0
	90% non-condensing @	Sealing covers	Included
	40°C)	Mounting	DIN-rail
Overvoltage category	Cat. III	Protection degree	
Insulation (for 1 minute)	4000 VAC RMS between	Front	IP51
	measuring inputs and	Screw terminals (cable inputs)	IP20
	digital/serial output (see table) 4000 VAC RMS	Weight	Approx. 160 g (packing included)
Dielectric strength	4000 VAC RMS for 1 minute		·
EMC	According to EN62052-11		
Standard compliance			
Safety	EN62052-11		
Metrology	EN62053-21, EN50470-3		
Approvals	CE, MID (PF option only), UL (AV1 model only)		
Connections			
Cable cross-section area	Measuring inputs: max. 25 mm <sup>2</sup> , min. 5 mm <sup>2</sup> with/ without metallic cable ferrule; Max. screw tightening torque: 2.8 Nm		
Other terminals	1.5 mm², Min./Max. screws tightening torque: 0.5 Nm		

# Power supply specifications


Self power supply		Power consumption	≤ 1W, ≤ 8VA
AV0	230VAC VL-N, -30% +20%		
	45-65Hz		
AV1	120VAC VL-N, -30% +30%		
	45-65Hz		

### Insulation (for 1 minute) between inputs and outputs


	Measuring input	Digital or serial output	Digital input
Measuring input	-	4 kV	4 kV
Digital or serial output	4 kV	-	0 kV
Digital input	4 kV	0 kV	-



# Accuracy (according to EN50470-3 and EN62053-23)



**kWh**, accuracy (RDG) depending on the current



### MID compliance (PF option only)

Accuracy	$0.9 \text{ Un} \le U \le 1.1 \text{ Un}; 0.98 \text{ fn} \le f \le 1.02 \text{ fn}; \text{ fn}: 50 \text{ Hz};$ $\cos\varphi: 0.5$ inductive to 0.8 capacitive. Class B Considering listed Ib or In values
Operating temperature	-25 to +55°C (-13°F to 131°F) (R.H. from 0 to 90% non-condensing @ 40°C)
EMC compliance	E2
Mechanical compliance	M2

### **Display pages**

No	1 <sup>st</sup> row	2 <sup>nd</sup> row	3 <sup>rd</sup> row	"Full" mode	"Easy" mode	Note
0	kWh+ (imported)		kW	X	Х	In PF version (MID) this is the only certified energy meter. In PFA version and in X version with Measurement menu set to "A", this is considering the total energy without considering the current direction.
1	kWh- (exported)		kW	Х	Х	In PFB version and in X version with Measurement menu set to "B"
2	kWh+ (imported)		V	X	Х	
3	kWh+ (imported)		A	Х	Х	
4	kWh+ (imported)		PF	Х		
5	kWh+ (imported)		Hz	Х		
6	kvarh+ (imported)		kvar	X		In PFA version and in X version with Measurement menu set to "A", this is considering the total positive reactive energy without considering the current direction.
7	kvarh- (exported)		kvar	Х		In PFB version and in X version with Measurement menu set to "B"
8	kWh+ (imported)	kWdmd peak	kWdmd	X		
9	kWh (t1)	"t1"	kW	Х		Only relevant to kWh+, with Tariff menu set to ON.
10	kWh (t2)	"t2"	kW	X		Only relevant to kWh+, with Tariff menu set to ON.

# List of available menus

Menu name and desc	ription	Range	Default setting
PASS	Password request	From 0000 to 9999	0000
nPASS	New password	From 0000 to 9999	0000
Measure	Measurement type (A=easy connection; B=bidirectional, imported and exported energy). Not available in PFA and PFB versions (MID)	A; b	A
P int	Integration time for Wdmd calculation	1 to 30 min	1
Mode	Selection of complete or simplified set of variables on display	Full or Easy	Full
Tariff	Tariff enabling	Yes/No	No
Home	Home page selection (default page at power-on and after 120 s time-out from other pages). Not available in PFA and PFB versions (MID).	0 to 9	0
PULSE (O1 option)	Selection of pulse ON duration	30 or 100 ms	30
	Selection of the pulse weight (multiples of 100 pulses/kWh)	100 to 500 (if duration is 100ms) 100 to 2000 (if 30 ms)	100
Address (S1 option)	Modbus serial address	1 to 247	01
Kbaud (S1)  Modbus baud rate		9.6; 19.2; 38.4; 57.6, 115.2 kbps	9.6
ParltY (S1)	Modbus parity	No/even	No
Prl Add (M1 option)	M-bus primary address	1 to 250	0
Kbaud (M1)	M-bus baud rate	0.3; 2.4; 9.6 kbps	2.4
RESET Allow the reset of tariff meters and W dmd peak (kWh/kvarh meter reset available only via serial communication)		Yes/No	No
End	Exit to measuring mode		


Note: after the confirmation of a new parameter value, the value is stored in the memory without the need to exit the programming mode.


# Additional available information on the display (\*)


Page	Code	Description
YEAr	InFO 1	Year of manufacture
SErIAL n	InFO 2	Serial number, corresponds to the one indicated on the front print
rEVISIon	InFO 3	Firmware revision – XY.nn:
PuLS Led	InFO 4	Front LED pulse weight
MEASurE	P3	Measurement type (only X option)
P int	P4	Requested average power calculation interval
ModE	P5	Display mode
tArIFF	P6	Enabling tariff management and any current tariff
НоМЕ	P7	Measurement page set as home page (only X option)
Pages specific to the	S1 version	
AddrESS	P10	Modbus address
bAUd	P11	Baud rate
PArITY	P12	Parity
StoP bit	P12–2	Stop bit
Pages specific to the	O1 version	
PULSE	P8	Duration
PuL rAtE	P8-2	Pulse weight
Pages specific to the	M1 version	
Pr I Add	P9	M-Bus primary address
bAUd	P11	Baud rate
SEC Add	InFO 5	M-Bus secondary address, univocal and set during production


(\*) can be reached by pressing simultaneously the 2 touch keys


### Wiring diagrams














### Front panel description



- Display Backlit LCD display with touch key-pad. Right key: enter, down Left key: up
- 2. LED LED proportional to kWh reading
- 3. Serial number and MID data Area reserved to serial number and MID-relevant data in PF versions

### **Dimensions (mm)**

