



<b>Phytion™</b>		Device Programmers and Development Tools for Microcontrollers				
Home	Products	E-Shop	Support	Contact	News	Site Map
<p>Quick Links</p> <ul style="list-style-type: none"> <li>Help Desk</li> <li>Downloads</li> <li>All Programmers</li> <li>Device Search</li> <li>Tools Catalogs</li> </ul> <p>Shopping Cart</p> <p>Items: 0</p> <p>Total: \$0.00</p> <p>Your Account</p>		<h2>Phytion PICE Emulators</h2> <h3>Trace cables for PICE emulators</h3> <div style="display: flex; justify-content: space-around;">   </div> <p>Intends to trace external signals from the target and to output synchronization impulses</p> <p>The PICE trace cable allows to enter up to 8 external signals, status of which can be recorded to the real time <a href="#">trace buffer</a></p> <p>Status of each traced signal can be used as a condition for breaking the emulation of generation of the trigger impulse</p> <p>Trigger outputs can be used for synchronization of logic analyzers, oscilloscopes and other lab equipment</p> <p>Trace cables are slightly different for the newer PICE-52, -MC, -XE, -SE and older PICE-51 and PICE-196 emulators</p> <p>Cables are about 10" (25 cm) long and has 14 micro grabbers for hooking control points on the target</p> <p>Two green micro grabbers are intended to connect the Ground, 8 black - for entering and 2-4 red - for outputting the signals</p> <p style="text-align: right;"><a href="#">Go Back</a></p>				
<p>Products</p> <ul style="list-style-type: none"> <li>Development Tools</li> <li>ARM</li> <li>8051</li> <li>Other</li> <li>Device programmers</li> <li>All Models</li> <li>Universal</li> <li>In-System</li> <li>Gang</li> <li>Adapters</li> <li>Custom made tools</li> <li>OEM tools</li> </ul>		<p>Copyright © 2007-2010 Phytion, Inc. Phone: 718-259-3191 • E-mails: <a href="mailto:info@phyton.com">info@phyton.com</a>, <a href="mailto:sales@phyton.com">sales@phyton.com</a>, <a href="mailto:support@phyton.com">support@phyton.com</a></p>				