




**NeoPress  
Plug and Receptacle  
Removal Tool**

**Application Tooling  
Specification Sheet**



**Order No. 62203-1320**

**FEATURES**

- Universal tool used for removal of NeoPress plug and receptacle assemblies
- Removes connector without damaging the PCB
- For plug insertion, use 62203-1300 (6x14) or 62203-1330 (6x10) tools
- For receptacle insertion, use 62203-1310 (6x14) or 62203-1340 (6x10) tools

**SCOPE**

Products: NeoPress 100 Ohm Plug and Receptacle Assemblies. See Product List below for specific part numbers.

**Product List**

The following is a partial list of the product order numbers and their specifications this tool is designed to run. Updates to this list are available on [www.molex.com](http://www.molex.com).


Size	Series No.	Assembly Order No.	
6 x 10	172801	172801-0005	172801-0006
		172801-0007	
	172832	172832-0005	172832-0006
		172832-0007	
6 x 14	172801	172801-0001	172801-0009
	172832	172832-0001	
6 x 16	172801	172801-0008	172801-0013
	172832	172832-0013	

**DESCRIPTION**

The 62203-1320 NeoPress Removal Tool is a pliers-type tool for removing a press-fit plug or receptacle signal module from the printed circuit board. The tool is approximately 200mm (8 in) long by 45mm (1.8 in) wide (closed) by 38mm (1.5 in) thick and weighs 0.7 kg (1.5 lb.).


**OPERATING SPACE (Keep Out Zone)**

A certain amount of space is required on the printed circuit board for the removal tool to fit over the signal module. Make sure there are no other components in this space. See Figure 1.



## TOOL OPERATION

1. Open the removal tool so jaws fit over the module to be removed. The front and back jaws should fit over the module as shown in Figure 2.
2. Slowly squeeze the removal tool closed, making sure the jaws securely grip the housing. See Figure 3.



3. Use a perpendicular upward motion to remove the module. Do not excessively “rock” the module back and forth because this may damage the PCB.
4. It may be necessary to reposition the tool along the module to gradually remove it from the PCB.

## Maintenance

It is recommended that each operator of the tool be made aware of and responsible for the following maintenance steps:

1. Remove dust, moisture and other contaminants with a clean brush or a soft, lint-free cloth.
2. Do not use any abrasive materials that could damage the tool.
3. Make certain all pins, pivot points and bearing surfaces are protected with a thin coat of high-quality machine oil. Do not oil excessively.
4. When the tool is not in use, store it in a clean, dry area.
5. There are no repair parts available for this tool. Should the tool be damaged, a new tool is required.

**CAUTION:** Molex application tooling specifications are valid only when used with Molex connectors and tooling.

### Application Tooling Support

**Phone:** (402) 458-TOOL (8665)

**E-Mail:** [applicationtooling@molex.com](mailto:applicationtooling@molex.com)

**Website:** [www.molex.com/applicationtooling](http://www.molex.com/applicationtooling)

Molex is a registered trademark of Molex, LLC in the United States of America and may be registered in other countries; all other trademarks listed herein belong to their respective owners.