## **Level Sensors Electromechanical Float Switches** Types FS, Horizontal and Vertical Mount



## **Product Description**

are economical electromechanical float switches for terials, allow the FS sensors liquid level sensing. Selectable normally open or normally closed outputs, along

The FS series of sensors with various mounting configurations and housing mato fit a wide variety of level applications.

•	Float	switches	for	liquid	level	sensing
---	-------	----------	-----	--------	-------	---------

- Horizontal or vertical mount
- Polypropylene, or polysulfone housings
- Maximum switching voltage: 200 VDC or 240 VAC
- Maximum switching current: 0.5 A (SPST)
- Suitable for specific gravities > 0.75

## **Ordering Key**

## FS H -2 1

	_	
Туре		
Mounting attitude –		
Mounting type		
Housing material –		

#### **Type Selection**

Housing Material	Horizontal mount, Ø16 mm compression	Horizontal mount, 1/2" NPT thread	Vertical mount, 1/8" PF thread
Polypropylene		FSH-31	FSV-31
Polysulfone	FSH-25	FSH-35	FSV-35

## **Specifications**


Rated maximum switching voltage	200 VDC, 240 VAC
Rated maximum current Switching	0.5 A
Carrying Rated maximum switching capacity	1.0 A 50W (VA)
Switch type, function	Reed, SPST
Rated operating temperature FS 1 types FS 5 types	-4 to +176°F -4 to +250°F
<b>Rated operating pressure</b> FS 1 types FS 5 types	57 psi 28 psi

Connection	2 wires, XLPE 22 AWG x 12 in.
Suitable specific gravity FS1 types FS5 types	>0.75 >0.85
Housing material color FSH 1 types FSV 31 type FS 5 types	Polypropylene, black Polypropylene, white Polysulfone, transparent
MTBF	1,000,000 Cycles
Approvals	CE
Weight FSH 1 types FSH 5 types FSV types	35 g 40 g 18 g

# FH, Horizontal and Vertical Mount



#### **Dimensions**



### **Installation Guide**

- **FSH...types** Normally open or normally closed operation is selectable by orientation of the sensor in the tank. Normally open switching is obtained when the arrow on the mounting is pointed up, and vice versa, normally closed when the arrow is downward.
- **FSV...types** Normally open or normally closed operation is selectable by inversion of the float on the shaft. The switches are shipped normally open otherwise indicated.

