



SPECIFICATIONS

| Model | Stroke mm | Max Energy Absorption J(kgf·m) | Max Equiv. Mass kg(kgf) | Range of Impact Rate m/s | Orifice Type |
|----------------|--------------|--------------------------------------|-------------------------------|--------------------------------|--------------------------------------|
| FWM-S2725FBD-C | 25 | 79.3(8.1) | 450(450) | 0.3~2 | Multiple- varying orifice type |

COMMON SPECIFICATIONS

| Max Drag N(kgf) | Max Cycle Rate cycle/min | Max Energy Absorption per min. J/min(kgf·m/min) | Extension Force N(kgf) | Operating Temp. C° | Mass g |
|-----------------------|--------------------------------|---|------------------------------|-----------------------|-----------|
| 6370(650) | 60 | 539(55) | 27.3(2.78) or lower | -5~70 | 460 |

PRECAUTIONS FOR USE

- Do not use this product in places where it may come in contact with oil as it does not have a liquid-proof structure.
- Please contact our sales department when the use of optional parts is planned.
- Although the dimensions are identical to those of the FA series standard products (adjustable), the FWM-S2016 series has a longer overall length.

ADJUSTMENT METHOD

- Please peruse the operation manual carefully before use.
- Do not operate without sufficient mounting strength.
- Do not operate without an external stopper.
- Note that Products specification might be changed without notice.


ABSORPTION CHARACTERISTICS


| Orifice type | Multiple-orifice type | Absorption characteristics | | |
|--------------|---|----------------------------|--|--|
| Model number | FWM-S2725FBD Series | Resistance | | |
| Application | For medium speed, in particular with a pneumatic cylinder | Stroke | | |

OPTIONAL PARTS

Eccentric angle adaptor OP-010FB

- Screw the eccentric angle adaptor into the main unit until the cap for the eccentric angle and the piston rod form a tight connection. While maintaining this position, fasten the main unit's nut until it is secured.
- Use the eccentric angle adaptor when the eccentric angle is 2.5° or larger.
- The main unit can also be used as a stopper.
- Use it with a capless soft absorber.
- The maximum operating eccentric angle with an eccentric angle adaptor is ±10°.
- The caps and the guides for inclined use are not unbundled.







Note: Material of cap for eccentric angle: Metal

Stopper nut OP-020FB

Adjust so that it stops 1 mm before the stroke end, and fasten with the main unit's nut until secured.



Mass 90g



Mass 137g


Note: When attaching, make sure that the side without a bearing chamfer is the impact surface.

Standard nuts are sold separately as well - M27 Nut

Square flange OP-040FB Holder with a switch OP-030FB


 Once the attachment site is determined, use the main unit's nut to securely fasten in place.

 $M27_{mm} \times 1.5_{mm}$



Liquid-proof cap FWM-2725FBD-C-060

- A drip proof cap is fitted on the unit on delivery.
- Liquid-proof caps are not sold separately.
- Ensure that the cap is facing upward. If the cap is facing sideways or downward, it cannot provide an effective means for liquid proofing.



Although a holder with a switch can be ordered on its own, we strongly recommend ordering one with the main unit. Please include the main unit's model number when placing an order.

