## **SIEMENS**

Data sheet 3UG4614-2BR20



Digital monitoring relay Asymmetry 0-20% Phase sequence can be activated Phase failure 3 x 160 to 690 V 50 to 60 Hz AC Undervoltage 160-690 V Hysteresis 1-20 V ON and OFF delay 0-20 s 2 change-over contacts spring-type connection system

product brand name	SIRIUS			
product designation	Network monitoring relay with digital setting			
design of the product	4 functions			
product type designation	3UG4			
General technical data				
product function	Phase monitoring relay			
display version LED	No			
design of the display	LCD			
insulation voltage for overvoltage category III according to IEC 60664				
<ul> <li>with degree of pollution 3 rated value</li> </ul>	690 V			
degree of pollution	3			
type of voltage				
<ul><li>for monitoring</li></ul>	AC			
of the control supply voltage	AC			
surge voltage resistance rated value	6 kV			
protection class IP	IP20			
shock resistance according to IEC 60068-2-27	sinusoidal half-wave 15g / 11 ms			
vibration resistance according to IEC 60068-2-6	1 6 Hz: 15 mm, 6 500 Hz: 2g			
mechanical service life (switching cycles) typical	10 000 000			
electrical endurance (switching cycles) at AC-15 at 230 V typical	100 000			
thermal current of the switching element with contacts maximum	5 A			
reference code according to IEC 81346-2	K			
relative repeat accuracy	1 %			
Substance Prohibitance (Date)	05/01/2012			
Product Function				
product function				
<ul> <li>undervoltage detection</li> </ul>	Yes			
<ul> <li>overvoltage detection</li> </ul>	No			
<ul> <li>phase sequence recognition</li> </ul>	Yes			
<ul> <li>phase failure detection</li> </ul>	Yes			
<ul> <li>asymmetry detection</li> </ul>	Yes			
<ul> <li>overvoltage detection 3 phase</li> </ul>	No			
<ul> <li>undervoltage detection 3 phases</li> </ul>	Yes			
<ul> <li>voltage window recognition 3 phase</li> </ul>	No			
<ul> <li>adjustable open/closed-circuit current principle</li> </ul>	Yes			
• auto-RESET	Yes			
Control circuit/ Control				

control supply voltage at AC	
• at 50 Hz rated value	160 690 V
at 60 Hz rated value	160 690 V
operating range factor control supply voltage rated value at AC at 50 Hz	
• initial value	1
full-scale value	1
operating range factor control supply voltage rated value at AC at 60 Hz	
<ul><li>initial value</li></ul>	1
full-scale value	1
Measuring circuit	
measurable voltage at AC	690 160 V
adjustable response delay time	
<ul><li>when starting</li></ul>	0.1 20 s
with lower or upper limit violation	0.1 20 s
accuracy of digital display	+/-1 digit
Precision	
relative metering precision	5 %
Auxiliary circuit	
number of NC contacts delayed switching	0
number of NO contacts delayed switching	0
number of CO contacts delayed switching	2
operating frequency with 3RT2 contactor maximum	5 000 1/h
Main circuit	
number of poles for main current circuit	3
ampacity of the output relay at AC-15	
• at 250 V at 50/60 Hz	3 A
• at 400 V at 50/60 Hz	3 A
ampacity of the output relay at DC-13	
• at 24 V	1 A
• at 125 V	0.2 A
• at 250 V	0.1 A
operational current at 17 V minimum  continuous current of the DIAZED fuse link of the	5 mA 4 A
output relay	4 A
Electromagnetic compatibility	
conducted interference	
<ul> <li>due to burst according to IEC 61000-4-4</li> </ul>	2 kV
<ul> <li>due to conductor-earth surge according to IEC 61000-4-5</li> </ul>	2 kV
<ul> <li>due to conductor-conductor surge according to IEC 61000-4-5</li> </ul>	1 kV
field-based interference according to IEC 61000-4-3	10 V/m
electrostatic discharge according to IEC 61000-4-2	6 kV contact discharge / 8 kV air discharge
Galvanic isolation	
galvanic isolation	
<ul> <li>between input and output</li> </ul>	Yes
<ul> <li>between the outputs</li> </ul>	Yes
between the voltage supply and other circuits	Yes
Connections/ Terminals	
product component removable terminal for auxiliary and control circuit	Yes
type of electrical connection	spring-loaded terminals
type of connectable conductor cross-sections	
• solid	2x (0.25 1.5 mm²)
<ul> <li>finely stranded with core end processing</li> </ul>	2 x (0.25 1.5 mm²)
<ul> <li>finely stranded without core end processing</li> </ul>	2x (0.25 1.5 mm²)
<ul> <li>at AWG cables solid</li> </ul>	2x (24 16)
at AWG cables stranded	2x (24 16)
connectable conductor cross-section	

mounting position fastening method height width 22.5 mm depth 91 mm required spacing • with side-by-side mounting — forwards — backwards — upwards — downwards — at the side • for grounded parts — forwards — backwards — o mm • for grounded parts — forwards — backwards — o mm • for grounded parts — forwards — backwards — upwards — o mm • for live parts — forwards — backwards — o mm • for live parts — forwards — backwards — o mm • for live parts — forwards — backwards — o mm  • for live parts — forwards — o mm  Ambient conditions  installation altitude at height above sea level maximum  2 000 m	mm²
AWG number as coded connectable conductor cross section  • solid • stranded  Installation/ mounting/ dimensions  mounting position fastening method height  width  depth  required spacing  • with side-by-side mounting — forwards — backwards — upwards — at the side  • for grounded parts — forwards — backwards — upwards — o mm  • for grounded parts — forwards — o mm  • for grounded parts — forwards — backwards — upwards — o mm  • for grounded parts — forwards — backwards — upwards — o mm  • o mm  • o mm  • o mm  — at the side — downwards — o mm — downwards — o mm — at the side — downwards — o mm — downwards — backwards — upwards — o mm — downwards — o mm — o mm — downwards — o mm —	
e solid e stranded 24 16 e stranded 24 16 Installation/ mounting/ dimensions    mounting position	ounting
stranded  Installation/ mounting/ dimensions  mounting position fastening method height width geth geth required spacing     with side-by-side mounting     — forwards     — backwards     — upwards     — downwards     — at the side     — downwards     — backwards     — at the side     — downwards     — backwards     — backwards     — at the side     — downwards     — at the side	ounting
mounting position fastening method height width depth required spacing  • with side-by-side mounting — forwards — backwards — upwards — at the side — for grounded parts — forwards — backwards — o mm  • for grounded parts — forwards — backwards — o mm  • for grounded parts — forwards — backwards — upwards — o mm  • for grounded parts — forwards — backwards — upwards — backwards — upwards — at the side — downwards — o mm  • for live parts — forwards — backwards — upwards — o mm — at the side — downwards — o mm — backwards — upwards — at the side — downwards — o mm — at the side — downwards — o mm — at the side	ounting
mounting position fastening method height width 22.5 mm depth 91 mm required spacing • with side-by-side mounting — forwards — backwards — upwards — downwards — at the side • for grounded parts — forwards — backwards — backwards — o mm • for grounded parts — forwards — backwards — o mm • for grounded parts — forwards — backwards — o mm • for live parts — forwards — backwards — o mm • for live parts — forwards — backwards — o mm • for live parts — forwards — backwards — o mm  • for live parts — forwards — o mm  Ambient conditions installation altitude at height above sea level maximum  2 000 m	ounting
fastening method  height  width  depth  e with side-by-side mounting  — forwards — backwards — upwards — downwards — at the side — backwards — backwards — o mm  • for grounded parts — forwards — upwards — o mm  • for grounded parts — forwards — o mm  — at the side — o mm  — o mm  — at the side — o mm  — o mm  — backwards — upwards — o mm  —	ounting
height       94 mm         width       22.5 mm         depth       91 mm         required spacing       0 mm         • with side-by-side mounting       0 mm         — forwards       0 mm         — backwards       0 mm         — at the side       0 mm         • for grounded parts       0 mm         — backwards       0 mm         — at the side       0 mm         — downwards       0 mm         • for live parts       0 mm         — backwards       0 mm         — backwards       0 mm         — backwards       0 mm         — downwards       0 mm         — at the side       0 mm         Ambient conditions       2 000 m	ounting
width 22.5 mm  depth 91 mm  required spacing  • with side-by-side mounting  — forwards — backwards — upwards — downwards — at the side  • for grounded parts — forwards — backwards — upwards — o mm  • for grounded parts — forwards — at the side — downwards — at the side — downwards — at the side — downwards  • for live parts — forwards — backwards — downwards — o mm  • for live parts — forwards — backwards — o mm — o	
depth       91 mm         required spacing         • with side-by-side mounting       0 mm         — forwards       0 mm         — backwards       0 mm         — at the side       0 mm         • for grounded parts       0 mm         — forwards       0 mm         — backwards       0 mm         — at the side       0 mm         — for live parts       0 mm         — backwards       0 mm         — backwards       0 mm         — backwards       0 mm         — at the side       0 mm         Ambient conditions       0 mm         installation altitude at height above sea level maximum       2 000 m	
required spacing  • with side-by-side mounting  — forwards — backwards — upwards — at the side  • for grounded parts — forwards — backwards — upwards — upwards — o mm  • for grounded parts — forwards — backwards — upwards — at the side — downwards — o mm  • for live parts — forwards — backwards — o mm  • for live parts — forwards — o mm  • for wards — o mm  • for live parts — forwards — o mm  — backwards — o mm  — downwards — o mm  — at the side — o mm  Ambient conditions  installation altitude at height above sea level maximum  2 000 m	
<ul> <li>with side-by-side mounting</li> <li>forwards</li> <li>backwards</li> <li>upwards</li> <li>downwards</li> <li>at the side</li> <li>for grounded parts</li> <li>for grounded parts</li> <li>backwards</li> <li>upwards</li> <li>upwards</li> <li>at the side</li> <li>mm</li> <li>downwards</li> <li>mm</li> <li>for live parts</li> <li>for live parts</li> <li>for live parts</li> <li>mount of mm</li> <li>backwards</li> <li>mm</li> <li>downwards</li> <li>mm</li> <li>downwards</li> <li>mm</li> <li>man</li> <li>mm</li> <li>mm</li> <li>mm</li> <li>mm</li> <li>mm</li> <li>Ambient conditions</li> <li>installation altitude at height above sea level maximum</li> <li>2 000 mm</li> </ul>	
<ul> <li>— forwards</li> <li>— backwards</li> <li>— upwards</li> <li>— downwards</li> <li>— at the side</li> <li>● for grounded parts</li> <li>— forwards</li> <li>— backwards</li> <li>— upwards</li> <li>— at the side</li> <li>— at the side</li> <li>— downwards</li> <li>● for live parts</li> <li>— forwards</li> <li>— to mm</li> <li>● for live parts</li> <li>— forwards</li> <li>— backwards</li> <li>— mm</li> <li>— backwards</li> <li>— upwards</li> <li>— o mm</li> <li>— backwards</li> <li>— upwards</li> <li>— upwards</li> <li>— at the side</li> <li>O mm</li> <li>— downwards</li> <li>— at the side</li> <li>O mm</li> </ul> Ambient conditions installation altitude at height above sea level maximum 2 000 m	
backwards 0 mm upwards 0 mm downwards 0 mm at the side 0 mm  for grounded parts forwards 0 mm backwards 0 mm upwards 0 mm at the side 0 mm at the side 0 mm downwards 0 mm for live parts forwards 0 mm backwards 0 mm at the side 0 mm downwards 0 mm at the side 0 mm  Ambient conditions installation altitude at height above sea level maximum 2 000 m	
— upwards 0 mm — downwards 0 mm — at the side 0 mm  • for grounded parts — forwards 0 mm — backwards 0 mm — upwards 0 mm — at the side 0 mm — downwards 0 mm • for live parts — forwards 0 mm — backwards 0 mm — at the side 0 mm — wards 0 mm — downwards 0 mm — at the side 0 mm  Ambient conditions  installation altitude at height above sea level maximum 2 000 m	
- downwards 0 mm - at the side 0 mm  • for grounded parts - forwards 0 mm - backwards 0 mm - upwards 0 mm - at the side 0 mm - downwards 0 mm • for live parts - forwards 0 mm - backwards 0 mm - at the side 0 mm - downwards 0 mm - downwards 0 mm - downwards 0 mm - at the side 0 mm  Ambient conditions  installation altitude at height above sea level maximum 2 000 m	
<ul> <li>— at the side</li> <li>● for grounded parts</li> <li>— forwards</li> <li>— backwards</li> <li>— upwards</li> <li>— at the side</li> <li>— downwards</li> <li>● for live parts</li> <li>— forwards</li> <li>— backwards</li> <li>— backwards</li> <li>— upwards</li> <li>— upwards</li> <li>— o mm</li> <li>— backwards</li> <li>— upwards</li> <li>— upwards</li> <li>— at the side</li> <li>O mm</li> <li>Ambient conditions</li> <li>installation altitude at height above sea level maximum</li> <li>2 000 m</li> </ul>	
for grounded parts         — forwards         — backwards         — upwards         — at the side         — downwards         — for live parts         — forwards         — backwards         — backwards         — upwards         — backwards         — upwards         — upwards         — at the side         — downwards         — at the side  Ambient conditions  installation altitude at height above sea level maximum  2 000 m	
<ul> <li>— forwards</li> <li>— backwards</li> <li>— upwards</li> <li>— at the side</li> <li>— downwards</li> <li>● for live parts</li> <li>— forwards</li> <li>— backwards</li> <li>— backwards</li> <li>— upwards</li> <li>— downwards</li> <li>— o mm</li> <li>— backwards</li> <li>— upwards</li> <li>— at the side</li> <li>O mm</li> <li>Ambient conditions</li> <li>installation altitude at height above sea level maximum</li> <li>2 000 m</li> </ul>	
<ul> <li>— backwards</li> <li>— upwards</li> <li>— at the side</li> <li>— downwards</li> <li>● for live parts</li> <li>— forwards</li> <li>— backwards</li> <li>— backwards</li> <li>— upwards</li> <li>— downwards</li> <li>— at the side</li> <li>O mm</li> <li>Ambient conditions</li> <li>installation altitude at height above sea level maximum</li> <li>O mm</li> <li>2 000 m</li> </ul>	
<ul> <li>— upwards</li> <li>— at the side</li> <li>— downwards</li> <li>● for live parts</li> <li>— forwards</li> <li>— backwards</li> <li>— backwards</li> <li>— upwards</li> <li>— downwards</li> <li>— at the side</li> <li>O mm</li> <li>Ambient conditions</li> <li>installation altitude at height above sea level maximum</li> <li>0 mm</li> <li>2 000 m</li> </ul>	
<ul> <li>— at the side</li> <li>— downwards</li> <li>● for live parts</li> <li>— forwards</li> <li>— backwards</li> <li>— upwards</li> <li>— downwards</li> <li>— at the side</li> <li>O mm</li> <li>Ambient conditions</li> <li>installation altitude at height above sea level maximum</li> <li>0 mm</li> <li>2 000 m</li> </ul>	
<ul> <li>— downwards</li> <li>● for live parts</li> <li>— forwards</li> <li>— backwards</li> <li>— upwards</li> <li>— downwards</li> <li>— at the side</li> <li>O mm</li> <li>Ambient conditions</li> <li>installation altitude at height above sea level maximum</li> <li>0 mm</li> <li>2 000 m</li> </ul>	
● for live parts  — forwards  — backwards  — upwards  — downwards  — at the side  Ambient conditions  installation altitude at height above sea level maximum  0 mm  2 000 m	
— forwards         0 mm           — backwards         0 mm           — upwards         0 mm           — downwards         0 mm           — at the side         0 mm           Ambient conditions           installation altitude at height above sea level maximum         2 000 m	
<ul> <li>backwards</li> <li>upwards</li> <li>downwards</li> <li>at the side</li> <li>0 mm</li> <li>0 mm</li> <li>0 mm</li> </ul> Ambient conditions installation altitude at height above sea level maximum 2 000 m	
<ul> <li>upwards</li> <li>downwards</li> <li>at the side</li> <li>0 mm</li> <li>0 mm</li> </ul> Ambient conditions installation altitude at height above sea level maximum <ul> <li>2 000 m</li> </ul>	
- downwards 0 mm - at the side 0 mm  Ambient conditions installation altitude at height above sea level maximum 2 000 m	
— at the side 0 mm  Ambient conditions  installation altitude at height above sea level maximum 2 000 m	
Ambient conditions installation altitude at height above sea level maximum 2 000 m	
installation altitude at height above sea level maximum 2 000 m	
ambient temperature	
• during operation -25 +6	
• during storage -40 +8	°C
• during transport -40 +8	
Certificates/ approvals	°C
General Product Approval	°C











Test Certificates	Marine / Shipping	other	Railway
-------------------	-------------------	-------	---------

Type Test Certificates/Test Report

**Special Test Certific-**<u>ate</u>





Confirmation

Vibration and Shock

Information- and Downloadcenter (Catalogs, Brochures,...)

https://www.siemens.com/ic10

Industry Mall (Online ordering system)

https://mall.industry.siemens.com/mall/en/en/Catalog/product?mlfb=3UG4614-2BR20

## Cax online generator

http://support.automation.siemens.com/WW/CAXorder/default.aspx?lang=en&mlfb=3UG4614-2BR20

Service&Support (Manuals, Certificates, Characteristics, FAQs,...) https://support.industry.siemens.com/cs/ww/en/ps/3UG4614-2BR20

Image database (product images, 2D dimension drawings, 3D models, device circuit diagrams, EPLAN macros, ...) <a href="http://www.automation.siemens.com/bilddb/cax">http://www.automation.siemens.com/bilddb/cax</a> de.aspx?mlfb=3UG4614-2BR20&lang=en

**Characteristic: Derating** 

https://support.industry.siemens.com/cs/ww/en/ps/3UG4614-2BR20/manual

last modified: 12/21/2020 🖸