



Introduction

The AJ3 Joystick provides the reliability required in demanding environmental conditions such as heavy duty industrial applications. The high mechanical strength of the shaft and the unique sensing design make the joystick ideal for rigorous use in rugged, harsh environments.

The AJ3 Joystick is designed to accommodate standard and custom designed multifunction grips. The AJ3 Joystick is available separately or combined with various mulitfunction grips.



Main Features

- Contactless sensing Hall effect
- Life greater than 5 million cycles
- 2 sensors per axis
- Integrated temperature compensation
- Standard or customized multifunction grips

Custom Modifications

- Output characteristics
- Operating force
- · Lever deflection angle
- Gate pattern
- Over travel function
- Multifunction grips



Electrical Variant

Supply Ratings - System Voltage - Voltage Range - Maximum Current - Max. Output Voltage		12V or 24V dc 8V 16V or 8V 30V 180 mA at 24V dc Vsupply – 2.5V dc
Voltage Output (maximum output current 5 mA) PWM Output	V01 V02 V08 V09 PW2	0V (Vsupply - 2.5V dc) 0 5V dc 0.5 4.5V dc 25% Vsupply 75% Vsupply 500 Hz ± 80 Hz
CAN Bus Output	CA1 CA2 J19	CAN 2.0A (11 bit identifier) CAN 2.0B (29 bit identifier) SAE J1939
Output Center Position (signal)	C2 C3	Inactive 0V / active 5V ^(B) Inactive 0V / active Vsupply ^(B)
Other electrical Characteristics	EMI	100 V/m

Page 1


Mechanical


Life	> 5 million cycles	
Operating temperature	- 40°C to 85°C	
Operating torque (measured 140 mm from pivot point)	0.56 Nm, 1.2 Nm, 1.7 Nm, 2.2 Nm	
Horizontal load maximum	100 Nm	
Vertical load maximum	1000 N	
max. Torque (Z-axis)	20 Nm	
Protection Level	IP 65 ^(C)	
Gate options	square, cross, single axis (A)	
Lever deflection X/Y	± 20° (A)	
Center position tolerance	± 2° + 0.5°	
Weight	450g	
Housing	Aluminum	
Boot	EPDM (black)	
Cable	Pigtail 600 mm without connector (24 AWG, 0,25 mm²)	



- (A) Others available on request
- (B) Active, if the lever is in the center position inactive, if the lever is outside of the center position
- (C) Above gate with boot









MFG Ball

MFG SK


MFG S1

MFG S2












MFG S3

MFG S4


MFG S7













Y-single axis





Cross

Square

Family AJ3 - S	— <u>X1.7</u>	- <u>Y1.7</u>	- ÷	_ <u>v</u>	08 —	C2 -	
AJ3							
Gate							
S: Square C: Cross X: X-axis single Y: Y-axis single							
X-Axis Operation Torque							
X0.56 : 0.56 Nm X1.2 : 1.2 Nm X1.7 : 1.7 Nm X2.2 : 2.2 Nm							
Y-Axis Operation Torque							
Y0.56 : 0.56 Nm Y1.2 : 1.2 Nm Y1.7 : 1.7 Nm Y2.2 : 2.2 Nm							
Overtravel (float)							
-: none (available on request)							
Output Signals							
V01: 0 (Vsupply - 2.5V) V02: 0 5V V08: 0.5 4.5V V09: 25% Vsupply 75% Vsupply PW2: PWM 500 Hz ± 80Hz CA1: CAN 2.0A CA2: CAN 2.0B J19: SAE J1939 based							
Output Center Position (sign	ial) only for	Voltage O	ıtput —			_	
C2: inactive OV / active 5V C3: inactive OV / active Vsupply							
Grip							
-: no grip : see MFG datasheet for grip order of	ode						

Recommended MFG operating torque combination:

MFG	Operating torque			
Ball	0.56 Nm, 1.2 Nm			
S2	1.2 Nm, 1.7 Nm			
S1, S3, SK, S4, S7	1.7 Nm, 2.2 Nm			

Conversion table N in NM for AJ3 (measured 140mm from pivot point)

Newton	Newtonmeter
4N	0.56 Nm
8N	1.2 Nm
12N	1.7 Nm
16N	2.2 Nm

Vsupply = voltage supply (Ubat)

MFG = multifunction grip

Sensata Technologies, Inc. ("Sensata") data sheets are solely intended to assist designers ("Buyers") who are developing systems that incorporate Sensata products (also referred to herein as "components"). Buyer understands and agrees that Buyer remains responsible for using its independent analysis, evaluation and judgment in designing Buyer's systems and products. Sensata data sheets have been created using standard laboratory conditions and engineering practices. Sensata has not conducted any testing other than that specifically described in the published documentation for a particular data sheet. Sensata may make corrections, enhancements, improvements and other changes to its data sheets or components without notice.

Buyers are authorized to use Sensata data sheets with the Sensata component(s) identified in each particular data sheet. HOWEVER, NO OTHER LICENSE, EXPRESS OR IMPLIED, BY ESTOPPEL OR OTHERWISE TO ANY OTHER SENSATA INTELLECTUAL PROPERTY RIGHT, AND NO LICENSE TO ANY THIRD PARTY TECHNOLOGY OR INTELLECTUAL PROPERTY RIGHT, IS GRANTED HEREIN. SENSATA DATA SHEETS ARE PROVIDED "AS IS". SENSATA MAKES NO WARRANTIES OR REPRESENTATIONS WITH REGARD TO THE DATA SHEETS OF USE OF THE DATA SHEETS, EXPRESS, IMPLIED OR STATUTORY, INCLUDING ACCURACY OR COMPLETENESS. SENSATA DISCLAIMS ANY WARRANTY OF TITLE AND ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, QUIET ENJOYMENT, QUIET POSSESSION, AND NON-INFRINGEMENT OF ANY THIRD PARTY INTELLECTUAL PROPERTY RIGHTS WITH REGARD TO SENSATA DATA SHEETS OR USE THEREOF.

All products are sold subject to Sensata's terms and conditions of sale supplied at www.sensata.com SENSATA ASSUMES NO LIABILITY FOR APPLICATIONS ASSISTANCE OR THE DESIGN OF BUYERS' PRODUCTS. BUYER ACKNOWLEDGES AND AGREES THAT IT IS SOLELY RESPONSIBLE FOR COMPLIANCE WITH ALL LEGAL, REGULATORY AND SAFETY-RELATED REQUIREMENTS CONCERNING ITS PRODUCTS, AND ANY USE OF SENSATA COMPONENTS IN ITS APPLICATIONS, NOTWITHSTANDING ANY APPLICATIONS-RELATED INFORMATION OR SUPPORT THAT MAY BE PROVIDED BY SENSATA.

Mailing Address: Sensata Technologies, Inc., 529 Pleasant Street, Attleboro, MA 02703, USA.

CONTACT US

Page 4

Regional head offices: United States of America

Sensata Technologies Attleboro, MA **Phone:** 508-236-3800 **E-mail:** support@sensata.com

Netherlands

Sensata Technologies Holland B.V.

Hengelo

Phone: +31 74 357 8000 E-mail: support@sensata.com

Sensata Technologies China Co., Ltd.

Shanghai **Phone:** +8621 2306 1500

Phone: +8621 2306 1500 E-mail:support@sensata.com