

EVM3620A-QV-00A

24V/2A Module Converter with Integrated Inductor Evaluation Board

DESCRIPTION

The EVM3620A-QV-00A is an evaluation board for MPM3620A, a synchronous rectified, step-down module converter with built-in power MOSFETs, inductor and two capacitors.

The evaluation board can deliver a 2A continuous output current with excellent load and line regulation over a wide input supply range.

Current-mode operation provides fast transient response and eases loop stabilization.

Full protection features include over-current protection and thermal shut down.

The MPM3620A is available in a space-saving QFN20 (3mm x5mmx1.6mm) package.

ELECTRICAL SPECIFICATION(1)

| Parameter | Symbol | Value | Units |
|----------------|------------------|-------|-------|
| Input Voltage | V_{IN} | 12 | V |
| Output Voltage | V _{OUT} | 3.3 | V |
| Output Current | I _{OUT} | 2 | Α |

Notes:

1) For different input, output spec, please refer to APPLICATION and TYPICAL APPLICATION CIRCUITS section on datasheet to choose proper values.

FEATURES


- 2A Continuous Load Current
- 90mΩ/40mΩ Low R_{DS(ON)} Internal Power MOSFETs
- Integrated Inductor
- Integrated VCC and Bootstrap Capacitors
- Power Save Mode at Light Load
- Power Good Indicator
- OCP Protection and Hiccup
- Thermal Shutdown
- Output Adjustable from 0.8V
- Available in QFN20 (3x5x1.6mm) Package
- Total solution size 6.7mm x7.3mm

APPLICATIONS

- Industrial Controls
- Medical and Imaging Equipment
- Telecom and Networking Applications
- LDO Replacement
- Space and Resource-limited Applications


All MPS parts are lead-free and adhere to the RoHS directive. For MPS green status, please visit MPS website under Products, Quality Assurance page. "MPS" and "The Future of Analog IC Technology" are registered trademarks of Monolithic Power Systems, Inc.

EVM3620A-QV-00A EVALUATION BOARD




(L x W x H) 6.35cm x 6.35cm x 0.32cm

| Board Number | MPS IC Number | | |
|---------------------|---------------|--|--|
| EVM3620A-QV-00A | MPM3620AGQV | | |





EVALUATION BOARD SCHEMATIC




EVM3620A-QV-00A BILL OF MATERIALS

| Qty | Ref | Value | Description | Package | Manufacturer | Manufacturer P/N |
|-----|-----|----------|---|---------|--------------|--------------------|
| 1 | C1 | 10μF | Ceramic Cap,25V,X5R | 0805 | muRata | GRM21BR61E106KA73L |
| 1 | C2 | 22µF | Ceramic Cap,16V,X5R | 0805 | muRata | GRM219R61C226ME15L |
| 0 | C3 | NS | | | | |
| 1 | R1 | 75k | Thick Film Res., 1% | 0402 | Any | |
| 1 | R2 | 24k | Thick Film Res., 1% | 0402 | Any | |
| 1 | R3 | 100k | Thick Film Res., 1% | 0402 | Any | |
| 1 | R4 | 100k | Thick Film Res., 1% | 0402 | Any | |
| 1 | U1 | MPM3620A | Synchronous Step-Down Module Converter | QFN-20 | MPS | MPM3620AGQV |



EVB TEST RESULTS

Performance waveforms are tested on the evaluation board. V_{IN} = 12V, V_{OUT} = 3.3V, T_A =25°C, unless otherwise noted.







EVB TEST RESULTS (continued)

Performance waveforms are tested on the evaluation board. $V_{IN} = 12V$, $V_{OUT} = 3.3V$, $T_A=25^{\circ}C$, unless otherwise noted.


Startup through Enable I_{OUT} = 2A




Shutdown through Enable I_{OUT} = 0A




Shutdown through Enable I_{OUT} = 2A




Short Circuit Steady State




Short Circuit Entry I_{OUT}=0A



Short Circuit Recovery $I_{OUT}=0A$




Load Transient Response





PRINTED CIRCUIT BOARD LAYOUT






Figure 1—Top Silk Layer

Figure 2—Top Layer




Figure 3—Bottom Silk Layer




Figure 4—Bottom Layer



QUICK START GUIDE

- 1. Connect the positive and negative terminals of the load to the V_{OUT} and GND pins, respectively.
- 2. Preset the power supply output between 4.5V and 24V, and then turn off the power supply.
- 3. Connect the positive and negative terminals of the power supply output to the V_{IN} and GND pins, respectively.
- 4. Turn the power supply on. The board will automatically start up.
- 5. To use the Enable function, apply a digital input to the EN pin. Drive EN higher than 1.4V to turn on the converter, or less than 1.25V to turn it off.

NOTICE: The information in this document is subject to change without notice. Please contact MPS for current specifications. Users should warrant and guarantee that third party Intellectual Property rights are not infringed upon when integrating MPS products into any application. MPS will not assume any legal responsibility for any said applications.