

# 193A True-RMS Auto Ranging Automotive DMM

#### **LCD Display**

40000 count with 42 segment bar graph.

# **REC** (Record Mode)

Store minimum, maximum, and average readings over a measurement period.

#### **RANGE**

Manually select the appropriate range

#### AC/DC

Manually select AC or DC measurement functin.

#### **FUNCTION**

Toggle between functions on Ohm, TEMP, and IG modes

### Hz (Frequency)

Measure the frequency of sensors and signals.

# $\Omega$ (Ohms, Resistance)

Measure the resistance of spark plug wires, coils, sensors, and continuity of wiring.

# ACmV and DCmV Ranges

Additional 40 millivolt DC range with 0.01mV resolution for improved accuracy when performing low voltage measurements.

# DCV, ACV (DC Volts, AC Volts)

Measure the voltage of circuits and sensors. Measure the voltage of ABS wheel sensors.

#### **REL** (Relative Mode)

Factor out lead resistance for improved low ohm measurements or compare readings to a known standard. Can also be used for differential measurements.

#### CYL (Cylinder)

Selects the number of cylinders in IG mode.

#### **HOLD**

Lock the reading on the display for hard to read locations or future reference.

#### PEAK-H (Peak Hold)

Capture signals spikes as fast as 1mS to diagnose intermittant events.

# **TEMP** (Temperature)

Measure temperature with included temperature probe.

#### **AC/DC Current Functions**

Measure the parasitic draw from the battery.

# **True-RMS Auto Ranging Automotive DMM**



# **⊣**€ (Capacitance)

Measure the capacitance of condensors or capacitors found in today's hybrid automobiles.

# IP, IG (Automotive Functions)

Measure RPM, Duty, Dwell, mS pulse width, Frequency.

#### **Built in Tilt Stand**

The tilt stand in built into the instrument housing adding strength and integrity to the design.

# **Quickly Test Condition of Internal Fuses**

You can determine the status of the internal fuses before you open the battery/fuse compartment. Simply set the instrument to the diode test function, plug the black test lead into the "V $\Omega$ " input jack and touch the prod end of the black lead to the metal inside the "A" or "UAmA" input lack. If the meter reads "OL, the fuse is blown. If there is a reading on the LCD besides "OL", the fuse is good.

# **Separate Fuse/Battery Compartment**

Easily replace fuses and batteries in this separate compartment. Fuses are clearly labeled with replacement part number.



L) US ED 010-1 CAT I

CAT II-1000V, CAT III-600V POLLUTION DEGREE 2

Safety! cULus 61010-1 Listed Meets CE and IEC61010-1 safety standards.

Function	Range	Resolution	Accuracy	Impedance
DC Volts	40mV	0.001V	'	
	400mV	0.01mV		10M ohm
	4V	0.0001V	±(0.1% + 5 digits)	
	40V	0.001V		
	400V	0.01V		
	1000V	1V		
AC Volts	400mV	0.01mV	·	
(45Hz to 2KHz)	4V	0.0001V		10M ohm
	40V	0.001V	±(0.75% + 40 digit)	
	400V	0.01V		
	750V	1V		
Function	Range	Resolution	Accuracy	Overload Protection
DC Amps	400uA	0.01uA	'	1
	4000uA	0.1uA		
	40mA	0.001mA	±(0.3% + 10 digits)	Fuse*(fast blow)
	400mA	0.01mA		F600V, .5A, 31CM
	4A	0.0001A	±(0.75% + 10 digits)	Fuse*(fast blow)
	10A	0.001A	- 4	F600V, 10A, 31CM
AC Amps	400uA	0.01uA		
	4000uA	0.1uA	±(0.75% + 10 digits)	
	40mA	0.001mA		Fuse*(fast blow)
	400mA	0.01mA		F600V, .5A, 31CM
	4A	0.0001A	±(1.5% + 10 digits)	Fuse*(fast blow)
	10A	0.001A		F600V, 10A, 31CM
ОНМ	400	0.01		600V DC or AC Peak
	4k	0.0001k		Contraction of the Contraction of States of the Contraction of the Con
	40k	0.001k	±(0.1% + 5 digits)	
	400k	0.01k	3 /	
	4M	0.0001M		
	40M	0.001M	±(0.75% + 15 digits)	1
Capacitance	40nF	0.01nF		
	400nF	0.1nF		
	4uF	0.001uF	±(3.0% + 10 digits)	
	40μF	0.01μF	_(=,=,=,	600V DC or Peak AC
	400μF	0.1μF		
	4mF	0.001mF		
	10mF	0.01mF	±(5.0% + 10 digits)	1
Frequency	40Hz	0.001Hz	±(0.070 1 10 digita)	1
	400Hz	0.01Hz		
	4kHz	0.0001kHz	±(0.05% + 2 digits)	1
	40kHz	0.0001kHz	_(0.00 /0 / L digito)	600V DC or Peak AC
	400kHz	0.001kHz		Soot Bo of Found
	4MHz	0.00001MHz		
	10MHz	0.0000 HVII IZ		
Temperature	-40° to 2,462°F	1°F	±(3°F +1 digit) (-4° to 572°F) ±3	S% of reading rest of range
	-40° to 1,350°C	1°C	±(1.5°C +1 digit) (-20 to 300°C) ±3	
Diode Test	3V Test Voltage		A Max Test Current	600 V DC or Peak AC
Continuity	3V Test Voltage	< 70 ohms		600 V DC or Peak AC
- community	57 100t Voltago	. 70 011110		200 v Do oi i oun Ao
IG				
RPM	60 to 12,000	1 RPM	±2 RPM	
	0.0 to 99.9%	0.1%	±2% per kHz, +0.1% (pulse w	idth >0.5mS\
Duty Cycle Dwell	0.0 to 356.4°	0.1% 0.1°	pulse width > 0.5mS	ium 20.31110)
	(30 to 19999 RPM)	0.1	Pulse Widtii > 0.51115	
Pulse Width	0.2 to 199.9mS	0.1mS	±2% per kHz, ±0.1% ±1 digit	(nulea width 2012)
	(30 to 19999 RPM)	0.11113	±2 /0 PEL KEIZ, ±0.170 ±1 UIGIL	(puise wiutii>Zµs)
Eroguepov		0.147	.0.05% of roading .0 digits	
Frequency	1Hz to 1999.9Hz	0.1Hz	±0.05% of reading, ±2 digits	
IP				
		ı	±2 RPM	

Max. Volt. between any Input and Ground	1000V	
Fuse Protection mA:	0.5Amp/600VAC;	
A:	10Amp/600VAC	
Display Type, Digital:	40,000 Count, 4x per second update	
Analog:	2x41 segments, 20x per sec. update	
Operating Temp.	-0° to 45°C (32° to 113°F)	
Storage Temp.	-40° to 60°C (-40° to 140°F)	
Relative Humidity		
0% to 80%:	(0° - 35°C/32° - 95°F)	
0% to 70%:	(35° - 55°C/95° - 131°F)	
Temp. Coefficient	0.1 x (Specified Accuracy) per °C	
	for temperature <18°C to >28°C	
Power Supply	9 Volt Battery	
Battery Life	100 hrs. Alkaline	
Size (H x W x L)	61mm x 97mm x 203mm	
	(2.4in x 3.8in x 8.0in)	
Weight	680g (24oz)	

