Energy Management Energy Meter Type EM340



- Digital input (for tariff management)
- Easy connection or wrong current direction detection
 Certified according to MID Directive (option PF only): see "how to order" below
- Other versions available (not certified, option X): see "how to order" on the next page

- Three phase energy meter
- Class 1 (kWh) according to EN62053-21
- Class B (kWh) according to EN50470-3
- Accuracy ±0.5% RDG (current/voltage)
- Direct current measurement up to 65AAC
- Backlit LCD display (3x 8-digit) with integrated touch key-pad
- Energy readout on display: 8 digit
- Variable readout on display: 4 digit
- Energy measurement: kWh and kvarh (imported/ exported); kWh+ by 2 tariffs; kWh per phase
- System variables: kW, kvar, kVA, VLL, VLN, PF, Hz, kWdmd, kWdmd peak
- Phase variables: kW, kvar, kVA, VLL, VLN, A, PF
- Self power supply
- Dimensions: 3-DIN module
- Protection degree (front): IP51
- Pulse output (optional, by open collector NPN)
- RS485 Modbus port (optional)
- M-bus port (optional)

Three-phase energy meter with backlit LCD display with

Product description

with backlit LCD display with integrated touch keypad. Particularly indicated for active energy metering and for cost allocation in applications up to 65 A (direct connection), with dual tariff management availability. It can measure imported and exported energy or be programmed to consider only the imported one. Housing for DIN-rail mounting, with IP51 front degree protection. The meter is optionally provided with pulse output proportional to the active energy being

measured, RS485 Modbus port or M-bus port. Available for legal metrology (PF option, only for imported energy).

Certified according to MID Directive, Module B and Module D of Annex II, for legal metrology relevant to active electrical energy meters (see Annex V, MI003, of MID). Can be used for fiscal (legal) metrology.

How to order EM340 DIN AV2 3 X O1 PF B

| Model | ΥΥ |
|-----------------|----|
| Range code | |
| System | |
| Power supply | |
| Output | |
| Option | |
| Measurement ——— | |

Type Selection

| Range code System | | Power supply | | Output | | | |
|-------------------|--|--------------|---|------------|---|-------------------|---|
| AV2: | 208 to 400 VLL AC - 5(65)A (Direct connection) | 3: | 3-phase, 3 or 4 wire; 2-phase 3 wire | x : | Self power supply -20% +20% of the rated measuring input voltage, 45 to 65Hz | O1: S1: M1: | pulse output RS485 Modbus port M-bus port |
| | | | | | | | |
| Optio | on | | | Меа | surement | | |
| Optio PF: | | | rective. Can be used for | Mea A: | surement The power is always in positive imported and r the total energy meter | negative | e exported power) and |

1

CARLO GAVAZZI



How to order EM340-DIN AV2 3 X O1 X STANDARD Model -Т Range code -Not certified according to MID Directive. Cannot be used System for fiscal (legal) metrology. Power supply -Output -Option -

Type Selection

| Rang | e code | de System | | Power supply | | Output | |
|------|--|-----------|--|--------------|---|-------------------|---|
| AV2: | 208 to 400 VLL AC - 5(65)A (Direct connection) | 3: | 3-phase, 3- or 4-wire; 2-phase 3-wire | X: | self power supply -20% +20% of the rated measuring input voltage, 45 to 65Hz | O1: S1: M1: | pulse output RS485 Modbus port M-bus port |

Option

X: none

Input specifications

| Rated Inputs | | Temperature drift | ≤200ppm/°C |
|---|---|---------------------------------------|---|
| Current type | 3-phase loads, direct | Sampling rate | 4096 samples/s @ 50Hz |
| _ | connection | | 4096 samples/s @ 60Hz |
| Current range | 5(65)A | Display and touch key-pad | |
| Nominal voltage | 208 to 400 VLL AC | Туре | Backlit LCD, 3 rows by |
| | | | 8-digit each, h 7 mm |
| (@25°C ±5°C, R.H. ≤60%, 45 to 65 Hz) | | Read-out | Energy: 8 digit. Variables: 4 |
| 45 10 05 112) | Imin=0.25A; Ib: 5A, Imax: | - | digit |
| | 65A; Un: 113 to 265VLN | Touch key Max. and Min. indication | 3 (DOWN, Enter and UP). |
| | (196 to 460VLL) | Energies | Max. 99 999 999 |
| | Imin=0.25A; Ib: 5A, Imax: | Ellergies | Min. 0.01 |
| | 65A; from 208 to 400 VLLAC | Variables | Max. 9999 |
| Current | From 0.04lb to 0.2lb: | Vanabioo | Min. 0.01 |
| | ±(0.5%RDG+1DGT) | Memory | |
| | From 0.2lb to Imax: | Energy | 10^12 cycles. Energy value |
| | ±(0.5%RDG) | | is saved every time the less |
| Phase-neutral voltage | In the range Un: ±(0.5% RDG) | | significant digit increases. |
| Phase-phase voltage | In the range Un: ±(1% RDG) | Programming parameters | 10^12 cycles. When a |
| Frequency | Range: 45 to 65Hz. | | parameter is modified, only |
| Active power | From 0.05 In to Imax, within Un range, PF=1: | | the relevant memory cell is |
| | ±(1% RDG) | | overwritten |
| | From 0.1 In to Imax, within | LEDs | Flashing red light pulses |
| | Un range, PF=0.5L or 0.8C: | | according to EN50470-3, |
| | ±(1% RDG) | | EN62052-11, 1000 imp./ kWh (min. period: 90ms) |
| Power factor | ±[0.001+1%(1.000 - "PF RDG")] | | Fix orange light: wrong |
| Reactive power | From 0.05 In to Imax, | | current direction (only with |
| · | within Un range, sinphì=1: | | PFB option or with "B" |
| | ±(2% RDG) | | measurement selection in |
| | From 0.1 In to Imax, within | | case of X option) |
| | Un range, sinphì=0.5L or | Current overloads | , , |
| | 0.8C: ±(2% RDG) | | |
| Energies | | Continuous For 10ms | 65A, @ 50Hz 8450 A |
| Active energy | Class 1 according to EN62053-21 Class B | Voltage Overloads | 0430 A |
| | (Class B (kWh) according | Continuous | 1.2 Un |
| | to EN50470-3) | For 500ms | 2 Un |
| Reactive energy | Class 2 according to | Input impedance | |
| readive energy | EN62053-23 | 230VL-N | 1.2Mohm |
| Start-up current: | 20mA | 120VL-N | 1.2Mohm |
| | Self-consumption is not | 5(65) A | < 1.25VA |
| | measured. | Wrong connection detection | Installation guide to |
| Start-up voltage | 90VLN | 5 | indicate if connections are |
| Resolution | Display/serial | | correctly carried out. Can |
| | communication | | be disabled. |
| Current | 0.1/0.001 A | Phase sequence | Indicates if the phase |
| Voltage | 0.1/0.1 V | | sequence is not the correct |
| Power | 0.01 kW or kVar/ 0.1 W or | | one (L1-L2-L3) |
| F | | Correct current direction | Indicates if the current |
| Frequency PF | 0.1 Hz/0.1Hz | | direction is not the right one |
| Energies (positive) | 0.01/ 0.001 0.01 kWh or kvarh / 0.1 | | (only with PFB option or |
| Energies (positive) | kWh or kvarh | | with type "B" measurement |
| Energies (negative) | 0.01 kWh or kvarh / 0.1 | | selection in case of X option). |
| | kWh or kvarh | | option). |
| Energy additional errors | | | |
| Influence quantities | According to EN62053-21 | | |
| · | - | | |
| | | | |

Input specifications (cont.)

Load conditions

The wrong connection detection works in case of loads with: - PF>0.766 (<40°) power factor if inductive or PF>0.996 (<5°) if capacitive

- a current at least equal to 10% rated current (primary current transformer)

Digital input specifications

| Digital inputs Function | Free of voltage contact Tariff management (switch between t1-t2) | Overload | In case a voltage is erroneously applied to the digital input, the input is not |
|--|--|----------|---|
| Number of inputs Contact measurement voltage Input impedance Contact resistance | 1 5 V 1kohm ≤1kohm, close contact ≥100kohm, open contact | | damaged up to 30 VAC/ DC. |

Output specifications

| RS485 serial port | RS485 by screw | | measured data |
|-------------------------|------------------------------|-----------------------------|------------------------------|
| • | connection. | Protocol | M-bus according to |
| Function | For communication | | EN13757-1 |
| | of measured data, | Baud rate | 0.3, 2.4, 9.6 kbaud |
| | programming parameters | Meters in the M-bus network | 250 |
| Protocol | ModBus RTU (slave | Primary address | Selectable |
| | function) | Secondary address | Univocally defined in each |
| Baud rate | 9.6, 19.2, 38.4, 57.6, 115.2 | | unit |
| | kbaud, | Identification number range | from 9000 0000 to 9999 |
| Data format | even or no parity, | | 9999 |
| Address | 1 to 247 (default: 01) | Other | Available functions: wild |
| Driver input capability | 1/8 unit load. Maximum 247 | | card, header, initialisation |
| | devices on the | | SND_NKE, and req_udr |
| | same bus. | | management. Management |
| Data refresh time | 1sec | | of primary address |
| Read command | 50 words available in 1 | | modification via M-bus and |
| | read command | | reset of partial energy via |
| Rx/Tx indication | Rx segment on display | | M-bus available. |
| | is shown when a valid | | VIF, VIFE, DIF and DIFE: |
| | Modbus command is sent | | see protocoll |
| | to that specific meter | Static output | |
| | Tx segment on display | Purpose | For pulse output |
| | is shown when a valid | | proportional to the active |
| | Modbus reply is sent back | | energy (kWh) |
| | to the master | Pulse rate | Selectable in multiple of |
| M-bus port | M-bus by screw | | 100 |
| | connection. | | Max 500 or 1500 kWh |
| Function | For communication of | | according to pulse ON |
| | | | duration |

Output specifications (cont.)

Pulse ON duration

Output type

Selectable: 30ms or 100 ms according to EN62052-31 Open collector NPN

Load

 $V_{_{\rm ON}}$ 1 VDC max. 100mA $V_{_{\rm OFF}}$ 80 VDC max.

General specifications

| Operating temperature | From -25 to +55°C/from | Standard compliance | |
|---------------------------|---|--------------------------|---|
| | -13 to +131°F (PF option) | Safety | EN62052-11 |
| | From –25 to +65°C/from | Metrology | EN62053-21, EN50470-3 |
| | -13 to +149°F (X option), | Approvals | CE, MID (PF option only) |
| | indoor, (R.H. from 0 to 90% | Connections | |
| | non-condensing @ 40°C) | Cable cross-section area | Measuring inputs: max. 16 mm ² , min. 2.5 mm ² |
| Storage temperature | From –30 to +80°C/from | | with/without metallic |
| | -22 to +176°F (R.H. < 90% | | cable ferrule; Max. screw |
| | non-condensing @ 40°C) | | tightening torque: 2.8 Nm |
| Overvoltage category | Cat. III | Other terminals | 1.5 mm ² , Min./Max. screws |
| Insulation (for 1 minute) | 4000 VAC RMS between | e di el terminale | tightening torque: 0.4 Nm |
| | measuring inputs and | Housing | |
| | digital/serial output (see | Dimensions (WxHxD) | 54 x 90 x 63 mm |
| | table) 4000 VAC RMS | Material | Noryl, self-extinguishing: |
| Dielectric strength | 4000 VAC RMS for 1 | | UL 94 V-0 |
| | minute | Sealing covers | Included |
| EMC | According to EN62052-11 | Mounting | DIN-rail |
| Electrostatic discharges | 15kV air discharge; | Protection degree | |
| Immunity to irradiated | | Front | IP51 |
| electromagnetic fields | Test with current: 10V/m from 80 to 2000MHz; | Screw terminals | IP20 |
| Electromagnetic fields | Test without any current: | Weight | Approx. 240 g (packing |
| | 30V/m from 80 to | | included) |
| Burst | 2000MHz; | | |
| Buist | On current and voltage measuring inputs circuit: | | |
| | 4kV | | |
| Immunity to conducted | | | |
| disturbances | 10V/m from 150KHz to | | |
| | 80MHz | | |
| Surge | On current and voltage | | |
| - | measuring inputs circuit: | | |
| | 4kV; | | |
| Radio frequency | According to CISPR 22 | | |
| | | | |
| | | | |
| | | | |

Power supply specifications

Self power supply

208 to 400VAC VLL, -20% +20% 50/60Hz


Power consumption

≤ 1W, ≤ 10VA


Insulation (for 1 minute) between inputs and outputs

| | Measuring input | Digital or serial output | Digital input |
|--------------------------|-----------------|--------------------------|---------------|
| Measuring input | - | 4 kV | 4 kV |
| Digital or serial output | 4 kV | - | 0 kV |
| Digital input | 4 kV | 0 kV | - |

Accuracy (according to EN50470-3 and EN62053-23)



kWh, accuracy (RDG) depending on the current kvarh, accuracy (RDG) depending on the current



Display pages

| No | 1 st row | 2 nd row | 3 rd row | "Full" mode | "Easy" mode | Note |
|----|----------------------|---------------------|---------------------|----------------|----------------|---|
| 0 | kWh+ (imported) | | kW system | Х | × | In PF version (MID) this is the only certified energy meter. In PFA version and in X version with Measurement menu set to "A", this is considering the total energy without considering the current direction. |
| 1 | kWh- (exported) | | kW system | х | X | Only in X version, with Measurement menu set to "B" |
| 2 | kWh+ (imported) | | V L-L system | х | X | |
| 3 | kWh+ (imported) | | V L-N system | Х | X | |
| 4 | kWh+ (imported) | | PF system | Х | | |
| 5 | kWh+ (imported) | | Hz | Х | | |
| 6 | kvarh+ (imported) | | kvar system | Х | × | In X version with Measurement menu set to "A", this is considering the total positive reactive energy without considering the current direction. |
| 7 | kvarh- (exported) | | kvar system | Х | X | Only in X version, with Measurement menu set to "B" |
| 8 | kWh+ (imported) | | kVA system | Х | | |
| 9 | kWh+ (imported) | kWdmd peak | kWdmd | Х | | |
| 10 | kWh (t1) | "t1" | kW system | Х | X | Only relevant to kWh+, with Tariff menu set to ON. |
| 11 | kWh (t2) | "t2" | kW system | Х | X | Only relevant to kWh+, with Tariff menu set to ON. |
| 12 | kWh L1 | kWh L2 | kWh L3 | Х | | In X version with Measurement menu set to "A", this is considering the total energy without considering the current direction. In PFB version and in X version with Measurement menu set to "B", this is considering only the imported energy. |
| 13 | kVA L1 | kVA L2 | kVA L3 | Х | | |
| 14 | kvar L1 | kvar L2 | kvar L3 | Х | | |
| 15 | PF L1 | PF L2 | PF L3 | Х | | |
| 16 | VL-NL1 | VL-NL2 | VL-NL3 | Х | | |
| 17 | V L-L L1 | VL-LL2 | V L-L L3 | Х | | |
| 18 | A L1 | A L2 | A L3 | Х | Х | |
| 19 | kW L1 | kW L2 | kW L3 | Х | | |


X= available




Additional available information on the display


| Туре | Description | Note | |
|--------|-------------------|---|--|
| Info 1 | Year (2016) | Year of production | |
| Info 2 | Serial (dddnnnA) | Serial number (ddd= day of the year; nnn=progressive number; A= production line, internal use only) | |
| Info 3 | Rev (A.01) | Firmware revision | |
| Info 4 | Puls led | Led pulsed/kWh | |
| P3 | System | System type | |
| P6 | Measure | Measurement type | |
| P7 | Install | Wrong connection detection | |
| P8 | P int | Integration time for Wdmd calculation | |
| P9 | Mode | Set of variables on display | |
| P10 | Tariff | Tariff enabling | |
| P11 | Home | Selected home page | |
| P12-1 | Pulse duration | Pulse ON duration | |
| P12-2 | Pulse rate | Pulse rate | |
| P13 | Primary address | M-bus primary address | |
| P14 | Address | Modbus serial address | |
| P15 | Kbaud | M-bus or Modbus baud rate | |
| P16 | Parity | Modbus parity | |
| Info 5 | Secondary address | M-bus secondary address | |


Wiring diagrams





Wiring diagrams (cont.)















Front panel description



- 1. Display Backlit LCD display with touch key-pad.
- 2. LED LED proportional to kWh reading

3. Serial number Area reserved to serial number and MID-relevant data in PF versions

Dimensions

