

Evaluation Boards for the **HMC6832** 3.5 GHz, Low Noise, 2:8 Differential Fanout Buffer

FEATURES

- On-board LDO voltage regulator for 2.5 V/3.3 V device under test (DUT) supply**
- LDO can be bypassed to allow for an external supply**
- AC-coupled differential SMA connectors**
- SMA connectors for**
 - 2 differential input clocks**
 - 8 analog differential outputs**
- Jumpers to enable/disable the LDO voltage regulator**
- Clip on access points for power/ground**
- Jumper for input clock selection**
- Matched RF differential traces**

GENERAL DESCRIPTION

This user guide describes the two evaluation boards for evaluating the [HMC6832](#) fully differential output buffer. Both evaluation boards, EV1HMC6832ALP5L and EV2HMC6832ALP5L, allow access to all [HMC6832](#) input/outputs via SMAs.

The EV1HMC6832ALP5L is configured for the LVPECL version of the product whereas the EV2HMC6832ALP5L is configured for LVDS. Each board has an on-board low dropout (LDO) regulator for 2.5 V/3.3 V operation that can be disabled to use an external supply. Each board has matched RF differential traces for testing output to output channel skew.

For full specifications on the [HMC6832](#), see the product data sheet, which should be consulted in conjunction with this user guide when working with the evaluation board. The evaluation board schematics and the [HMC6832](#) data sheet are available on the [HMC6832](#) product page.

PHOTOGRAPH OF EV1HMC6832ALP5L




Figure 1. EV1HMC6832ALP5L Evaluation Board

14294-001

TABLE OF CONTENTS

Features	1	Setting Up Signal Connections.....	3
General Description	1	Bypassing the 5 V LDO Voltage Regulator	3
Photograph of EV1HMC6832ALP5L	1	Jumper Configurations	4
Revision History	2	Test Equipment Configurations	5
Getting Started	3		
Powering the Evaluation Board	3		

REVISION HISTORY

3/16—Revision 0: Initial Version

GETTING STARTED

For convenience, many of the jumpers are preinstalled on the evaluation boards as listed in Table 1. The jumper installation is dependent on the version of the evaluation board, EV1HMC6832ALP5L or EV2HMC6832ALP5L. Prior to powering on the evaluation board, it is important to verify the jumper configuration against Table 1 and Figure 3 for the physical locations of the jumpers and test points.

POWERING THE EVALUATION BOARD

It is important to decide whether to use the on-board voltage regulator or an external power supply because the jumper configurations vary accordingly. Refer to Table 1 for the required jumper configurations.

If using the on-board regulator, apply 5 V to TP3 and ground either TP1 or TP4. Figure 4 provides an example of this scheme. In this scenario, install J8 but do not install J7. J6 determines the output voltage of the regulator and installing J9 allows observation of the regulator output voltage at TP2. Refer to Table 1 for additional information about J6 and J9.

SETTING UP SIGNAL CONNECTIONS

There are two ac-coupled inputs to choose from, Input 0 or Input 1, via the IN_SEL pin of the HMC6832. The input is determined by J3 on the evaluation board. A signal generator can be connected to either or both of these inputs and the user can select between them as follows:

- To select Input 0, tie J3 to ground.
- To select Input 1, tie J3 to V_{DD}.

Connect the output(s) of interest to either an oscilloscope or a spectrum analyzer for observation and evaluation (see Figure 4).

BYPASSING THE 5 V LDO VOLTAGE REGULATOR

To use an external power supply, such as for current measurements, bypass the on-board voltage regulator. To bypass the regulator, reconfigure the jumpers by installing J7 and not installing J8. An external supply of either 2.5 V (LVDS or LVPECL) or 3.3 V (LVPECL only) can then be supplied to TP2 (see Table 2).




Figure 2. Functional Block Diagram

14294-002

JUMPER CONFIGURATIONS

Refer to Figure 3 for jumper and test point locations on the board.

Table 1. Jumper Settings

Jumper Number	Function	Installed	Uninstalled	Preinstalled on Evaluation Board
J3	Input level for IN_SEL pin. GND selects Input0 and DUT_VCC selects Input1.	As needed, depending on input desired.	If not installed, default is Input0 as IN_SEL has an internal pull-down	No
J5	Determines LVPECL/LVDS mode.	Sets CONFIG pin to proper configuration mode (LVPECL/LVDS).	Sets HMC6832 to LVDS mode due to internal pull-up on the device.	Yes
J6	Determines the regulator supply.	Regulator supplies 2.5 V, assuming it is enabled (J7 not installed) and 5 V is supplied to TP3.	Regulator supplies 3.3 V, assuming it is enabled (J7 not installed) and 5 V is supplied to TP3.	Yes
J7	Enables or disables the regulator output.	Disables regulator output.	Enables regulator output.	No
J8	Connects or disconnects the regulator output to the HMC6832 device.	Connects the regulator output to the device.	Disconnects the regulator output and the device.	Yes
J9	Determines the function of TP2 to observe the regulator output or to apply power to the HMC6832 device, depending on the installation status of J8.	When J8 is installed, the regulator output can be observed at TP2. When J8 is not installed, power can be applied (2.5 V or 3.3 V) via TP2.	Power cannot be applied or observed at TP2.	Yes
J30	Analog Devices, Inc., use only.	Do not install.	Analog Devices use only.	No

Table 2. Test Points

Test Point Number	Function
TP1	Ground connection.
TP2	When J8 and J9 are installed, TP2 observes the regulator output. When J9 is installed and J8 is not installed, TP2 supplies power (2.5 V or 3.3 V) to the HMC6832 .
TP3	5 V supply for the on-board regulator.
TP4	Ground connection.

TEST EQUIPMENT CONFIGURATIONS

The test equipment requirements and setup configurations are shown in Figure 3 and Figure 4.




Figure 3. Test Point and Jumper Labels on EV1HMC6832ALP5L/EV2HMC6832ALP5L




Figure 4. Block Diagram of the EV1HMC6832ALP5L/EV2HMC6832ALP5L Test Equipment Setup

NOTES

**ESD Caution**

ESD (electrostatic discharge) sensitive device. Charged devices and circuit boards can discharge without detection. Although this product features patented or proprietary protection circuitry, damage may occur on devices subjected to high energy ESD. Therefore, proper ESD precautions should be taken to avoid performance degradation or loss of functionality.

Legal Terms and Conditions

By using the evaluation board discussed herein (together with any tools, components documentation or support materials, the "Evaluation Board"), you are agreeing to be bound by the terms and conditions set forth below ("Agreement") unless you have purchased the Evaluation Board, in which case the Analog Devices Standard Terms and Conditions of Sale shall govern. Do not use the Evaluation Board until you have read and agreed to the Agreement. Your use of the Evaluation Board shall signify your acceptance of the Agreement. This Agreement is made by and between you ("Customer") and Analog Devices, Inc. ("ADI"), with its principal place of business at One Technology Way, Norwood, MA 02062, USA. Subject to the terms and conditions of the Agreement, ADI hereby grants to Customer a free, limited, personal, temporary, non-exclusive, non-sublicensable, non-transferable license to use the Evaluation Board FOR EVALUATION PURPOSES ONLY. Customer understands and agrees that the Evaluation Board is provided for the sole and exclusive purpose referenced above, and agrees not to use the Evaluation Board for any other purpose. Furthermore, the license granted is expressly made subject to the following additional limitations: Customer shall not (i) rent, lease, display, sell, transfer, assign, sublicense, or distribute the Evaluation Board; and (ii) permit any Third Party to access the Evaluation Board. As used herein, the term "Third Party" includes any entity other than ADI, Customer, their employees, affiliates and in-house consultants. The Evaluation Board is NOT sold to Customer; all rights not expressly granted herein, including ownership of the Evaluation Board, are reserved by ADI. CONFIDENTIALITY. This Agreement and the Evaluation Board shall all be considered the confidential and proprietary information of ADI. Customer may not disclose or transfer any portion of the Evaluation Board to any other party for any reason. Upon discontinuation of use of the Evaluation Board or termination of this Agreement, Customer agrees to promptly return the Evaluation Board to ADI. ADDITIONAL RESTRICTIONS. Customer may not disassemble, decompile or reverse engineer chips on the Evaluation Board. Customer shall inform ADI of any occurred damages or any modifications or alterations it makes to the Evaluation Board, including but not limited to soldering or any other activity that affects the material content of the Evaluation Board. Modifications to the Evaluation Board must comply with applicable law, including but not limited to the RoHS Directive. TERMINATION. ADI may terminate this Agreement at any time upon giving written notice to Customer. Customer agrees to return to ADI the Evaluation Board at that time. LIMITATION OF LIABILITY. THE EVALUATION BOARD PROVIDED HEREUNDER IS PROVIDED "AS IS" AND ADI MAKES NO WARRANTIES OR REPRESENTATIONS OF ANY KIND WITH RESPECT TO IT. ADI SPECIFICALLY DISCLAIMS ANY REPRESENTATIONS, ENDORSEMENTS, GUARANTEES, OR WARRANTIES, EXPRESS OR IMPLIED, RELATED TO THE EVALUATION BOARD INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTY OF MERCHANTABILITY, TITLE, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT OF INTELLECTUAL PROPERTY RIGHTS. IN NO EVENT WILL ADI AND ITS LICENSORS BE LIABLE FOR ANY INCIDENTAL, SPECIAL, INDIRECT, OR CONSEQUENTIAL DAMAGES RESULTING FROM CUSTOMER'S POSSESSION OR USE OF THE EVALUATION BOARD, INCLUDING BUT NOT LIMITED TO LOST PROFITS, DELAY COSTS, LABOR COSTS OR LOSS OF GOODWILL. ADI'S TOTAL LIABILITY FROM ANY AND ALL CAUSES SHALL BE LIMITED TO THE AMOUNT OF ONE HUNDRED US DOLLARS (\$100.00). EXPORT. Customer agrees that it will not directly or indirectly export the Evaluation Board to another country, and that it will comply with all applicable United States federal laws and regulations relating to exports. GOVERNING LAW. This Agreement shall be governed by and construed in accordance with the substantive laws of the Commonwealth of Massachusetts (excluding conflict of law rules). Any legal action regarding this Agreement will be heard in the state or federal courts having jurisdiction in Suffolk County, Massachusetts, and Customer hereby submits to the personal jurisdiction and venue of such courts. The United Nations Convention on Contracts for the International Sale of Goods shall not apply to this Agreement and is expressly disclaimed.

©2016 Analog Devices, Inc. All rights reserved. Trademarks and registered trademarks are the property of their respective owners.
UG14294-0-3/16(0)



www.analog.com