



### PRODUCT OVERVIEW


DMS01-VP-RS12-C is a robust digital panel meter that provides precise measurement and display of voltage process signals on a highly visible red 1" (25mm) tall, 3  $\frac{1}{2}$  to 4  $\frac{1}{2}$  digit seven-segment LED display with adjustable brightness. It provides selectable 0-5VDC or 0-10VDC input range, up to 32 display ranges and choice of user calibration or factory calibration modes. An external 12VDC power source provides power to the meter and an internal DC-DC converter accommodates a  $\pm 48V$  common-mode measurement range with respect to the power supply input, simplifying a wide range of measurement applications and an internal digital filter enhances performance in electrically noisy environments making this digital panel meter is ideal for laboratory instrumentation, factory automation, and any application requiring precision measurement.

## ORDERING INFORMATION

DMS01-VP-RS12-C Digital Voltage Process Meter, 1" Red Display, 12VDC Power

## **Features**

- Measures 0-5 V or 0-10 V process signals
- 32 user-selectable span (display) ranges
- Bright 1" red LED display, readable at distance of 80 feet (~24 m)
- Adjustable display brightness
- Wide common-mode input range (±48V)
- Digital filter for optimizing measurements in electrically noisy environments
- Operates from an external 12VDC power supply
- Mounts with adhesive strips (supplied) or screws
- 0.1% Typical Accuracy
- Two-year warranty





For full details go to www.murata-ps.com/rohs



Parameter	Min	Тур	Max	Units		
Supply Voltage (Operating)	11	12	13	V		
Absolute Maximum Supply Voltage	-1		+14	V		
Supply Current <sup>1</sup> (Operating at maximum intensity)			100	mA		
(Operating at minimum intensity)			60	mA		
Digits (Displayed)	3.5 – 4.5	, depending on disp	olay range			
Digit Height		1 (25.4)		inch (mm)		
Display Update Rate		3		Sa/s		
Decimal Selection	Manual/Auto (o	Manual/Auto (only when displaying physical input voltage)				
Display Color						
Over-range Indication						
Measurement Range (5V range)	0		+5	V		
(10V range)	0		+10	V		
Display Span Range (unipolar mode)	2000		20000			
(bipolar mode)	-9500		+9500			
Accuracy		0.1%	1%			
Zero-Offset (5V range)	-2		+2	count		
(10V range)	-2		+2	count		
Input Impedance		1M		Ω		
Offset Trim Range	±5% of span rai	nge, see span rang	e selection table			
Gain Trim Range	see s	table				
Temperature Drift (0 to +50°C)		±0.8		count/°C		
Absolute Maximum Input Voltage (+VIN to -VIN)	-30		+30	V		
Common-mode Input Range (-VIN) to (-VS)	-48		+48	V		

<sup>1</sup> based on a display value of "1.888"


based on a display value of "1.888"						
PHYSICAL/ENVIRONMENTAL						
Parameter	Min	Тур	Max	Units		
Operating Temperature	0		+50	°C		
Storage Temperature	-40		+75	°C		
Humidity (non-condensing)			85	%RH		
Weight		6.14 (174)		oz (g)		
User Controls						
ghtness single-turn potentiometer						
Offset and Gain Adjustment		QTY 2 12-turn trim potentiometers				
Dipswitch configuration setting for: - Input voltage range - Digital filter enable - Span (display) range - Unipolar / Bipolar mode - Trim enable		QTY 2 6-position dipswitches (S1 & S2)				
Overall Dimensions 5.86 (149) L x 3.36 (86) W x 1.43 (37) H inc						
Terminal Blocks	Min	Тур	Max	Units		
Wire Size	24		14	AWG		
Insulation Strip Length		0.25 (6)		inch (mm)		
Screw Tightening Torque		56.6 (0.4)		oz-in (N-m)		



### MEASUREMENT TYPE AND CAPABILITIES

- Measures 0-5 or 0-10 VDC process signals with 32 user-selectable span ranges (via S1, S2), displaying 3-1/2 to 4 1/2 digits of resolution.
- > Choice of two user selectable modes of operation: unipolar (supports only positive readings) and bipolar (supports negative output readings).
- ➤ A high-input impedance helps maintain accuracy with a variety of signal sources.
- > The meter's measurement terminals are electrically isolated from the power terminals through a DC-DC converter, providing a high common-mode input range (±48V) for the input (relative to the power terminals), simplifying a wide range of measurement applications.
- > Meter requires an external 12VDC power supply (not included).

## REAR PANEL LAYOUT: SCREW TERMINAL CONNECTIONS & CONTROLS




Terminal Block						
Terminal #	Name	Function				
1	-VS	Dowar Cupply Torminals (+19)/DC)				
2	+VS	Power Supply Terminals (+12VDC)				
3	-IN	Magaurament Input Tarminala				
4	+IN	Measurement Input Terminals				

**Brightness Adjust** — This single-turn potentiometer supports adjustment of the meter's LED display brightness for maximum readability. Turning the pot clockwise increases brightness, while turning it counterclockwise decreases brightness.

Offset Adjust – This 12-turn potentiometer supports the offset adjustments of the span ranges. See the span range selection table for the maximum allowed offset for each span range. Turning the pot clockwise will give a negative offset, while turning it counterclockwise give a positive offset. Gain (Scale) Adjust – This 12-turn potentiometer supports gain adjustments of the span ranges. This allows the user to select values between each of the span ranges, between 1780 to 20300 (unipolar mode) and -9785 to 9785 (bipolar mode). See the span range selection table for the maximum allowed gain for each span range. Turning the pot clockwise decreases (-) the gain, while turning it counterclockwise increases (+) the gain (see Span Ranges below).

S1 & S2 – 6-position dipswitches provided for configuration the meter's various options. See Meter Configuration below for details.

### **CONNECTION EXAMPLES**



This example illustrates an application where the voltage output sensor is connected to terminals 3 and 4, where terminal 3 is the negative input terminal (-IN) and terminal 4 is the positive input terminal (+IN).

The 12V power supply (not included) connects to terminals 1 and 2, where terminal 1 is the negative power supply terminal (-VS) and terminal 2 is the positive power supply terminal (+VS) and the sensor is powered from a separate external power supply. Note: it is possible to power both the sensor and the meter from the same power supply provided the sensor can operate from +12VDC.



## METER CONFIGURATION

This Meter is configured through 2, 6-position dipswitches S1 and S2 on the back of the meter. Each switch position is identified by SW#. For example, SW1 is switch 1 on S1, and controls the input range, while SW1 on S2 selects of one the span ranges. The following illustrate the possible configurations:

Input Range Sele											
Input Range Setting	9	SW1	Dipsw	itch S1	Description						
0-5V	OFF		ON [] [] [] 1 2 3	4 5 6	SW1 on S1 controls the meter's input range. In the OFF p			position the input			
0-10V		ON	ON 1 2 3	4 5 6	range is 0-5 V, while in the ON position the meter's range is 0						
Digital Filter											
Digital Filter Or	n/Off	SW2	Dipsw	itch S1	Description						
OFF		OFF ON		4 5 6	SW2 on S1 controls the meter's digital filter. In the OFF position, the is disabled and readings are updated at maximum speed. In the ON						
ON		ON	ON	4 5 6	<ul> <li>position, the filter is enabled, and readings are processed through moving average filter, which results in more stable readings, by response.</li> </ul>						
Unipolar/Bipolar	Mode Selection										
Mode Settin		SW2	Dipsw	itch S2	Description						
Unipolar		OFF	ON	4 5 6	Bipolar mode allows the user to display negative value the meter is set to 0-10 V input, span of 6000 and se then 0 V input results in a count of 0 on the display, w		an of 6000 and set in	et in unipolar mode,			
Bipolar		ON	ON I 1 2 3		results in a count of 6000 on the display. If the meter is set to bip mode with the same settings, 0 V input results in a count of -600 display, while 10 V results in a count of +6000 on the display. SV controls whether the meter is in unipolar or bipolar mode. Unipola can display values between 0 to +20000 depending on the span setting. Bipolar mode can display values between -9500 to +950 depending on the span range setting. The bipolar mode is not offe beyond ±9500 because of display limitations.				t of -6000 on the isplay. SW2 on S2 e. Unipolar mode the span range to +9500		
Span Range Sele											
Span Range	Gain Adjustment	Offset Adjustment	S2 SW1	SW3	SW4	1 SW5	SW6	Dipswitch S2	Dipswitch S1		
Input Voltage (V)	N/A	N/A	OFF	OFF	OFF	OFF	OFF	ON 1 2 3 4 5 6	ON 1 2 3 4 5 6		
2000	220 ±2	100 ±2	OFF	ON	OFF	OFF	OFF	ON 1 2 3 4 5 6	ON		
2500	288 ±2	125 ± 1	OFF	OFF	ON	OFF	OFF	ON 1 2 3 4 5 6	ON		
3000	255 ±2	150 ±2	OFF	ON	ON	OFF	OFF	ON 1 2 3 4 5 6	ON		
3500	263 ±2	175 ±2	OFF	OFF	ON	OFF	OFF	ON	ON		





Span Range Sel	ection continued								
Span Range	Gain Adjustment	Offset Adjustment	S2 SW1	SW3	SW4	S1 SW5	SW6	Dipswitch S2	Dipswitch S1
4000	260 ±2	200 ±2	OFF	ON	OFF	ON	OFF	ON	ON
4500	270 ±2	225 ±2	OFF	OFF	ON	ON	OFF	ON 1 2 3 4 5 6	ON
5000	250 ±2	250 ±2	OFF	ON	ON	ON	OFF	ON 1 2 3 4 5 6	ON
5500	275 ±2	275 ±2	OFF	OFF	OFF	OFF	ON	ON 1 2 3 4 5 6	ON 1 2 3 4 5 6
6000	270 ±2	300 ±2	OFF	ON	OFF	OFF	ON	ON 1 2 3 4 5 6	ON 1 2 3 4 5 6
6500	260 ±2	325 ±2	OFF	OFF	ON	OFF	ON	ON 1 2 3 4 5 6	ON 1 2 3 4 5 6
7000	280 ±2	350 ±2	OFF	ON	ON	OFF	ON	ON	ON 1 2 3 4 5 6
7500	263 ±2	375 ±2	OFF	OFF	OFF	ON	ON	ON 1 2 3 4 5 6	ON 1 2 3 4 5 6
8000	280 ±2	400 ±2	OFF	ON	OFF	ON	ON	ON 1 2 3 4 5 6	ON 1 2 3 4 5 6
8500	298 ±2	425 ±2	OFF	OFF	ON	ON	ON	ON 1 2 3 4 5 6	ON 1 2 3 4 5 6
9000	270 ±2	450 ±2	OFF	ON	ON	ON	ON	ON 1 2 3 4 5 6	ON 1 2 3 4 5 6
9500	285 ±2	475 ±2	ON	OFF	OFF	OFF	OFF	ON 1 2 3 4 5 6	ON 1 2 3 4 5 6
10000	250 ±2	500 ±2	ON	ON	OFF	OFF	OFF	ON 1 2 3 4 5 6	ON 1 2 3 4 5 6
10500	263 ±2	525 ±2	ON	OFF	ON	OFF	OFF	ON 1 2 3 4 5 6	ON
11000	275 ±2	550 ±2	ON	ON	ON	OFF	OFF	ON 1 2 3 4 5 6	ON 1 2 3 4 5 6
11500	288 ±2	575 ±2	ON	OFF	OFF	ON	OFF	ON	ON 1 2 3 4 5 6
12000	300 ±2	600 ±2	ON	ON	OFF	ON	OFF	ON 1 2 3 4 5 6	ON
12500	250 ±2	625 ±2	ON	OFF	ON	ON	OFF	ON 1 2 3 4 5 6	ON 1 2 3 4 5 6
13000	260 ±2	650 ±2	ON	ON	ON	ON	OFF	ON 1 2 3 4 5 6	ON





0 D	Gain	Offset	S2			S1		DI	D	
Span Range	Adjustment	Adjustment	SW1	SW3	SW4	SW5	SW6	Dipswitch S2	Dipswitch S1	
13500	270 ±2	675 ±2	ON	OFF	OFF	OFF	ON	ON 1 2 3 4 5 6	ON 1 2 3 4 5 6	
14000	280 ±2	700 ±2	ON	ON	OFF	OFF	ON	ON 1 2 3 4 5 6	ON	
15000	750 ±2	750 ±2	ON	OFF	ON	OFF	ON	ON 1 2 3 4 5 6	ON	
16000	320 ±2	800 ±2	ON	ON	ON	OFF	ON	ON 1 2 3 4 5 6	ON	
17000	765 ±2	850 ±2	ON	OFF	OFF	ON	ON	ON 1 2 3 4 5 6	ON	
18000	270 ±2	900 ±2	ON	ON	OFF	ON	ON	ON 1 2 3 4 5 6	ON	
19000	760 ±2	950 ±2	ON	OFF	ON	ON	ON	ON 1 2 3 4 5 6	ON	
20000	300 ±2	1000 ±2	ON	ON	ON	ON	ON	ON 1 2 3 4 5 6	ON	
Decimal Point S	election									
Decimal Placement	SW3	SW4	SW5		itch S2					
0000	OFF	OFF	OFF	ON		When the span range dipswitch settings are all turned OFF, the decimal placement is automatically chosen based on the input value. For example, for 0-5 V the decimal placement is 0.000. For 0-10 V the decimal placement is 00.00. When any of the span range switches are turned ON, the decimal point				
0.000	ON	OFF	OFF							
00.00	OFF	ON	OFF	ON	4 5 6	placement has to be manually selected. SW3 through SW5 or S2 control the decimal point placement options as shown.  Setting only one of the switches on at a time allows the user to				
000.0	OFF	OFF	ON	ON	choose the decimal place the					
Trim Enable Sel		01110		D		077/0				
Trim E	nadie	SW6	)	Dipswi	tch S2			or adjusting gain and In the "OFF" position		
OF	F	OFF			4 5 6	enabled by SW6 on S2. In the "OFF" position, disabled and the meter runs from factory calibration ranges. In the "ON" position the trim is enabled to vary the gain and offset of the span range. The span range of the span range.		ibrated span led, allowing use		
ON		ON		ON	4 5 <b>6</b>	adjustment any number 9785 to +9 (see span ra the operator	allows the use between 17785 (bipolar ange table all can use the nly when on	ser to adjust the spa (80 and 20300 (unip mode) with the spar pove). If the meter is a gain or offset adjus e of the span range	n of the meter to olar mode) and n range setting out of calibration tment for	



## **TECHNICAL NOTES**



#### 1. Calibration

This meter is calibrated at the factory at the time of manufacture. If the meter is out of calibration the operator can use the gain or offset adjustment (Trim Enable) for correction, only when one of the span range settings is set, not when displaying the physical input voltage. However, calibration may no long be within datasheet specifications.

### 2. Protection and Fusing

This meter contains an internal PTC fuse as well as other protective elements that are intended for protection against brief electrical transients and misconnect conditions. Additional external protective components such as fuses and transient suppressors may be required depending on the application in which the meter is deployed.

## 3. Noisy Power Supplies


In systems with noisy power supplies, connecting an external, non-polarized capacitor across the +VS and -VS inputs can help reduce measurement errors. In certain situations, the use of twisted pair or shield wiring may be required.

#### 4. Installation

**IMPORTANT!** To ensure safe and reliable operation, DMS01 meters must be installed and serviced by qualified technical personnel. Contact Murata Power Solutions if there is any doubt regarding their installation or operation.


### 5. Over-range Limit

This meter flashes on and off when the meters minimum or maximum input voltage is exceeded. For example, if the meter is set to the 0-5 V input range; any input voltage below 0 V or above 5 V will cause the display flash on and off.



Note: When mounting panel meter with hardware, a four hole pattern (four outermost holes) or the six hole pattern may be used at the customer's option.





APPLICATION NOTES							
Document Number	Description	URL Link to Document					
DMS-AN25	Application Note: DMS01 Meter Measurement and Calibration	Click to open application note					

Murata Power Solutions, Inc. 129 Flanders Rd. Westborough, Ma 01581, USA. ISO 9001 and 14001 REGISTERED



This product is subject to the following operating requirements and the Life and Safety Critical Application Sales Policy:

Refer to: https://www.murata-ps.com/requirements/

Murata Power Solutions, inc. makes no representation that the use of its products in the circuits described herein, or the use of other technical information contained herein, will not infringe upon existing or future patent rights. The descriptions contained herein do not imply the granting of licenses to make, use, or sell equipment constructed in accordance therewith. Specifications are subject to change without notice.

### 2020 Murata Power Solutions, Inc..