Ultra-stable, high precision (ppm class) fluxgate technology DS Series current transducer for non-intrusive, isolated DC and AC current measurement up to 440A



#### Features

DANI/ENSE

Linearity error maximum ±15 ppm

10V BNC output connection

Fluxgate, closed loop compensated technology with fixed excitation frequency and second harmonic zero flux detection for best in class accuracy and stability

Green diode for normal operation indication

Full aluminum body for superior EMI shielding and extended operating temperature range

Large aperture  $\phi$ 27.6mm for cables and bus bars

# UK CA

CE

**ROHS** 

#### **Applications:**

MPS for particles accelerators

Gradient amplifiers for MRI devices

Stable power supplies

Precision drives

Batteries testing and evaluation systems

Power measurement and power analysis

Current calibration purposes

Specification highlights	Symbol	Unit	Min	Тур.	Max
Nominal primary AC current	I <sub>PN</sub> AC	Arms			280
Nominal primary DC current	I <sub>PN</sub> DC	А			400
Nominal output voltage	V <sub>out</sub>	V	-10		10
Measuring range	I <sub>PM</sub>	А	-440		440
Primary / secondary ratio		V/kA	25,0000		25,0000
Linearity error (Best fit)	€L	ppm	-15		15
Offect Veltage (including certh field)	I <sub>OE</sub>	ppm	-15		15
Offset Voltage (including earth field)	V <sub>OE</sub>	uV	-150		150
AC Maximum gain error 10Hz to 1kHz					0.01%
Bandwidth (3dB)	f <sub>3dB</sub>	kHz	500		
Operating temperature range	Та	°C	-40		65
Power supply voltages	Uc	V	±14.25		±15.75

All ppm (or %) values refer to nominal current

# Electrical specifications at Ta=23°C, supply voltage = ± 15V unless otherwise stated


Parameter		Symbol	Unit	Min	Тур.	Max	Comment
Nominal primary A	AC current	I <sub>PN</sub> AC	Arms			280	Refer to fig. 1 & 2 for derating
Nominal primary D	DC current	I <sub>PN</sub> DC	А	-400		400	Refer to fig. 1 for derating
Measuring range		I <sub>PM</sub>	А	-440		440	Refer to fig. 1 & 2 for derating
Overload capacity		Î <sub>OL</sub>	А			1500	Non-measured, 100ms
Nominal voltage o	utput	Vo	V	-10		10	At nominal primary DC current
Primary/seconda	ryratio		V/kA	25,0000		25,0000	
Linearity error		ε <sub>L</sub>	ppm	-15		15	ppm refers to nominal current
Bandwidth (3dB)		f <sub>3dB</sub>	kHz	500			Small signal, graphs figure 3
Response time to IPN	a step current	tr@90%	μs		1		di/dt = 100A/µs
Amplitude error	10Hz-1kHz					0,04	
	1kHz-10kHz	εG	%			0,20	% refers to nominal current
	10kHz-100kHz					7,00	
Phase shift	10Hz-1kHz					0,01	
	1kHz-10kHz	θ	o			0,07	
	10kHz-100kHz					2,00	
Noise	0 - 100Hz					0,02	Measured on secondary current
	0 - 1kHz	noise	nom rma			0,10	
	0 - 10kHz	noise	ppm rms			1,00	
	0 - 100kHz					3,50	
Fluxgate excitation	frequency	f <sub>Exc</sub>	kHz		32,5		
Power supply volta	ages	Uc	V	±14.25		±15.75	
Positive current co	onsumption	lps	mA			104	Add Vo/25 (A)
Negative current c	onsumption	Ins	mA			96	Add Vo/25 (A)
Operating tempera	ature range	Та	°C	-40		65	
Offset error							
Initial		V <sub>OE</sub>	ppm	-15		15	ppm refers to nominal DC current
Versus temperatu	re	TC <sub>VOE</sub>	ppm/K	-1		1	ppm refers to nominal DC current
Versus time		V <sub>OE</sub> /time	ppm/ month	-0,3		0,3	ppm refers to nominal DC current
Versus supply volt	age		ppm/V	-0,1		0,1	ppm refers to nominal DC current
Ratio Error							
Initial @23°C		ε <sub>c</sub>	ppm	-5		5	ppm refers to nominal DC current
Versus temperature		TCE <sub>c</sub>	ppm/K	-2		2	ppm refers to nominal DC current
Versus time		€ <sub>C</sub> /time	ppm/ month	-3		3	ppm refers to nominal DC current




Indicate that caution is necessary when operating the device

Caution: Intended use is to measure current, and the product should only be used for intended use.

### Frequency and ambient temperature derating (Fig. 2)



### Frequency characteristics (Fig. 3)



### Amplitude / Phase

Precision – Innovation www.danisense.com



# **Isolation specifications**

Parameter	Unit	Value
Clearance	mm	9.5
Creepage distance	mm	10.5
Comparative tracking index (CTI)		> 600
Rms voltage for AC isolation test, 50/60 Hz, 1 min - Between primary and (secondary and shield) - Between secondary and shield	kV	5.7 0.2
Impulse withstand voltage (1.2/50µs)	kV	10.4
Continous working voltage with Uninsulated wire Non mains CAT II (DC and rms) CAT III (DC and rms) Insulated wire Non mains CAT II (DC and rms) CAT III (DC and rms)	V	1000 600 300 2000 1000 1000
Transient voltage with Uninsulated wire Non mains CAT II CAT III Insulated wire Non mains CAT II CAT III CAT III	V	4500 6000 6000 6000 6000 8000



**Caution:** Do not connect the transducer to signals or use for measurements within Measurement Category IV, or for measurements on MAINs circuits or on circuits derived from Overvoltage Category IV which may have transient overvoltages above what the product can withstand. The product must not be connected to circuits that have a maximum voltage above the continuous working voltage, relative to earth or to other channels, or this could damage and defeat the insulation. The product can only withstand transients up to the transient overvoltage rating without breakdown or damage to the insulation. An analysis of the working voltages, loop impedances, temporary overvoltages, and transient overvoltages in the system must be conducted prior to making measurements.

Caution: When using insulated wires all wiring must be insulated for the highest voltage used.

# Absolute maximum ratings

Parameter	Unit	Max	Comment
Primary	kA	4.5	Maximum 100ms
Power supply	V	±16.5	

# Environmental, safety and mechanical specifications

Parameter	Unit	Min	Тур	Max	Comment	
Altitude	m			2000		
Usage					Designed for indoor use	
Transient voltages					Up to overvoltage category III	
Poution Degree				2		
Ambient operating temper- ature range	°C	-40		65		
Storage temperature range	°C	-40		85		
Relative humidity	%	20		80	Non-condensing	
Mass	kg		0.6			
Connections	DSUB9 male and BNC connector					
Standards	IEC61010-2-30 IEC61326-1 EMC IEC61010-1:2010 3rd Edition					
External devices	External devices connected to current transducers must comply with the standards IEC61010-1, IEC60950 or IEC62368-1 and be energy-limited circuitry					
Cleaning	The transducer should only be cleaned with a damp cloth. No detergent or chemicals should be used.					
Temperature	When multiple primary turns are used or high primary currents are applied the temperature around the transducer will increase, please monitor to ensure that the maximum ratisngs are not exceeded. It is recommended to have minimum 1mm <sup>2</sup> per ampere in the primary busbar.					

# Advanced Sensor Protection Circuits "ASPC"

Developed to protect the current transducer from typical fault conditions:

- Unit is un-powered and secondary circuit is open or closed
- Unit is powered and secondary circuit is open or interrupted

Both DC and AC primary current up to 100% of nominal value can be applied to the current transducers in the above situations without damage to the electronics.

Please notice that the transducer core can be magnetized in all above cases, leading to a small change in output offset current (less than 10ppm)

### Status pins

When transducer is operating in normal condition, the status pins (3 and 8) are shorted. Status pins properties: - forward direction pin 8 to pin 3, maximum forward current 10mA - maximum forward voltage 60V, maximum reverse voltage 5V


# Accessories

- 4-channel power supplies unit for connection up to 4 x DL2000 :
- 6-channel power supplies for connection of up to 6 x DL2000:
- Transducer cables in 4 lengths (2m 5m 10m 15m 20m):

DSSIU-4-1U DSSIU-6-1U DSUB2 - DSUB5 - DSUB10 -DSUB15 - DSUB20

Please visit the Danisense homepage for relevant datasheets.





(general tolerance 0.3mm unless otherwise stat-

#### **DSUB pin layout**





#### DSUB-9 pinout & BNC connection

When sensor is operating in normal condition the status pins are shorted.

Status pin properties.

- Forward direction pin 8 to pin 3
- Maximum forward current 10mA - Maximum forward voltage 60V
- Maximum reverse voltage 5V





#### Positive current direction

Is identified by an arrow on the transducer body

#### **Mounting instructions**

- Base plate mounting
- Back side panel mounting
- 2 holes  $\phi$ 6.5 2 x M5 steel screws / 6N.m
- 3 x M4 steel screw / 4N.m



#### Intended use:

The DS400UB-10V is designed to measure current up to 400A, and be powered by a DSSIU-4-1U or DSSIU-6-1U.

#### Instruction for use:

- 1. Do not power up the device before all cables are connected.
- 2. Only use cables supplied by Danisense
- 3. Place the primary conductor through the apperture of the transducer
- 4. If the DSSIU-4(6)-1U is intended for desk use, mount the rubber feet which are part of the package.

5. If the DSSIU-4(6)-1U is intended for Rack mounting, use the screw kit for mounting and do not mount the rubber feet.

6. Connect a DSUB cable between DSSIU-4(6)-1U and each sensor

7. Connect a Voltmeter, DMM or other sort of analyzer with a voltage input to the transducer BNC connector.

8. Ensure that no calibration connectors are attached when measuring primary current. Always avoid to create a calibration short circuit, between + and — calibration connection.

9. There is a risk of electrical shock if an uninsulated busbar with high voltages is touching the metal enclosure of the transducer. Please ensure before powering up the system that no primary busbar can touch the metal enclosure.

10. When all connection are secured - connect mains power

11. Apply primary current

#### Safety Instructions:

DO NOT TRY TO DISASSEMBLE THE UNIT.

If the green transducer diode is not operating when the system is powered up, disconnect power and contact Danisense for further instruction.

If the equipment is used in a manner not specified by the manufacturer, the protection provided by the



# **Declaration of Conformity**

Danisense A/S Malervej 10 DK-2630 Taastrup Denmark

Declares that under our sole responsibility that this product is in conformity with the provisions of the following EC Directives, including all amendments, and with national legislation implementing these directives:

Directive 2014/30/EU

Directive 2014/35/EU

And that the following harmonized standards have been applied

EN 61010-1 (Third Edition):2010, EN 61010-1:2010/A1:2019

EN 61010-2-030:2021/A11:2021

#### EN 61326-1:2013

All DANISENSE products are manufactured in accordance with RoHS directive 2011/65/EU. Annex II of the RoHS directive was amended by directive 2015/863 in force since 2015, expanding the list of 6 restricted substances (Lead, Hexavalent Chromium, PBB, PBDE and Cadmium)

Danisense follows the provision in EN 63000:2018

Haurk

Place

Taastrup, Denmark

Henrik Elbæk

Date 2022-03-15