



## **Isolated DC/DC Converter IC**

# **Isolated Type Fly-back Converter IC with Integrated Switching MOSFET for Automotive**

## **BD7F205EFJ-C**

#### <span id="page-0-0"></span>**General Description**

BD7F205EFJ-C is an opto-coupler-less isolated flyback converter. Feedback circuit by optocouplers or the auxiliary winding of transformers becomes unnecessary, contributing to reduction of set parts. Furthermore, the adoption of original adapted ON-time control technology enables fast load response. In addition, the various protection function realizes the designs of isolated power supply application for high reliability.

#### <span id="page-0-1"></span>**Features**

- AEC-Q100 Qualified (Note 1)
- No Need for Optocoupler and Third Winding of **Transformer**
- Set Output Voltage with Two External Resistors and Ratio of Transformer Turns
- Adopt of Original Adapted ON-Time Control Technology Fast Load Response
- High Efficiency at Light Load Mode (PFM Operation)
- Shutdown Function / Enable Control
- Built-in 60 V Switching MOSFET
- Frequency Spectrum Spread
- Soft Start Function
- Load Compensation Function
- Various Protection Function
- Input Low Voltage Lockout (UVLO) Over Current Protection (OCP) Thermal Shutdown (TSD) REF Pin Open Protection (REFOPEN) Short Circuit Protection (SCP) Battery Short Protection (BSP) ■ HTSOP-J8 Package
- *(Note 1)* Grade 1

## <span id="page-0-5"></span>**Typical Application Circuit**

#### <span id="page-0-2"></span>**Key Specifications**



■ Operating Ambient Temperature Range  $-40$  °C to +125 °C

<span id="page-0-3"></span>**Package W (Typ) x D (Typ) x H (Max)** 4.9 mm x 6.0 mm x 1.0 mm



#### <span id="page-0-4"></span>**Applications**

- Automotive Isolated Power Supplies (E-Comp, Inverter etc)
	- Industrial Isolated Power Supplies



OProduct structure : Silicon integrated circuit OThis product has no designed protection against radioactive rays.<br>www.rohm.com

## **Contents**

<span id="page-1-0"></span>

## <span id="page-2-0"></span>**Pin Configuration**



## <span id="page-2-1"></span>**Pin Descriptions**



*(Note 1)* The N.C pin does not have internal connection. Open the pin when mounting board. *(Note 2)* The EXP-Pad pin is connected to GND on the mounting board.

#### <span id="page-2-2"></span>**Block Diagram**



## <span id="page-3-1"></span><span id="page-3-0"></span>**Description of Blocks**

#### **1 INTERNAL REGULATOR**

This is regulator block for internal circuits. This block shuts itself down at the shutdown status of SDX/EN pin voltage  $V_{SDX}$  or less. When SDX/EN pin voltage rises V<sub>SDX</sub> or above, IC consumption current increases. When SDX/EN pin voltage is  $V_{EN1}$  or above, IC enters the enable status and starts switching operation. The soft start function operates for tss period from switching start, and the output voltage rises slowly. When SDX/EN pin voltage falls V<sub>EN2</sub> or below, IC enters the disables status and the switching operation is stopped.



Figure 1. Startup and Stop Timing Chart

#### <span id="page-3-2"></span>**2 Input Low Voltage Lock Out (UVLO)**

This is the protection function for the low input voltage of the VIN pin. When VIN pin voltage falls V<sub>UVLO1</sub> or below, IC detects UVLO and stops switching operation. When VIN pin voltage rises  $V_{UVLO2}$  or above, IC starts switching operation and a soft start function operates during the period of tss.



Figure 2. VIN UVLO Timing Chart

## <span id="page-4-0"></span>**Description of Blocks – continued**

#### **3 Thermal Shutdown (TSD)**

This block is the thermal shutdown circuit that prevents heat damage to the IC. When IC junction temperature rises more than 175 °C (Typ), IC stops switching operation. After that When IC junction temperature falls IC restarts. The temperature hysteresis is 25 °C (Typ). The TSD function aims to protect itself. So IC junction temperature should be designed less than Tjmax = 150 °C. For that, it should not use as over temperature protection function of application.

#### <span id="page-4-1"></span>**4 SW VOLTAGE DETECTION**

This block detects the flyback voltage generated in the SW pin. In turn-off of the transformer, this block converts current to flow from the FB pin into voltage by the resistance of the REF pin and the flyback voltage is detected by this REF pin voltage.

The IC controls REF pin voltage to be equivalent to VINTREF.

#### <span id="page-4-2"></span>**5 SOFT START**

When IC turns to enable status that SDX/EN pin voltage is V<sub>EN1</sub> or above, the comparison voltage of the PWM COMPARATOR block increases gradually from 0 V to VINTREF. PWM comparator voltage is constantly VINTREF after soft start time passed.

This operation prevents from the output voltage overshooting. The soft start time is fixed to tss in the IC. And SCP protection is invalid for t<sub>MASKSCP</sub> period from start-up.

#### <span id="page-4-3"></span>**6 PWM COMPARATOR**

This block compares REF pin voltage equivalent to feedback voltage of the output voltage with soft start voltage or reference voltage VINTREF. This comparator output decides the ON timing. Since it does not have error amplifier and constitutes a feedback loop by the comparator, IC enables fast control to load response during PWM operation.

#### <span id="page-4-4"></span>**7 ADAPTIVE ON TIME CONTROLLER**

This block is ON time control block which uses original adapted ON-time control technology.

Stable load current: IC operates in PWM operation by constant ON time control. Fluctuating load current: IC operates in the constant ON time control and fluctuate the switching frequency. It results from fast response. Light load: The switching frequency decreases and realizes a high efficiency by PFM operation during discontinuous mode.

When the load current fluctuates, IC operates  $f_{SWMAX}$  or below. IC raises the primary average current by shortening the off time. It results from increasing the secondary current and secondary output voltage is quickly stable.





#### <span id="page-4-5"></span>**8 Maximum Frequency Limit Function (MAX FREQ)**

This function limits the maximum frequency. The switching frequency is instantly high at ON width control in start-up or load response. It may influence to EMI. For that, IC limits max frequency less than fsw MAX.

#### <span id="page-4-6"></span>**9 DRIVER**

This is the block which drives Nch MOSFET for switching.

#### <span id="page-4-7"></span>**10 Nch MOSFET**

This is Nch MOSFET for switching.

## <span id="page-5-0"></span>**Description of Blocks – continued**

#### **11 LOAD COMPENSATION**

This block compensates the decrease of output voltage caused by the change of  $V_F$  characteristic in the secondary output diode which is proportional to load current. It monitors the current flown to the switching MOSFET and a part of the current flows to the REF pin. The quantity of compensation determines by the external resistor and capacitor at the L\_COMP pin and KL\_COMP which is coefficient for SW current. For that, as the current flown from the FB pin to the external resistor of the REF pin decreases, the output voltage decrease is compensated.

#### <span id="page-5-1"></span>**12 Frequency Spectrum Spread (SPECTRUM SPREAD)**

This is the function to spread switching frequency.

## The frequency spreading in the range of  $\pm 5$  % contributes to low EMI.

## <span id="page-5-2"></span>**13 Over Current Protection (OCP), Battery Short Protection (BSP)**

This function is over current protection of the MOSFET.

#### **13.1 Over Current Protection (OCP)**

When the switching MOSFET is on, as the primary transformer peak current becomes  $I_{LIMIT}$  or more, IC detects the over current and the switching MOSFET is turned off. Because IC detects OCP per switching cycles, ON duty is limited and the output voltage drops. In addition, to prevent miss detection by turn ON surge, the detection of OCP is invalid for ton MIN after the switching MOSFET is turned on.

After IC detects OCP, switching MOSFET is turn off after a delay time. When VIN voltage is increased, ILIMIT is higher by the rise of current slope. ΔILIMIT depends on LP value of transformer.

$$
\Delta I_{LIMIT} = VIN \times t_{DELAY} / L_P
$$

 $t_{DELAY}$  : OCP detection delay time<br>  $L_P$  : Primary inductance

: Primary inductance

 $t_{DELAY}$  is always 0.2 µs or less.



#### Figure 4. OCP Timing Chart

## **13.2 Battery Short Protection (BSP)**

In the case of increasing peak current by CCM (Continuous Conduction Mode) operation such as the short of the transformer winding or output short of secondary, large current over ILIMIT is flown to the switching MOSFET. To prevent this phenomenon, IC is built-in BSP function. When SW pin current becomes I<sub>BSP</sub> or more at the switching MOSFET ON, the IC detects BSP. By this function, the switching operation is stopped in the period of tBSP. After it passes tBSP, IC recovers switching operation without soft-start function. When BSP state continues, IC stops switching operation by SCP protection because output voltage is low. BSP is affected by the delay time (t<sub>DELAY</sub>) the same as OCP, and I<sub>BSP</sub> increases according to VIN voltage. Also, when primary transformer is short, the function is operated.



Figure 5. BSP Timing Chart

## <span id="page-6-0"></span>**Description of Blocks – continued**

#### **14 Short Circuit Protection (SCP), REF Pin Open Protection (REFOPEN)**

This is the block of the short protection and the open protection of the REF pin.

#### **14.1 Short Circuit Protection (SCP)**

As IC converts the primary flyback voltage to REF pin voltage, IC detects secondary output status. When secondary output voltage drops, REF pin voltage also drops. When REF pin voltage is Vsc<sub>P</sub> or below, IC detects SCP. When the detection continues for t<sub>MASK</sub>, the switching operation is stopped. After the time of tRESTART passes from the stop, IC restarts with soft start function. To prevent SCP miss detection, the detection of SCP is invalid for t<sub>MASKSCP</sub> at start-up. When REF voltage is V<sub>SCP</sub> or below for t<sub>MASKSCP</sub> from start-up, IC stops switching for tRESTART.



#### Figure 6. SCP Timing Chart

#### **14.2 REF Pin Open Protection (REFOPEN)**

The REF pin detects the secondary output voltage status from the primary flyback voltage. When the REF pin is open, output status is not detected, and switching MOSFET may occur malfunction. Therefore, when the REF pin voltage is VREFOP or above, the IC detects REFOPEN protection. When the detection continues for t<sub>MASK</sub>, the switching operation is stopped. After the time of tRESTART from the stop, IC restarts with soft start function. When auto recovery, IC operates for  $t_{\text{MASK}}$  from start-up. When REF pin voltage is  $V_{\text{REFOP}}$  or above for  $t_{\text{MASK}}$ , IC stops switching for tRESTART.





## <span id="page-7-0"></span>**Absolute Maximum Ratings** (**Ta = 25 °C**)



Caution 1: Operating the IC over the absolute maximum ratings may damage the IC. The damage can either be a short circuit between pins or an open circuit *between pins and the internal circuitry. Therefore, it is important to consider circuit protection measures, such as adding a fuse, in case the IC is operated over the absolute maximum ratings.*

Caution 2: Should by any chance the maximum junction temperature rating be exceeded the rise in temperature of the chip may result in deterioration of the<br>properties of the chip. In case of exceeding this absolute maximum *increasing board size and copper area so as not to exceed the maximum junction temperature rating.*

#### <span id="page-7-1"></span>**Thermal Resistance***(Note 1)*



*(Note 1)* Based on JESD51-2 A (Still-Air).

*(Note 2)* The thermal characterization parameter to report the difference between junction temperature and the temperature at the top center of the outside surface of the component package. *(Note 3)* Using a PCB board based on JESD51-3.



 *(Note 5)* This thermal via connect with the copper pattern of layers 1,2, and 4. The placement and dimensions obey a land pattern.

#### <span id="page-7-2"></span>**Recommended Operating Conditions**



*(Note 6)* Set the REF resistor value of 2.7 kΩ (Typ). Choose the resistance accuracy for an output voltage accuracy.

<span id="page-8-0"></span>

*(Note 1)* Load compensation current coefficient is the coefficient which compensates output voltage decrease for output current.

It sets by L\_COMP pin resistor. It is tested at  $R_{\text{L\_COMP}}$  = 10 kΩ.

## <span id="page-9-0"></span>**Typical Performance Curves**



Figure 8. Current at Shutdown vs Temperature



Figure 10. UVLO Detection Voltage1 vs Temperature



Figure 9. Operating Current at No Switching vs Temperature



Figure 11. UVLO Detection Voltage2 vs Temperature

## **Typical Performance Curves – continued**



Figure 12. UVLO Voltage Hysteresis vs Temperature



Figure 14. Enable Voltage1 vs Temperature



Figure 13. Shutdown Voltage at the SDX/EN Pin vs **Temperature** 



Figure 15. Enable Voltage2 vs Temperature

## **Typical Performance Curves – continued**



Figure 16. Enable Voltage Hysteresis vs Temperature



Figure 18. SDX/EN Pin Pull-down Resistance vs Temperature



Figure 17. SDX/EN Pin Current vs Temperature



Figure 19. Reference Voltage vs Temperature



Figure 20. REF Pin Current vs Temperature



Figure 22. Over Current Detection Current vs Temperature



Figure 21. On Resistance vs Temperature



Figure 23. BSP Detection Current vs Temperature

## **Typical Performance Curves – continued**



Figure 24. Averaging Switching Frequency vs Temperature



Figure 26. On Time vs Temperature  $(Duty = 40 %, fsw = 363 kHz)$ 



Figure 25. Maximum Switching Frequency vs Temperature



Figure 27. Minimum ON Time vs Temperature



Figure 28. Maximum OFF Time vs Temperature



Figure 30. Short Protection Detection Voltage vs Temperature



Figure 29. Soft Start Time vs Temperature



Figure 31. REFOPEN Protection Detection Voltage vs Temperature



Figure 32. SCP/REFOPEN Detection Mask Time vs Temperature



Figure 34. BSP Stop Time at Detection vs Temperature



Figure 33. SCP Mask Time at Start-up vs Temperature



Figure 35. Restart Time vs Temperature

## **Typical Performance Curves – continued**



Figure 36. KL\_COMP vs Temperature

## <span id="page-17-1"></span><span id="page-17-0"></span>**Application Examples**

#### **1 Output Voltage**

When the internal switching MOSFET is off, SW pin voltage "Vsw" is higher than VIN pin voltage. The secondary output voltage is calculated by the primary flyback voltage, which is described by the difference between this SW pin voltage and VIN pin voltage. The SW pin voltage at turn off is calculated by the following formula.

$$
V_{SW} = V_{IN} + \frac{N_P}{N_S} \times (V_{OUT} + V_F)
$$
 [V]

where:

 $V_{SW}$  is SW pin voltage.

 $V_{IN}$  is VIN pin voltage.

 $N_P$  is the number of winding at the primary transformer.

 $N_{\mathcal{S}}$  is the number of winding at the secondary transformer.

 $V_{OUT}$  is the Output voltage.

 $V_F$  is the forward voltage of the secondary output diode.



Figure 37. Application Block Diagram

The external resistor R<sub>FB</sub> between the FB pin and the SW pin converts the primary flyback voltage into the FB pin inflow current  $I_{FB}$ . I<sub>FB</sub> is calculated by the formula below because the FB pin voltage is nearly equal to the VIN pin voltage by IC's internal circuit.

$$
I_{FB} = \frac{V_{SW} - V_{FB}}{R_{FB}} = \frac{V_{IN} + \frac{N_P}{N_S} \times (V_{OUT} + V_F) - V_{FB}}{R_{FB}} = \frac{\frac{N_P}{N_S} \times (V_{OUT} + V_F)}{R_{FB}}
$$
 [A]

where:

 $I_{FB}$  is FB the pin inflow current.

 $V_{FB}$  is FB pin voltage.

 $R_{FB}$  is the external resistor between the FB pin and the SW pin.

#### **1 Output Voltage – continued**

FB current IRFB flows to the REF pin and the external resistor RREF between the REF pin and the GND pin. REF pin voltage is calculated by below equation.

$$
V_{REF} = \frac{R_{REF}}{R_{FB}} \times \frac{N_P}{N_S} \times (V_{OUT} + V_F)
$$
 [V]

where:

 $V_{REF}$  is REF pin voltage.

 $R_{\text{RFF}}$  is the external resistor between the REF pin and the GND pin.

RREF resistor is necessary to set 2.7 kΩ because REF pin current is equivalent to IREF and REF pin voltage is equivalent to VINTREF.

$$
R_{REF} = \frac{0.54 \text{ V}}{200 \text{ }\mu\text{A}} = 2.7 \text{ } k\Omega
$$

 $\frac{100}{4}$  200  $\mu$ A<br>Therefore, the REF pin resistor is always needed to set R<sub>REF</sub> = 2.7 kΩ .

The REF pin voltage is input to the comparator with the reference voltage V<sub>INTREF</sub> in the IC. By the internal circuit, the REF pin voltage is equal to the reference voltage. Therefore, the output voltage and the REF pin voltage is calculated by the formula below.

$$
V_{OUT} = \frac{R_{FB}}{R_{REF}} \times \frac{N_S}{N_P} \times V_{INTER} - V_F
$$
 [V]

To be shown to the equation, the output voltage is set by the number of winding ratio of the primary and secondary transformer (N<sub>P</sub>/N<sub>S</sub>) and the resistance ratio of R<sub>FB</sub> and R<sub>REF</sub>. According to the relational expression in above, the external resistor RFB between the FB pin and the SW pin is calculated by the formula below.

$$
R_{FB} = \frac{R_{REF}}{V_{INTER}} \times \frac{N_P}{N_S} \times (V_{OUT} + V_F)
$$
 [Ω]

The ESR of the transformer on the secondary side as well as  $V_F$  causes the output voltage drop.

And, when transformer coupling is low, the N<sub>P</sub> / N<sub>S</sub> turns ratio changes and output voltage is lower than the setting voltage. Therefore, adjust the output voltage by actual evaluation of power supply.

#### <span id="page-19-0"></span>**2 Transformer**

#### **2.1 The Determine of Winding Ratio N<sup>P</sup> / N<sup>S</sup>**

 The winding ratio is the parameter for setting output voltage, Max output power, Duty, SW pin voltage. The duty of flyback converter is calculated by the following equation:

$$
Duty = \frac{\frac{N_P}{N_S} \times (V_{OUT} + V_F)}{V_{IN} + \frac{N_P}{N_S} \times (V_{OUT} + V_F)}
$$
 [%)

 $N_P$  is the Primary transformer winding

 $N_S^{\phantom i}$  is the Secondary transformer winding

 $V_{OUT}$  is the Output voltage

 $V_F$  is the forward voltage of secondary output diode

 $V_{IN}$  is VIN pin voltage

The winding ratio is calculated by below equation.

$$
\frac{N_P}{N_S} = \frac{D_{TYP}}{1 - D_{TYP}} \times \frac{V_{IN}}{V_{OUT} + V_F}
$$
  

$$
D_{TYP}
$$
 is the Duty of VIN voltage (Typ)

In the middle VIN voltage of usual operating range, it recommends that  $D_{TYP}$  is set from 30 % to 50 %. First, it recommends to set  $D_{TYP}$  = 40 %. The winding ratio is limited by the maximum duty( $D_{MAX}$ ) in minimum input voltage condition. D<sub>MAX</sub> given by the formula below must be not over 70 %. When duty is over 70 %, change D<sub>TYP</sub> to be lower. If Duty is over 70 %, OFF time is short and the output voltage may change due to the shift in flyback voltage detection.

$$
\frac{N_P}{N_S} = \frac{D_{MAX}}{1 - D_{MAX}} \times \frac{V_{IN(Min)}}{V_{OUT(Max)} + V_{F(Max)}}
$$
  
where:

 $D_{MAX}$  is the Maximum duty of minimum VIN voltage condition

 $V_{OUT(Max)}$  is the Maximum output voltage

 $V_{F(Max)}$  is the Maximum forward voltage (V<sub>F</sub>) of Secondary diode

Flyback voltage is calculated by below calculation.

$$
V_{OR} = (V_{OUT} + V_F) \times \frac{N_P}{N_S}
$$
 [V]

 $S$  is the set of the state  $N_S$ <br>SW pin voltage calculated below must be set so that the withstand voltage is not exceeded.

$$
V_{SW} = V_{IN(Max)} + V_{OR} + V_{SURGE} \qquad [V]
$$

For example, when it has the delating of 90 % for SW pin voltage, SW pin voltage is needed to be the value which calculated 54 V or less.

$$
V_{SW} = 60 V \times (100\% - 10\%) = 54
$$

 $V_{SW}$  = 60  $V$  × (100 % − 10 %) = 54  $V$ <br>In the case of V<sub>IN(Max)</sub> = 30 V and V<sub>OR</sub> = 10 V, V<sub>SURGE</sub> voltage is needed to be 14 V or less. This value is calculated below.

$$
54 V - (30 V + 10 V) = 14 V
$$

 $54$   $V - (30 V + 10 V) = 14 V$ <br>V $s$ unge is occurred by the leakage of transformer. If V $s$ unge is higher, it needs to decrease the voltage by re-designing transformation structure or snubber circuit adjustment.





 When designed transformer, temporarily set winding ratio to satisfy above. When the winding ratio is decided, RFB can be set and Vout also can be set.

#### **2. Transformer – continued**

#### **2.2 The Calculation of LP, L<sup>S</sup>**

The transformer should be set  $L_P$  and  $L_S$  value that power supply works CCM operation. For that, L<sub>P</sub> and Ls is determined to use "k" which is the indicator of CCM operation. k is expressed from Figure 39 Ispk, IsB by the following equation.

$$
k = (I_{SPK} - I_{SB})/I_{SPK}
$$

where:

where:

 $I_{\mathcal{S}PK}$  is the Secondary transformer peak current

 $I_{SB}$  is the Secondary transformer bottom current

 $\overline{k}\;$  is the Indicator of CCM ratio (It guides that it sets k = 0.25 when designing at first.)



Figure 39. The Waveform Example of Primary and Secondary Current of Transformer

 $I_{PPK}$  is the Primary transformer peak current  $I_{PR}$  is the Primary transformer bottom current

 $I_{LIMIT}$  shown in electric characteristics determines maximum primary peak current. It enables to decide capable secondary minimum peak current from minimum ILIMIT.

$$
I_{SPK1(Min)} = I_{LIMIT(Min)} \times \frac{N_P}{N_S}
$$
 [A]

 $\frac{N_S}{N_S}$ Next, Ispk2(Max) is calculated from secondary maximum output current (lou $_{\text{T(Max)}}$ ).

$$
I_{SPK2(Max)} = \frac{2 \times I_{OUT(Max)}}{(1 - D_{MAX}) \times (2 - k)} \times \frac{1}{\eta}
$$
 [A]

 $\eta$  is the Efficiency of power supply, it recommends to set to about 70 %

In order to output  $I_{\text{OUT(Max)}}$ , the condition of  $I_{\text{SPK2(Max)}}$  <  $I_{\text{SPK1(Min)}}$  must be satisfied.

If not satisfied, re-design to change k value. The higher the k value, the wider the load area of DCM (Discontinuous Conduction Mode) operation. k = 1 means that the operation is DCM at all loads. IC has advantage of fast response and low EMI characteristics in CCM operation. For that, k is recommended lower value. Even if k value is high, there is no problem to output voltage regulation operation.

The secondary inductance  $L_{S(Max)}$  is calculated by the following equation.

$$
L_{S(Max)} = \frac{(2-k) \times (V_{OUT} + V_F) \times (1 - D_{MAX})^2}{2 \times I_{OUT(Max)} \times f_{SW(Max)} \times k}
$$
 [µH]

where:

 $f_{SW(Max)}$  is the Switching frequency (f $_{\text{SW(Max)}}$  is set to 430 kHz in IC)

 $I_{OUT(Max)}$  is the Maximum secondary output current

Primary inductance L<sub>P</sub> is calculated by below.

$$
L_P = L_S \times (\frac{N_P}{N_S})^2
$$
 [µH]

#### **2. Transformer – continued**

#### **2.3 The Calculation of IPRMS and ISRMS**

Maximum primary RMS current (I<sub>PRMS</sub>) and Maximum secondary RMS current (I<sub>SRMS</sub>) are calculated below.

$$
I_{PRMS} = \sqrt{\frac{(I_{PPK}^{2} + I_{PPK} \times I_{PB} + I_{PB}^{2}) \times D_{MAX}}{3}}
$$
 [A]  

$$
I_{SRMS} = \sqrt{\frac{(I_{SPK}^{2} + I_{SPK} \times I_{SB} + I_{SB}^{2}) \times (1 - D_{MAX})}{3}}
$$
 [A]

When selecting the wire diameter of transformer, refer to this RMS current.

#### <span id="page-21-0"></span>**3 Output Capacitor**

The output capacitor place as close to the secondary diode as possible. Output capacitor value  $C_{\text{OUT}}$  is needed to set from the output ripple voltage  $(\Delta V_0)$  and start-up time. The output ripple voltage which occurs by switching is calculated by below equation.

$$
\Delta V_O = \frac{I_{OUT(Max)} \times D_{MAX}}{f_{SW(Max)} \times C_{OUT}}
$$
 [V]

On the other hand, when output capacitor is large, start-up time is long. When SCP detection mask time (t<sub>MASKSCP</sub>) in start-up is passed, if REF voltage is lower than V<sub>SCP</sub>, power supply cannot output. Therefore, Cout must be satisfied below condition.

$$
C_{OUT} \leq \frac{1}{2} \times \frac{t_{MASKSCP(Min)} \times \{ (l_{LIMIT(Min)} \times \frac{N_P}{N_S}) \times (1 - Duty) - l_{OUT(Max)} \}}{V_{OUT} \times (\frac{V_{SCP(Max)}}{V_{INTER(Min)})}}
$$
[µF]  
Here,  $\frac{V_{SCP(Max)}}{V_{UATEEF(Min)}}$ 

$$
r = \frac{1}{V_{INTER}(Min)} = 0
$$

A large output capacitance is required to hold the output voltage for load response or input voltage response. As a guide for output capacitor, it recommends the capacitance of 20 µF or more. And ceramic capacitor may be lower capacitance because of temperature characteristics and variance, DC bias characteristics. It needs to select the parts to care them.

#### <span id="page-21-1"></span>**4 Input Capacitor**

It uses ceramic capacitor to input capacitor and it is placed as close to the IC as possible. The capacitor value is set 10 µF or more.

#### <span id="page-22-0"></span>**5 Secondary Output Diode**

Because the forward voltage  $(V_F)$  of secondary output diode causes an error in the output voltage, it needs to use SBD or FRD which is low forward voltage  $(V_F)$ , and the peak of diode reverse voltage must not exceed the rating of the diode. The secondary RMS current must be set that it does not exceed the rating current. Generally, it is recommended that the reverse voltage of secondary output diode sets to have margin of 30 % or more.

$$
V_R = (V_{IN(Max)} \times \frac{N_S}{N_P} + V_{OUT}) \times 1.3 + V_{SURGE}
$$
 [V]

where:

 $V_R$  is the reverse voltage of secondary output diode

 $V_{IN(Max)}$  is VIN maximum pin voltage

 $N_P$  is the primary winding turns of transformer

 $N_{\cal S}$  is the secondary winding turns of transformer

 $V_{OUT}$  is the Output voltage

 $V_{SURGE}$  is the Surge voltage of transformer generated to the diode

And it is recommended that rating current of output diode margin twice or more for ISRMS.

#### <span id="page-22-1"></span>**6 Output Resistor and Output Zener Diode (Minimum Load Current)**

The output voltage raises in no load or light load. This is the reason IC is always worked by the minimum switching frequency which is determined by maximum OFF time toff max and minimum ON time ton MIN at light loads. Because power supply supplies minimum power  $P_{OMIN}$  by this minimum switching frequency, output voltage raises when secondary power is lighter than Po\_MIN. Po\_MIN is calculated by below.

$$
P_{O\_MIN} = \frac{V_{IN(Max)}^{2}}{2 \times L_P} \times t_{ON\_MIN(Max)}^{2} \times \frac{1}{t_{ON\_MIN(Max)} + t_{OFF\_MAX(Min)}} \quad [W]
$$
  

$$
I_{OUT\_MIN} = \frac{P_{O\_MIN}}{V_{OUT}}
$$
 By the equation,  $I_{OUT\_MIN}$  can be also calculated.

When the raise of secondary output voltage is unacceptable, it needs to connect zener diode to secondary output. It operates output voltage suppression less than zener diode voltage.

And it can prevent to rise output voltage by losses which is occurred to connect resistors to secondary output. The secondary load resistor  $R_{OUT}$  is less than below equation is needed. Secondary resistor loss is calculated by the equation.

$$
P_{LOSS} = \frac{V_{OUT}^2}{R_{OUT}} \quad [W]
$$
  
\n
$$
R_{OUT} \le \frac{V_{OUT}^2}{P_{O\_MIN}} = \frac{V_{OUT}^2}{\frac{V_{IN(Max)}^2}{2 \times L_P} \times t_{ON\_MIN(Max)}^2 \times \frac{1}{t_{ON\_MIN(Max)} + t_{OFF\_MAX(Min)}}}
$$
 [Ω]

In fact, even if R<sub>OUT</sub> resistance which is calculated above equation is used, output voltage rises transiently in switching OFF time. For that, Rout should be set low enough. Rout needs to adjust through evaluation. Rout resistor is needed to notice power dissipation.

The reason of output voltage raise refers to Application Examples: "10.The Influence on Frequency and Output Voltage for Each Load".



Figure 40. Zener Diode and Resistor to Secondary Output

#### <span id="page-23-0"></span>**7 Snubber Circuit**

When the combination degree of transformer is low or large current line of board is long, the large surge voltage may be occurred in the SW pin at turn OFF timing of MOSFET. Preventing it, the snubber circuit shown in figure 41 is used. This snubber circuit clamps fly-back voltage + surge voltage when the voltage exceeds snubber voltage.



The clamp voltage is determined the following equation.

$$
V_{CLAMP} = V_{F2} + V_z
$$
 [V]

where:

 $V_{CLAMP}$  is the Clamp setting voltage of snubber circuit

 $V_{F2}$  is the Forward voltage of SBD

 $V_{Z}$  is the Zener diode voltage

When the clamp setting voltage is lower than flyback voltage ( equal to  $\frac{N_P}{N}$  $\frac{N_P}{N_S}$   $\times$   $(V_{OUT} + V_F)$ ), large current flows to Zener diode in the turn off. Therefore, the snubber voltage (V<sub>CLAMP</sub>) must be higher than flyback voltage. When snubber circuit is slow response, it may not clamp setting voltage. So, SW voltage must be evaluated.

#### <span id="page-23-1"></span>**8 Setting of SDX/EN Pin Resistor**

#### **8.1 Setting of Enable Voltage**

It can set enable voltage  $V_{\text{IN ENABLE}}$  by following equation after releasing VIN UVLO.

$$
V_{IN\_ENABLE} = V_{EN1} \times \frac{R_1 + (R_2 // R_{SDX/EN})}{R_2 / (R_{SDX/EN})}
$$
 [V]

where:

 $V_{IN\ ENABLE}$  is the Target VIN operating start voltage

 $V_{FN1}$  is the Enable voltage 1

 $R_2// R_{SDX/FN}$  is the Divided resistor between R<sub>2</sub> and R<sub>SDX/EN</sub> which is IC internal resistor



Figure 42. Resistors Connected to the SDX/EN Pin

#### **8.2 Setting of disabled Voltage**

It can set disable voltage  $\bar{V}_{IN}$  DISABLE at VIN pin voltage falling by following equation.

$$
V_{IN\_DISABLE} = V_{EN2} \times \frac{R_1 + (R_2 // R_{SDX/EN})}{R_2 // R_{SDX/EN}}
$$
 [V]

where:

 $V_{IN\ DISABLE}$  is the Target VIN operating stop voltage  $V_{EN2}$  is the Enable voltage2

#### <span id="page-24-0"></span>**9 The Output Voltage Compensation Function by L\_COMP Pin Resistor**

This IC is built in output voltage compensation function which is prevented that output voltage decrease when primary transformer peak current (IP) increase. The cause of the drop of output voltage  $V_{\text{OUT}}$  are the forward voltage change of secondary diode and transformer leakage etc.

The example of output voltage compensation is shown in Figure 43.



Figure 43. L\_COMP Voltage Compensation Example

This function compensates the output voltage by increasing IREFCOMP current to the REF current that determines the output voltage.

$$
V_{OUT} = R_{FB} \times \frac{N_S}{N_P} \times \left(\frac{V_{INTER}}{R_{REF}} + I_{REFCOMP}\right) - V_F \quad [V]
$$

REF current  $\frac{V_{INTERF}}{P}$  is fiexed to 200 µA (Typ). I $_{REFORM}$  is increased for primary current increasing. As the result,  $R_{REF}$ output voltage is compensated by output current on the secondary side. IREFCOMP is calculated to below.

$$
I_{REFCOMP} = R_{L\_COMP} \times K_{L\_COMP} \times I_{SW(Ave)} \tag{[µA]}
$$

where:

 $R_{L\ COMP}$  is the Resistor connected to the L\_COMP pin

 $I_{SW(Ave)}$  is the Averaging current flown to the SW pin

 $K_{\text{L COMP}}$  is the Fixed value determined by IC

Averaging current Isw(Ave) of the SW pin can be converted below.

$$
I_{SW(Ave)} = I_{S(Ave)} \times \frac{N_S}{N_P} = I_{OUT} \times \frac{1}{\eta} \times \frac{N_S}{N_P}
$$
 [A]

where:

 $\eta$  is the efficiency (It recommends 70 % in design. And adjust RL\_comp in application evaluation.)

Because  $I_{SW(Ave)}$  is proportional to  $I_{OUT}$  as shown in the above equation, it enables to compensate output voltage. The compensation degree can adjust by resistor value of the L\_COMP pin. Because I<sub>SW</sub> is triangle wave current, connect the capacitor 0.1 µF or more at the L\_COMP pin to flatten it.

The resistor value of the L\_COMP pin is calculated by the following equation.

$$
R_{L\_COMP} = \frac{I_{REFCOMP}}{I_{SW(Ave)}} \times \frac{1}{K_{L\_COMP}}
$$
 [kΩ]

Be sure to evaluate the output voltage characteristics in the application and adjust L\_COMP resistance as necessary. And, if the function is no use, the L\_COMP pin is needed to connect to GND.

#### <span id="page-25-0"></span>**10 The Influence on Frequency and Output Voltage for Each Load**

This IC enables high efficiency to be lower switching frequency in light load. In CCM operation, the switching frequency is fsw for a constant load. When the load is light, the operation is changed from CCM operation to DCM operation. Then, switching frequency is reduced from fsw. The output load  $I<sub>OUT</sub>$  fsw<sub>1</sub> is calculated below.

> $I_{OUT}\,f_{SW1} =$ 1 2 ×  $(V_{IN} \times Duty)^2$  $L_P \times f_{SW} \times V_{OUT}$  $\times \eta$ [A]

where:

 $I_{OUT}$   $f_{SW1}$  is the Switched output current from DCM to CCM

 $f_{SW}$  is the Switching frequency

 $V_{IN}$  is VIN pin voltage

 $L_P$  is the Primary inductance

 $V_{OUT}$  is the Output voltage

 $\eta$  is the Efficiency

As the load is further lightened, the ON time and OFF time decreases. ON time is operated by ton\_MIN. The load current operated by ton MIN is below.

$$
I_{OUT\_f_{SW2}} = \frac{1}{2} \times \frac{f_{SW} \times (V_{IN} \times t_{ON\_MIN})^2}{L_P \times V_{OUT}} \times \eta
$$
 [A]

where:

 $I_{OUT}$   $f_{SW2}$  is the Load current operated by minimum ON time

 $t_{ON~MIN}$  is the Minimum ON time

As the load is further lightened, the ON time is not shorter than the t<sub>ON MIN</sub> and the OFF time is longer. Because IC is determined maximum OFF time, f<sub>SW MIN</sub> is calculated to below.

$$
f_{SW\_MIN} = \frac{1}{t_{ON\_MIN} + t_{OFF\_MAX}} \qquad \text{[kHz]}
$$

where:

 $f_{SW~MIN}$  is the Minimum switching frequency

 $t_{OFF\ MAX}$  is the Maximum OFF time

Therefore, constant output power is generated by fsw MIN operation in no load or light load. For that, output voltage raises in no load or light load.

And the IC builds in frequency spectrum spread function for EMI improvement. For that, the switching frequency is changed within a constant rate. An output voltage ripple which is dependent on spectrum spread occurs by the function.



Figure 44. Switching Frequency

## <span id="page-26-0"></span>**I/O Equivalence Circuits**



## <span id="page-27-0"></span>**Operational Notes**

#### **1. Reverse Connection of Power Supply**

Connecting the power supply in reverse polarity can damage the IC. Take precautions against reverse polarity when connecting the power supply, such as mounting an external diode between the power supply and the IC's power supply pins.

#### **2. Power Supply Lines**

Design the PCB layout pattern to provide low impedance supply lines. Furthermore, connect a capacitor to ground at all power supply pins. Consider the effect of temperature and aging on the capacitance value when using electrolytic capacitors.

## **3. Ground Voltage**

Ensure that no pins are at a voltage below that of the ground pin at any time, even during transient condition.

#### **4. Ground Wiring Pattern**

When using both small-signal and large-current ground traces, the two ground traces should be routed separately but connected to a single ground at the reference point of the application board to avoid fluctuations in the small-signal ground caused by large currents. Also ensure that the ground traces of external components do not cause variations on the ground voltage. The ground lines must be as short and thick as possible to reduce line impedance.

#### **5. Recommended Operating Conditions**

The function and operation of the IC are guaranteed within the range specified by the recommended operating conditions. The characteristic values are guaranteed only under the conditions of each item specified by the electrical characteristics.

#### **6. Inrush Current**

When power is first supplied to the IC, it is possible that the internal logic may be unstable and inrush current may flow instantaneously due to the internal powering sequence and delays, especially if the IC has more than one power supply. Therefore, give special consideration to power coupling capacitance, power wiring, width of ground wiring, and routing of connections.

#### **7. Testing on Application Boards**

When testing the IC on an application board, connecting a capacitor directly to a low-impedance output pin may subject the IC to stress. Always discharge capacitors completely after each process or step. The IC's power supply should always be turned off completely before connecting or removing it from the test setup during the inspection process. To prevent damage from static discharge, ground the IC during assembly and use similar precautions during transport and storage.

#### **8. Inter-pin Short and Mounting Errors**

Ensure that the direction and position are correct when mounting the IC on the PCB. Incorrect mounting may result in damaging the IC. Avoid nearby pins being shorted to each other especially to ground, power supply and output pin. Inter-pin shorts could be due to many reasons such as metal particles, water droplets (in very humid environment) and unintentional solder bridge deposited in between pins during assembly to name a few.

#### **9. Unused Input Pins**

Input pins of an IC are often connected to the gate of a MOS transistor. The gate has extremely high impedance and extremely low capacitance. If left unconnected, the electric field from the outside can easily charge it. The small charge acquired in this way is enough to produce a significant effect on the conduction through the transistor and cause unexpected operation of the IC. So unless otherwise specified, unused input pins should be connected to the power supply or ground line.

## **Operational Notes – continued**

#### **10. Regarding the Input Pin of the IC**

This monolithic IC contains P+ isolation and P substrate layers between adjacent elements in order to keep them isolated. P-N junctions are formed at the intersection of the P layers with the N layers of other elements, creating a parasitic diode or transistor. For example (refer to figure below):

When GND > Pin A and GND > Pin B, the P-N junction operates as a parasitic diode. When GND > Pin B, the P-N junction operates as a parasitic transistor.

Parasitic diodes inevitably occur in the structure of the IC. The operation of parasitic diodes can result in mutual interference among circuits, operational faults, or physical damage. Therefore, conditions that cause these diodes to operate, such as applying a voltage lower than the GND voltage to an input pin (and thus to the P substrate) should be avoided.



Figure 45. Example of Monolithic IC Structure

#### **11. Ceramic Capacitor**

When using a ceramic capacitor, determine a capacitance value considering the change of capacitance with temperature and the decrease in nominal capacitance due to DC bias and others.

#### **12. Thermal Shutdown Circuit (TSD)**

This IC has a built-in thermal shutdown circuit that prevents heat damage to the IC. Normal operation should always be within the IC's maximum junction temperature rating. If however the rating is exceeded for a continued period, the junction temperature (Tj) will rise which will activate the TSD circuit that will turn OFF power output pins. When the Tj falls below the TSD threshold, the circuits are automatically restored to normal operation.

Note that the TSD circuit operates in a situation that exceeds the absolute maximum ratings and therefore, under no circumstances, should the TSD circuit be used in a set design or for any purpose other than protecting the IC from heat damage.

## **13. Over Current Protection Circuit (OCP)**

This IC incorporates an integrated overcurrent protection circuit that is activated when the load is shorted. This protection circuit is effective in preventing damage due to sudden and unexpected incidents. However, the IC should not be used in applications characterized by continuous operation or transitioning of the protection circuit.

## <span id="page-29-0"></span>**Ordering Information**



## <span id="page-29-1"></span>**Marking Diagram**



## **Datasheet**

<span id="page-30-0"></span>



Reel

## <span id="page-31-0"></span>**Revision History**



## **Notice**

#### **Precaution on using ROHM Products**

1. If you intend to use our Products in devices requiring extremely high reliability (such as medical equipment  $(Note 1)$ , aircraft/spacecraft, nuclear power controllers, etc.) and whose malfunction or failure may cause loss of human life, bodily injury or serious damage to property ("Specific Applications"), please consult with the ROHM sales representative in advance. Unless otherwise agreed in writing by ROHM in advance, ROHM shall not be in any way responsible or liable for any damages, expenses or losses incurred by you or third parties arising from the use of any ROHM's Products for Specific Applications.





2. ROHM designs and manufactures its Products subject to strict quality control system. However, semiconductor products can fail or malfunction at a certain rate. Please be sure to implement, at your own responsibilities, adequate safety measures including but not limited to fail-safe design against the physical injury, damage to any property, which a failure or malfunction of our Products may cause. The following are examples of safety measures:

[a] Installation of protection circuits or other protective devices to improve system safety

[b] Installation of redundant circuits to reduce the impact of single or multiple circuit failure

- 3. Our Products are not designed under any special or extraordinary environments or conditions, as exemplified below. Accordingly, ROHM shall not be in any way responsible or liable for any damages, expenses or losses arising from the use of any ROHM's Products under any special or extraordinary environments or conditions. If you intend to use our Products under any special or extraordinary environments or conditions (as exemplified below), your independent verification and confirmation of product performance, reliability, etc, prior to use, must be necessary:
	- [a] Use of our Products in any types of liquid, including water, oils, chemicals, and organic solvents
	- [b] Use of our Products outdoors or in places where the Products are exposed to direct sunlight or dust
	- [c] Use of our Products in places where the Products are exposed to sea wind or corrosive gases, including Cl2, H2S, NH3, SO2, and NO2
	- [d] Use of our Products in places where the Products are exposed to static electricity or electromagnetic waves
	- [e] Use of our Products in proximity to heat-producing components, plastic cords, or other flammable items
	- [f] Sealing or coating our Products with resin or other coating materials
	- [g] Use of our Products without cleaning residue of flux (Exclude cases where no-clean type fluxes is used. However, recommend sufficiently about the residue.); or Washing our Products by using water or water-soluble cleaning agents for cleaning residue after soldering
	- [h] Use of the Products in places subject to dew condensation
- 4. The Products are not subject to radiation-proof design.
- 5. Please verify and confirm characteristics of the final or mounted products in using the Products.
- 6. In particular, if a transient load (a large amount of load applied in a short period of time, such as pulse, is applied, confirmation of performance characteristics after on-board mounting is strongly recommended. Avoid applying power exceeding normal rated power; exceeding the power rating under steady-state loading condition may negatively affect product performance and reliability.
- 7. De-rate Power Dissipation depending on ambient temperature. When used in sealed area, confirm that it is the use in the range that does not exceed the maximum junction temperature.
- 8. Confirm that operation temperature is within the specified range described in the product specification.
- 9. ROHM shall not be in any way responsible or liable for failure induced under deviant condition from what is defined in this document.

#### **Precaution for Mounting / Circuit board design**

- 1. When a highly active halogenous (chlorine, bromine, etc.) flux is used, the residue of flux may negatively affect product performance and reliability.
- 2. In principle, the reflow soldering method must be used on a surface-mount products, the flow soldering method must be used on a through hole mount products. If the flow soldering method is preferred on a surface-mount products, please consult with the ROHM representative in advance.

For details, please refer to ROHM Mounting specification

#### **Precautions Regarding Application Examples and External Circuits**

- 1. If change is made to the constant of an external circuit, please allow a sufficient margin considering variations of the characteristics of the Products and external components, including transient characteristics, as well as static characteristics.
- 2. You agree that application notes, reference designs, and associated data and information contained in this document are presented only as guidance for Products use. Therefore, in case you use such information, you are solely responsible for it and you must exercise your own independent verification and judgment in the use of such information contained in this document. ROHM shall not be in any way responsible or liable for any damages, expenses or losses incurred by you or third parties arising from the use of such information.

#### **Precaution for Electrostatic**

This Product is electrostatic sensitive product, which may be damaged due to electrostatic discharge. Please take proper caution in your manufacturing process and storage so that voltage exceeding the Products maximum rating will not be applied to Products. Please take special care under dry condition (e.g. Grounding of human body / equipment / solder iron, isolation from charged objects, setting of Ionizer, friction prevention and temperature / humidity control).

#### **Precaution for Storage / Transportation**

- 1. Product performance and soldered connections may deteriorate if the Products are stored in the places where:
	- [a] the Products are exposed to sea winds or corrosive gases, including Cl<sub>2</sub>, H<sub>2</sub>S, NH<sub>3</sub>, SO<sub>2</sub>, and NO<sub>2</sub>
	- [b] the temperature or humidity exceeds those recommended by ROHM
	- [c] the Products are exposed to direct sunshine or condensation
	- [d] the Products are exposed to high Electrostatic
- 2. Even under ROHM recommended storage condition, solderability of products out of recommended storage time period may be degraded. It is strongly recommended to confirm solderability before using Products of which storage time is exceeding the recommended storage time period.
- 3. Store / transport cartons in the correct direction, which is indicated on a carton with a symbol. Otherwise bent leads may occur due to excessive stress applied when dropping of a carton.
- 4. Use Products within the specified time after opening a humidity barrier bag. Baking is required before using Products of which storage time is exceeding the recommended storage time period.

#### **Precaution for Product Label**

A two-dimensional barcode printed on ROHM Products label is for ROHM's internal use only.

#### **Precaution for Disposition**

When disposing Products please dispose them properly using an authorized industry waste company.

#### **Precaution for Foreign Exchange and Foreign Trade act**

Since concerned goods might be fallen under listed items of export control prescribed by Foreign exchange and Foreign trade act, please consult with ROHM in case of export.

#### **Precaution Regarding Intellectual Property Rights**

- 1. All information and data including but not limited to application example contained in this document is for reference only. ROHM does not warrant that foregoing information or data will not infringe any intellectual property rights or any other rights of any third party regarding such information or data.
- 2. ROHM shall not have any obligations where the claims, actions or demands arising from the combination of the Products with other articles such as components, circuits, systems or external equipment (including software).
- 3. No license, expressly or implied, is granted hereby under any intellectual property rights or other rights of ROHM or any third parties with respect to the Products or the information contained in this document. Provided, however, that ROHM will not assert its intellectual property rights or other rights against you or your customers to the extent necessary to manufacture or sell products containing the Products, subject to the terms and conditions herein.

#### **Other Precaution**

- 1. This document may not be reprinted or reproduced, in whole or in part, without prior written consent of ROHM.
- 2. The Products may not be disassembled, converted, modified, reproduced or otherwise changed without prior written consent of ROHM.
- 3. In no event shall you use in any way whatsoever the Products and the related technical information contained in the Products or this document for any military purposes, including but not limited to, the development of mass-destruction weapons.
- 4. The proper names of companies or products described in this document are trademarks or registered trademarks of ROHM, its affiliated companies or third parties.

## **General Precaution**

- 1. Before you use our Products, you are requested to carefully read this document and fully understand its contents. ROHM shall not be in any way responsible or liable for failure, malfunction or accident arising from the use of any ROHM's Products against warning, caution or note contained in this document.
- 2. All information contained in this document is current as of the issuing date and subject to change without any prior notice. Before purchasing or using ROHM's Products, please confirm the latest information with a ROHM sales representative.
- 3. The information contained in this document is provided on an "as is" basis and ROHM does not warrant that all information contained in this document is accurate and/or error-free. ROHM shall not be in any way responsible or liable for any damages, expenses or losses incurred by you or third parties resulting from inaccuracy or errors of or concerning such information.