TI CC3000 BoosterPack Evaluation Module Board

User's Guide



Literature Number: SWRU331A November 2012-Revised August 2014



Contents

Pref	reface				
Revi					
1	Intro	duction	6		
2	CC3	00 BoosterPack EVM Board	7		
	2.1	BoosterPack EVM Board Top View	7		
	2.2	CC3000 BoosterPack EVM Board Bottom View	9		
	2.3	Antenna1	0		
	2.4	Hardware Setup			
	2.5	CC3000 BoosterPack Schematic	4		
	2.6	Bill of Materials (BOM)			
		2.6.1 PCB Design Guidelines			
		2.6.2 RF Trace			
		2.6.3 Antenna			
		2.6.4 Power Trace	7		
		2.6.5 Ground			
3	App	cation Development 1	8		

2



www.ti.com

List of Figures

2-1.	BoosterPack EVM Board (Top View)	7
2-2.	CC3000 BoosterPack EVM Board (Bottom View)	9
2-3.	Antenna Location and RF Trace Routing	10
2-4.	Matching Circuit Between the Antenna and the CC3000 BoosterPack EVM Board	11
2-5.	Return Loss From the ACX Antenna and Matching Circuit	11
2-6.	Antenna Radiation Pattern	12
2-7.	Host PCB Mating Connector Arrangement	13
2-8.	CC3000 BoosterPack Schematics	14
2-9.	Trace Design for PCB Layout	15
2-10.	Antenna Layout Guidelines	16
2-11.	Power Trace	17
2-12.	Ground Routing for the CC3000 BoosterPack EVM Board	17
3-1.	MSP-EXP430G2 Test Platform and CC3000 BoosterPack EVM Board	18
	List of Tables	
2-1.	Key Parts of CC3000 BoosterPack EVM Board Top View	7
2-2.	J2 Configuration of the CC3000 EVM Board	
2-3.	Header J11 of the CC3000 BoosterPack EVM Board Top View	8
2-4.	Header J12 of the CC3000 BoosterPack EVM Board Top View	8
2-5.	Header J9 of the CC3000 BoosterPack EVM Board (Bottom View)	9
2-6.	Header J10 of the CC3000 BoosterPack EVM Board (Bottom View)	10
2-7.	LaunchPad to BoosterPack Pin Comparison	13
2-8.	PCB Stack-Up Data	15
2-9.	Trace Design Measurement Values	16



Read This First

About This Manual

This user guide describes how to use the TI CC3000 BoosterPack evaluation module (EVM) board to evaluate the performance of the TI CC3000 module.

Related Documentation From Texas Instruments

- TI SimpleLink™ CC3000 Module Wi-Fi 802.11b/g Network Processor Data Sheet (SWRS126)
- CC3000 wiki

If You Need Assistance

The primary sources of CC3000 information are the device-specific data sheets and user's guides. For the most up-to-date version of the user's guide and data sheets, see the CC3000 module product page.

FCC Warning

This equipment is intended for use in a laboratory test environment only. It generates, uses, and can radiate radio frequency energy and has not been tested for compliance with the limits of computing devices pursuant to subpart J of part 15 of FCC rules, which are designed to provide reasonable protection against radio frequency interference. Operation of this equipment in other environments may cause interference with radio communications, in which case the user at his own expense will be required to take whatever measures may be required to correct this interference.



www.ti.com Revision History

Revision History

CI	Changes from Original (November 2012) to A Revision			
•	Changed wiki title in Related Documentation From Texas Instruments	4		
•	Changed link name in If You Need Assistance	4		
•	Changed wiki title in Table 2-2	8		
•	Changed typo in Table 2-6: name for pin 7 changed from WL_SPI_CLK, pin type changed from input, and description changed from clock input			
•	Changed wiki title in Chapter 3	18		
•	Changed link name in Chapter 3	18		

NOTE: Page numbers for previous revisions may differ from page numbers in the current version.



Introduction

This user's guide describes how to use the TI CC3000 BoosterPack EVM board to evaluate the performance and functionality of the TI CC3000 module. The TI CC3000 module is a self-contained Wi-Fi® solution that enables Internet connectivity for a wide variety of embedded applications. This document details the key parts and features of the CC3000 BoosterPack EVM board along with the different options available for the user and includes layout guidelines to assist in PCB development.



CC3000 BoosterPack EVM Board

2.1 BoosterPack EVM Board Top View

Figure 2-1 shows the top view of the CC3000 BoosterPack EVM board.




Figure 2-1. BoosterPack EVM Board (Top View)

Table 2-1 describes the key parts and jumpers mounted on top of the CC3000 BoosterPack EVM board.

Table 2-1. Key Parts of CC3000 BoosterPack EVM Board Top View

Part Name	Description
CC3000MOD	Core module for performance evaluation. For more information, see the CC3000 module datasheet (SWRS126).
Antenna	Can be used for radiated testing by reworking the capacitor to correct pads
J1	U.FL RF connector used for conductive power tests
J2	Used to swap between test mode and operation mode. When pins 2 and 3 are shorted, J2 runs in operation mode. When pins 1 and 2 are shorted, J2 runs in test mode.
J11	Through-hole test points (for more information, see Table 2-3)
J12	Through-hole test points (for more information, see Table 2-4)
J13	Used to switch between external power and power from the motherboard. Can be used for power measurements. Connect pins 1 and 2 for power from the LaunchPad flash programmer and debugging tool. Connect pins 2 and 3 for external power.
J14	DC jack for external power supply. If power is not supplied from the motherboard, ensure that external power is applied.



Table 2-2 describes the J2 configuration of the CC3000 EVM board.

Table 2-2. J2 Configuration of the CC3000 EVM Board

Mode	Description
Test mode: CC3000 radio tool ⁽¹⁾	Connect pins 1 and 2. Test mode is used with the CC3000 radio tool to operate, test, and calibrate the CC3000 chipset designs during development. This tool uses the RS232/UART pins to run radio frequency (RF) RX and TX tests on the CC3000 module. For more information, see the CC3000 wiki.
Functional mode: Normal mode	Connect pins 2 and 3. Normal mode is for regular functionality between the host platform and the CC3000 module.

⁽¹⁾ For more information about test software for the PC, see the CC3000 wiki.

Table 2-3 describes the signals on J11.

Table 2-3. Header J11 of the CC3000 BoosterPack EVM Board Top View

Pin	Pin Name	Pin Type	Descriptions
1	Reserved	_	Reserved
2	Reserved	_	Reserved
3	WL_RS232_TX	Output	RS232 transmit output; used for radio tool serial interface in test mode. Leave floating in functional mode.
4	WL_RS232_RX	Input	RS232 receive output; used for radio tool serial interface in test mode. Leave floating in functional mode.

Table 2-4 describes the signals on J12.

Table 2-4. Header J12 of the CC3000 BoosterPack EVM Board Top View

Pin	Pin Name	Pin Type	Descriptions
1	GND	_	Ground
2	SCL_CC3000	Output	$\mbox{\sc l}^2\mbox{\sc C}$ clock signal output from the CC3000 module. This pin is connected to SCL_EEPROM through a 0- Ω resistor and is not used by end users.
3	SCL_EEPROM	Input	l ² C clock signal input from EEPROM inside the CC3000 module. This pin is connected to SCL_CC3000 using a 0 - Ω resistor and is not used by end users.
4	SDA_CC3000	Input and output	I ² C data signal from the CC3000 module. This pin is connected to SDA_EEPROM using a 0-Ω resistor and is not used by end users.
5	SDA_EEPROM	Input and output	I ² C data signal from EEPROM inside the CC3000 module. This pin is connected to SDA_CC3000 using a 0- Ω resistor and is not used by end users.



2.2 CC3000 BoosterPack EVM Board Bottom View

The two BoosterPack mating connectors (J9 and J10) connect to the host platform and mount to the bottom of the BoosterPack EVM board, as shown in Figure 2-2.




Figure 2-2. CC3000 BoosterPack EVM Board (Bottom View)

Table 2-5 describes the signals on J9.

Table 2-5. Header J9 of the CC3000 BoosterPack EVM Board (Bottom View)

Pin	Pin Name	Pin Type	Descriptions
1	VBAT_IN	Power In	Battery voltage input to module. For the MSP430 host platform, VIO_HOST = VBAT_IN. For other platforms that have different voltage levels from the battery voltages, R14 can be removed.
2	VBAT_SW_EN	Input	Active-high enables signal from the host device
3	Reserved	_	Reserved
4	Reserved	_	Reserved
5	Reserved	_	Reserved
6	Reserved	_	Reserved
7	WL_SPI_CLK	Input	Host interface SPI clock input
8	Reserved	_	Reserved
9	Reserved	_	Reserved
10	Reserved	_	Reserved



Antenna www.ti.com

Table 2-6 describes the signals on J10.

Table 2-6. Header J10 of the CC3000 BoosterPack EVM Board (Bottom View)

Pin	Pin Name	Pin Type	Descriptions
1	GND	_	Ground
2	WL_SPI_IRQ	Output	Host interface SPI interrupt request
3	WL_SPI_CS	Input	Host interface SPI chip select
4	Reserved	-	Reserved
5	Reserved	_	Reserved
6	WL_SPI_DIN	Input	Host interface SPI data input
7	WL_SPI_DOUT	Output	Host interface SPI data output
8	Reserved	-	Reserved
9	Reserved	_	Reserved
10	Reserved	-	Reserved

2.3 Antenna

The ACX ceramic mounts on the BoosterPack EVM board with a specific layout and matching circuit for the radiation tests conducted in FCC, CE, and IC certifications. Figure 2-3 shows the location of the ACX ceramic antenna on the BoosterPack EVM board and the RF trace routing from the CC3000 module to the antenna.

AT8010-E2R9HAA




Figure 2-3. Antenna Location and RF Trace Routing



www.ti.com Antenna

Figure 2-4 shows the matching circuit between the antenna and the BoosterPack EVM board.




Figure 2-4. Matching Circuit Between the Antenna and the CC3000 BoosterPack EVM Board

The return loss is based on the matching circuit and RF trace routing, as shown in Figure 2-5.




Figure 2-5. Return Loss From the ACX Antenna and Matching Circuit



Antenna www.ti.com

Figure 2-6 shows the antenna radiation pattern.




Figure 2-6. Antenna Radiation Pattern



Hardware Setup www.ti.com

2.4 **Hardware Setup**

To conduct performance tests, connect the BoosterPack EVM board to the host platform using the J9 and J10 mating connectors or the J11 and J12 single-row headers. The J9 and J10 mating connectors must line up as shown in Figure 2-7. The J11 and J12 single-row headers require the signals from the EVM board mating connectors to be wired to the host platform.




Figure 2-7. Host PCB Mating Connector Arrangement

Table 2-7 compares the pins of the LaunchPad MSP-EXP430G2 board with the CC3000 BoosterPack EVM board.

Table 2-7. LaunchPad to BoosterPack Pin Comparison

Pin	MSP430 Port	CC3000 BoosterPack	
1	VCC	VBAT_IN	
2	P1.0	VBAT_SW_EN	
3	P1.1/TX	NC	
4	1.2/RX	NC	
5	P1.3	NC	
6	P1.4	NC	
7	P1.5	WL_SPI_CLK	
8	P2.0	NC	
9	P2.1	NC	
10	P2.2	NC	
11	P2.3	NC	
12	P2.4	NC	
13	P2.5	NC	
14	P1.6	WL_SPI_DOUT	
15	P1.7	WL_SPI_DIN	
16	T/SBWT	NC	
17	T/SBW	NC	
18	2.6/XOUT	WL_SPI_CS	
19	P2.7/XIN	WL_SPI_IRQ	
20	GND	GND	



2.5 CC3000 BoosterPack Schematic

Figure 2-8 shows the CC3000 BoosterPack schematics.




Figure 2-8. CC3000 BoosterPack Schematics



www.ti.com Bill of Materials (BOM)

2.6 **Bill of Materials (BOM)**

2.6.1 PCB Design Guidelines

The recommendations in this document are based on a two-layer PCB with the CC3000 module. The PCB is built using standard FR4 material. Both layers are used for signal routing. TI recommends keeping the traces of the SPI signals as short as possible. Table 2-8 shows the PCB stack-up data.

	PCB S		Imped	ance	
Layer	Туре	Thickness		Single end	Theory value
	Top side solder mask		0.50 mil		
L1	Тор	copper + plating	1.82 mil	Trace 20 space 5, 50 Ω ±10%	47.57
		Prepreg	52.20 mil	mil	
L2		copper + plating	1.82 mil	mil	
	Bottom side solder mask				
TOTAL			56.84 mil		
			1.44 mm		

Table 2-8. PCB Stack-Up Data

2.6.2 RF Trace

Figure 2-9 shows a $50-\Omega$ trace design recommended for the PCB layout.




Figure 2-9. Trace Design for PCB Layout

SWRU331-009

15



Bill of Materials (BOM) www.ti.com

Table 2-9 lists the values associated with the trace design, including the measurements referenced in Figure 2-9.

Table 2-9. Trace Design Measurement Values

Measurement	Length
H (height between L1 and L2)	52.2 mil
H1 (height 1)	0.5 mil
W (width)	19 mil
W1 (width 1)	20 mil
T (thickness)	1.82 mil
S (grid separation)	5 mil
ɛr (dielectric)	4.3
Zo (impedance)	47.57

2.6.3 Antenna

Figure 2-10 shows the specified guidelines for the BoosterPack antenna.

NOTE: The antenna vendor determines the antenna guidelines.




Figure 2-10. Antenna Layout Guidelines



www.ti.com Bill of Materials (BOM)

2.6.4 Power Trace

Figure 2-11 shows the power trace for VBAT_IN highlighted in white.

NOTE: VBAT_IN must have a thickness of 24 mil or more.




Figure 2-11. Power Trace

2.6.5 Ground

The PCB must have a strong ground with more ground vias under the module for system stability and thermal dissipation. Ground vias must be close to the pad.

Figure 2-12 shows the ground routing for the CC3000 BoosterPack EVM board.




Figure 2-12. Ground Routing for the CC3000 BoosterPack EVM Board



Application Development

TI supports the CC3000 BoosterPack paired with the TI MSP-EXP430G2 Launchpad, a microcontroller (MCU) test platform.

The CC3000 BoosterPack lets users easily develop a complete Wi-Fi solution paired with the MSP-EXP430G2 Launchpad platform.

For example applications, see the CC3000 wiki.

The CC3000 BoosterPack also can be used on other platforms with the same connector interface. The TI wiki also has a host driver porting guide to assist with porting to other platforms.

Figure 3-1 shows the Launchpad MSP-EXP430G2 test platform and the CC3000 BoosterPack EVM board.




Figure 3-1. MSP-EXP430G2 Test Platform and CC3000 BoosterPack EVM Board

To order the MSP-EXP430G2 test platform, see the MSP430 LaunchPad Value Line Development Kit.

IMPORTANT NOTICE

Texas Instruments Incorporated and its subsidiaries (TI) reserve the right to make corrections, enhancements, improvements and other changes to its semiconductor products and services per JESD46, latest issue, and to discontinue any product or service per JESD48, latest issue. Buyers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All semiconductor products (also referred to herein as "components") are sold subject to TI's terms and conditions of sale supplied at the time of order acknowledgment.

TI warrants performance of its components to the specifications applicable at the time of sale, in accordance with the warranty in TI's terms and conditions of sale of semiconductor products. Testing and other quality control techniques are used to the extent TI deems necessary to support this warranty. Except where mandated by applicable law, testing of all parameters of each component is not necessarily performed.

TI assumes no liability for applications assistance or the design of Buyers' products. Buyers are responsible for their products and applications using TI components. To minimize the risks associated with Buyers' products and applications, Buyers should provide adequate design and operating safeguards.

TI does not warrant or represent that any license, either express or implied, is granted under any patent right, copyright, mask work right, or other intellectual property right relating to any combination, machine, or process in which TI components or services are used. Information published by TI regarding third-party products or services does not constitute a license to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

Reproduction of significant portions of TI information in TI data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations, and notices. TI is not responsible or liable for such altered documentation. Information of third parties may be subject to additional restrictions.

Resale of TI components or services with statements different from or beyond the parameters stated by TI for that component or service voids all express and any implied warranties for the associated TI component or service and is an unfair and deceptive business practice. TI is not responsible or liable for any such statements.

Buyer acknowledges and agrees that it is solely responsible for compliance with all legal, regulatory and safety-related requirements concerning its products, and any use of TI components in its applications, notwithstanding any applications-related information or support that may be provided by TI. Buyer represents and agrees that it has all the necessary expertise to create and implement safeguards which anticipate dangerous consequences of failures, monitor failures and their consequences, lessen the likelihood of failures that might cause harm and take appropriate remedial actions. Buyer will fully indemnify TI and its representatives against any damages arising out of the use of any TI components in safety-critical applications.

In some cases, TI components may be promoted specifically to facilitate safety-related applications. With such components, TI's goal is to help enable customers to design and create their own end-product solutions that meet applicable functional safety standards and requirements. Nonetheless, such components are subject to these terms.

No TI components are authorized for use in FDA Class III (or similar life-critical medical equipment) unless authorized officers of the parties have executed a special agreement specifically governing such use.

Only those TI components which TI has specifically designated as military grade or "enhanced plastic" are designed and intended for use in military/aerospace applications or environments. Buyer acknowledges and agrees that any military or aerospace use of TI components which have *not* been so designated is solely at the Buyer's risk, and that Buyer is solely responsible for compliance with all legal and regulatory requirements in connection with such use.

TI has specifically designated certain components as meeting ISO/TS16949 requirements, mainly for automotive use. In any case of use of non-designated products, TI will not be responsible for any failure to meet ISO/TS16949.

Products Applications

Audio www.ti.com/audio Automotive and Transportation www.ti.com/automotive **Amplifiers** amplifier.ti.com Communications and Telecom www.ti.com/communications **Data Converters** dataconverter.ti.com Computers and Peripherals www.ti.com/computers **DLP® Products** www.dlp.com Consumer Electronics www.ti.com/consumer-apps DSP dsp.ti.com **Energy and Lighting** www.ti.com/energy Clocks and Timers www.ti.com/clocks Industrial www.ti.com/industrial Interface interface.ti.com Medical www.ti.com/medical Logic Security www.ti.com/security logic.ti.com

Power Mgmt power.ti.com Space, Avionics and Defense www.ti.com/space-avionics-defense

Microcontrollers <u>microcontroller.ti.com</u> Video and Imaging <u>www.ti.com/video</u>

RFID www.ti-rfid.com

OMAP Applications Processors www.ti.com/omap TI E2E Community e2e.ti.com

Wireless Connectivity www.ti.com/wirelessconnectivity