

For Gas Head-separated Dual Display Digital Pressure Sensor DPC-100 SERIES DPH-100 SERIES



Head-separated Dual Display Digital Pressure Sensor For Gas

DPC-100 SERIES DPH-100 SERIES



Single axis type Direct installation using a hexagonal wrench

Breakthrough construction

Obstructions can be avoided and installation from above can be done much more easily using a hexagonal wrench. This also eliminates wasted installation space and contributes to a smaller installation footprint.



Large space needed to turn the spanner!

Conventional models



Embedded installation greatly increases design flexibility!

Quick maintenance

During maintenance, the sensor head needed to be removed can be easily removed from directly above.

Spanner does not fit! It cannot be turned either!



DPH-100 **Remove and install** the required sensor head directly.

.....

Easy to knock

against objects.



Flexible design! Sensor heads can be embedded New concept

Because the bolts can be turned from directly above,

embedding the sensor heads into narrow spaces is

2

To remove (3), you have to remove the sensors in order starting from (1).

APPLICATIONS

Confirming vacuum breakdown



Mounting space-saving

Space saving during installation

Confirming reference pressure





Easy adjustment

Sensor heads can be turned after installation



Because the dead zone caused by the nut is eliminated, the narrowed-down thickness after installation contributes to space saving.



After installation, you can alter the cable direction with the pressure port still secured in place. In addition, the cable does not get twisted during installation.

Independent use of sensor head possible

Separate analog voltage output for each sensor head



The analog voltage output from the sensor head can be picked up directly.





Reduced tact time. Response time contributes to even greater productivity.



Response time at 500 µs

The controller's setting operation mode has a 3-level configuration to suit the frequency of use

The setting levels are clearly separated into "RUN mode" for operation settings that are carried out daily, "MENU SETTING mode" for basic settings, and "PRO mode" for special and detailed setting. These make setting operations easy to understand and easy to carry out.



RUN mode



Settings such as threshold value adjustment and key lock operation can be carried out while the sensor is operating.

MENU SETTING mode



Basic settings such as output mode setting and NO/NC switching can be carried out.

PRO mode



High-level function settings such as hysteresis adjustment and the copy function can be carried out.

3-color display lets you view the controller status at a glance

The main display color switches between green and red in accordance with the ON/OFF status of output during RUN mode. In addition, the display always appears orange while setting is in progress, so that the status of the controller can be viewed at a glance.



Copy function reduces man-hours and human error

Controllers can be connected to a master controller one by one, and a copy of the setting details for the master controller can be transmitted as data to the slave controllers. If making the same settings for multiple controllers, this prevents setting errors from occurring with the other controllers and also reduces the number of changes required to instruction manuals when equipment designs are changed.



Sensor head auto-recognition

The controller will automatically recognize sensor heads when they are connected, even for sensor heads with different rated pressure ranges. There is no need to use the controller to change settings.



1 model to suit a wide variety of applications

DPC-100 original functions



Equipped with independent two output and three output modes

Equipped with two independent comparative outputs, and separate sensing modes can be selected for each of them. Two comparative outputs are provided, so that one of the outputs can be used as a warning output. In addition, if an output is not being used, it can be disabled.



Equipped with auto-reference/remote zero-adjustment functions, More precise pressure management is possible with a minimum of effort

If the reference pressure of the device changes, the auto-Without auto-reference and remote zero-adjustment functions reference function partially shift the comparative output Comparative output: Window comparator mode judgment level by the amount that the reference pressure Hi-1…30, Lo-1…25 shifts, and the remote zero-adjustment function can Fixed set value reset the display value to zero via external input. These 40 functions are ideal for places where the reference pressure NG? fluctuates wildly, or where fine settings are desired. 30 Leak threshold level OK 25 20 NG? 15 Variation in the filling pressure Trial 1 rial : Trial 3 Pressure 0 Time decisions With remote zero-adjustment function applied With auto-reference function applied Comparative output: Window comparator mode Comparative output: Window comparator mode Hi-1…0, Lo-1…—5 Hi-1...0, Lo-1...-5 Sets the absolute threshold level Sets the absolute threshold leve Remote zero-adjustment input The display is forced to "0", and only the Auto-reference in The display remains at "30" and only the threshold level is changed. filling pressure drop range is displayed. 30 30 0 25 OK 25 -5 OK 20 20 Threshold level after applying auto-reference input Threshold level after applying emote zero-adjustment inpu 15 15 Threshold level before applying Threshold level before applying remote zero-adjustment input uto-reference input Trial 1 Trial 1 Pressure C Pressure C Displayed when remote zero Auto-reference input value -5 -5 adjustment input is applied-Time Time

When auto-reference input is applied, the reference pressure "30" is added to the threshold level. If the reference pressure changes to "20" or "40", the auto-reference input compensates for this every time by changing the threshold level, so any variation in the filling pressure can be ignored.



Because the threshold level is fixed for conventional pressure sensors, changes in the reference pressure result in wrong



When remote zero-adjustment input is applied, the reference pressure is forced to "0"

If the reference pressure changes to "20" or "40", the remote zero-adjustment input adjusts the reference pressure to "0" every time the reference pressure changes, so any variation in the filling pressure can be ignored.

The sub display can be set to indicate any other desired values or letters apart from the threshold value. This eliminates the need for tasks such as affixing a label to the device to indicate the normal pressure value.



Setting details can be understood at a glance

The **DPC-100** setting details appear in the digital display. Because the settings are in numeric form that can be easily understood, it is useful for times such as when receiving technical support by telephone.



Tight installation to panels is possible

An exclusive mounting bracket (MS-DP1-2) that is suitable for 1 to 6 mm 0.039 to 0.236 in panel thickness is available.

An exclusive mounting bracket (MS-DP1-6) that supports tight installation is available

Space saving can also be obtained if an L-shaped mounting bracket is used.





mounting

Power supply cable can be connected with one-touch connection



* Options: 5 m 16.404 ft type is also available.

Types without connector attached DPC-10□-J cable are also available

Commercially-available connectors can be used for cable connections. Only the required length of cable needs to be used, which contributes to a reduced amount of wastage for unneeded cable.



* Refer to p.9 for recommended commercially-available connectors.



PRODUCT CONFIGURATION



ORDER GUIDE

Sensor heads

Туре	Type Appearance		Model No.	Pressure port	Applicable fluid
		–100.0 to +100.0 kPa	DPH-101	R1/8 male thread + M5 female thread	
Compound pressure			DPH-101-M3	M3 male thread	
	DPH-10□-M3(-R)		DPH-101-M5	M5 male thread	
Bending-	OW		DPH-101-R	R1/8 male thread + M5 female thread	
resistant			DPH-101-M3-R	M3 male thread	
cable			DPH-101-M5-R	M5 male thread	
Desitive reserves	DPH-10□-M5(-R)	0 to +1.000 MPa	DPH-102 (Note)	R1/8 male thread + M5 female thread	
Positive pressure			DPH-102-M5	M5 male thread	Air, non-corrosive gas
Bending- resistant cable			DPH-102-M5-R	M5 male thread	lien concerte gue
	DPH-10□(-R)		DPH-103	R1/8 male thread + M5 female thread	
Vacuum pressure			DPH-103-M3	M3 male thread	
			DPH-103-M5	M5 male thread	
Ronding		0 to –101.0 kPa	DPH-103-R	R1/8 male thread + M5 female thread	
resistant			DPH-103-M3-R	M3 male thread	
cable			DPH-103-M5-R	M5 male thread	

Note: The bending-resistant cable type of DPH-102 is not available.

5 m 16.404 ft cable length type

5 m 16.404 ft cable length type (standard: 2 m 6.562 ft) is also available. When ordering this type, suffix"-**C5**" to the Model No. (e.g.) 5 m 16.404 ft cable length type of **DPH-103-M5-R** is "**DPH-103-M5-R-C5**"

Controllers

Appearance	Rated pressure range	Model No.	Comparative output
235 = 550	Compound pressure: -100.0 to +100.0 kPa	DPC-101	NPN open-collector transistor
* CN-66A-C2 (Connector attached cable 2 m 6.562 ft) is attached.	Vacuum pressure: 0 to –101.0 kPa	DPC-101-P	PNP open-collector transistor

Type without connector attached cable

Type without connector attached cable **CN-66A-C2** is available. When ordering this type, suffix "-**J**" to the Model No. (e.g) Type without connector attached cable of **DPC-101-P** is "**DPC-101-P-J**"

Accessory

CN-66A-C2 (Connector attached cable 2 m 6.562 ft)



OPTIONS

Designation	Model No.	Description			
Sensor head connector (e-CON)	CN-EP2 (Note 1) 5 pcs. per set	Connector for connecting sensor head controller			
Connector	CN-66A-C2 (Note 2)	Length 2 m 6.562 ft	Controller power supply / I-O cable. 0.2 mm^2 6-core oil-resistant cabtyre cable		
attached cable	CN-66A-C5	Length 5 m 16.404 ft	with connector		
Power supply connector	CN-66A 5 pcs. per set	Connector for controller power supply / I-O cable.			
Controller mounting bracket	MS-DP1-6	Allows sensors sensors can als	to be installed on the wall. Multiple o be mounted closely.		
Panel mounting bracket	MS-DP1-2	Allows installation to panels with thickness of 1 to 6 mm 0.0 to 0.236 in. Multiple sensors can also be mounted closely			
Front protection cover	MS-DP1-3	Protects the adj (Can be attache	ustment surfaces of controllers. ed when using the panel mounting bracket)		

Notes: 1) One is attached to each sensor head according to standard.

2) The connector attached cable CN-66A-C2 is supplied with the controller according to standard.

Sensor head connector (e-CON)



Note: One is attached to each sensor head according to standard.

Connector attached cable

- CN-66A-C2
- CN-66A-C5



Note: The connector attached cable CN-66A-C2 is supplied with the controller according to standard.

Power supply connector

• CN-66A



Controller mounting bracket



Panel mounting bracket, Front protection cover



Recommended e-CON

Model No.: 1473562-4 (Manufactured by Tyco Electronics Japan G.K.) Note: Contact the manufacturer for details of the recommended products.

Recommended power supply connector

Contact: SPHD-001T-P0.5, Housing: PAP-06V-S (Manufactured by J.S.T. Mfg.Co., Ltd.) Note: Contact the manufacturer for details of the recommended products.

Recommended crimping tool

Model No.: YC-610R (Manufactured by J.S.T. Mfg. Co., Ltd.) Note: Contact the manufacturer for details of the recommended products.

SPECIFICATIONS

Sensor heads

Tuno		Со	mpound press	ure	Positive	pressure	Vacuum pressure			
	\smallsetminus	Туре		±100 kPa type		1 MP	a type		–101 kPa type	!
Item		Model No.(Note 3)	DPH-101(-R)	DPH-101-M3(-R)	DPH-101-M5(-R)	DPH-102	DPH-102-M5(-R)	DPH-103(-R)	DPH-103-M3(-R)	DPH-103-M5(-R)
CE m	narking di	rective compliance				EMC Directive,	RoHS Directive			
Туре	of press	ure				Gauge	pressure			
Rate	d pressu	re range	–1	00.0 to +100.0 k	Pa	0 to +1.	000 MPa		0 to –101.0 kPa	
Pres	sure with	standability		500 kPa		1.5	MPa		500 kPa	
Appli	icable flui	d				Air, non-co	prrosive gas			
Supp	oly voltag	e			12 to 24	4 V DC ±10 %	Ripple P-P 10 %	or less		
Curre	ent consu	Imption				15 mA	or less			
Analog voltage output		Output voltag Zero point: wi Wi Span: within Linearity: with Output imped	Output voltage: 1 to 5 V (over rated pressure range) Zero point: within 1 V ±2.5 % F.S. (vacuum / positive pressure type) within 3 V ±3 % F.S. (compound pressure type)5Span: within 4 V ±3.5 % F.S. Linearity: within ±0.5 % F.S. Output impedance: 1 kΩ approx.High pressure (positive / compound pressure type)						id pressure type) type)	
Ø	Protecti	on	IP40 (IEC)							
tanc	Ambien	t temperature	0 to +50 °C +32 to +122 °F (No dew condensation allowed), Storage: -10 to +60 °C +14 to +140 °F							
resis	Ambien	t humidity	35 to 85 % RH, Storage: 35 to 85 % RH							
ental	Voltage	withstandability	1,000 V AC for one min. between all supply terminals connected together and enclosure					d enclosure		
onme	Insulatio	on resistance	50 M Ω , or more, with 500 V DC megger between all supply terminals connected together and enclosure							
Envire	Vibratio	n resistance	10 to 500 Hz frequency, double amplitude 3 mm 0.118 in or maximum acceleration 196 m/s ² , in X, Y and Z directions for two holds a second sec						two hours each	
ш	Shock r	esistance		1,000 m	/s ² acceleration	(100 G approx.)	in X, Y and Z dir	rections three tim	nes each	
Temp	perature	characteristics	Over ambient temperature range 0 to +50 °C +32 to +122 °F: within ±2 % F.S. of detected pressure at +25 °C +77 °F							
Pres	sure port		DPH-10□(-R): R ¹ / ₈ male thread + M5 female thread, DPH-10□-M3(-R): M3 male thread (for installing gasket) DPH-10□-M5(-R): M5 male thread (for installing gasket)							
Mate	erial		Front case: PBT, Rear case: PBT (glass fiber reinforced), Pressure port: Stainless steel (SUS303), O-ring: NBR Pressure element: Silicon diaphragm, PPS							
Connecting method		Connector								
Cabl	е		0.2 mm ² 4-core oil resistant cabtyre cable (Models with "-R" affixed to the Model No. have flexible, oil-resistant cabtyre cable)							
Cabl	e extensi	on	Extension up to total 10 m 32.808 ft is possible with 0.2 mm ² , or more, cable.							
Weig	tht	Net weight	DPH-10	(-R): Head 10 g	approx. / Cable	40 g approx., D	PH-10□-M3/M5(-	R): Head 6 g ap	prox. / Cable 40	g approx.
weig	,	Gross weight			DPH-10□(-R): 8	30 g approx., DF	PH-10□-M3/M5(-I	R): 70 g approx.		
Accessory			Connector (e-CON): 1 pc.							

Notes: 1) Where measurement conditions have not been specified precisely, the conditions used were an ambient temperature of +25 °C +77 °F. 2) The sensor head can be used independently. 3) Model No. having the suffix "-**R**" is bending-resistant cable type. The bending-resistant cable type of **DPH-102** is not available.

SPECIFICATIONS

Controllers

\vee	\sim	Туре	NPN output type	PNP output type				
Item	י 🦯	Model No.	DPC-101	DPC-101-P				
CE marking directive compliance			EMC Directive, RoHS Directive					
Арр	licable sens	or head	DPH-101□, DPH-102□, DPH-103□					
Rate	ed pressure	range (Note 2)	Compound pressure: -100.0 to +100.0 kPa, Positive press	sure: 0 to +1.000 MPa, Vacuum pressure: 0 to -101.0 kPa				
Set	pressure rai	nge (Note 2)	Compound pressure: -199.9 to +199.9 kPa (-1.999 to +1.999 kgf/cm ² , -19.98 to Positive pressure: -1.050 to +1.050 MPa (-10.71 to +10.71 kgf/cm ² , -152.2 to Vacuum pressure: +101.3 to -101.3 kPa (+1.033 to -1.033 kgf/cm ² , +14.70 to	+19.98 psi, -1.999 to +1.999 bar, -1510 to +1537 mmHg, -59.4 to +60.5 inHg) to +152.2 psi, -10.50 to +10.50 bar) o -14.70 psi, +1.013 to -1.013 bar, +760 to -760 mmHg, +29.9 to -29.9 inHg)				
Sup	ply voltage		12 to 24 V DC ±10 % F	Ripple P-P 10 % or less				
Pow	ver consump	tion	Normal operation: 960 mW or less (Current cons ECO mode (STD): 720 mW or less (Current cons ECO mode (FULL): 600 mW or less (Current con Excluding the current consumption of sensor hea	umption 40 mA or less at 24 V supply voltage) sumption 30 mA or less at 24 V supply voltage) isumption 25 mA or less at 24 V supply voltage) ad and analog output current				
Sen	sor head su	pply voltage	Same as su	oply voltage				
Con (Co	nparative ou mparative o	tputs utput 1, 2)	NPN open-collector transistor (2 outputs) • Maximum sink current: 100 mA • Applied voltage: 30 V DC or less (between comparative output and 0 V) • Residual voltage: 2 V or less (at 100 mA sink current)	PNP open-collector transistor (2 outputs) • Maximum source current: 100 mA • Applied voltage: 30 V DC or less (between comparative output and +V) • Residual voltage: 2 V or less (at 100 mA source current)				
[Output oper	ation	NO/NC, selectable	by key operation				
	Output mod	es	EASY mode / Hysteresis mode	e / Window comparator mode				
	Hysteresis		Minimum 1 digit (variable) (howe	ver, 2 digits when using psi unit)				
	Repeatabilit	у	With vacuum / positive pressure type connected: within ± 0.2 % F.S. (± 2 digits) With compound pressure type connected: within ± 0.2 % F.S. (± 4 digits)					
	Response ti	me	0.5 ms, 1 ms, 2.5 ms, 5 ms, 10 ms, 25 ms, 50 ms, 100 ms, 250 ms, 500 ms, 1,000 ms, 5,000 ms, selectable by key operation					
	Short-circuit	protection	Incorporated					
Analog output			<analog output="" voltage=""> • Output current: 1 to 5 V DC • Zero point: within 1 V ±0.5 % F.S. (vacuum / positive pressure type) within 3 V ±0.5 % F.S. (compound pressure type) • Span: within 4 V ±0.5 % F.S. • Linearity: within ±0.1 % F.S. • Output impedance: 1 kΩ approx.</analog>	<analog current="" output=""> • Output current: 4 to 20 mA • Zero point: within 4 mA ±1 % F.S. (vacuum / positive pressure type) within 12 mA ±1.5 % F.S. (compound pressure type) • Span: within 16 mA ±1.5 % F.S. • Linearity: within ±0.1 % F.S. • Load resistance: 250 Ω (max.)</analog>				
	Sensor hea	d input	Input voltage range: 1 to 5 V DC (over rated pressure range)					
Inputs	External ing Auto-referent Remote zer	out nce function/ o-adjustment	ON voltage: 0.4 V DC or less OFF voltage: 5 to 30 V DC, or open Input impedance: 10 k Ω approx. Input time: 1 ms or more	ON voltage: 5 V to +V DC OFF voltage: 0.6 V DC or less, or open Input impedance: 10 k Ω approx. Input time: 1 ms or more				
Disp	olay		4 digits + 4 digits 3-color LCD display (Display refresh rate	: 250 ms, 500 ms, 1,000 ms, selectable by key operation)				
	Displayable	pressure range	Vacuum pressure: +5.1 to -101.3 kPa, Positive pressure: -0.0	50 to +1.020 MPa, Compound pressure: -101.3 to +105.0 kPa				
Ope	eration indica	ator	Orange LED (Comparative output 1 operation indicator, comparative outp	ut 2 operation indicator: Lights up when each comparative output is ON)				
	Protection		IP40	(IEC)				
ance	Ambient ter	nperature	-10 to +50 °C +14 to +122 °F (No dew condensation or	icing allowed), Storage: -10 to +60 °C +14 to +140 °F				
esist	Ambient hu	midity	35 to 85 % RH, Stor	age: 35 to 85 % RH				
ntal r	Voltage wit	nstandability	1,000 V AC for one min. between all supply t	erminals connected together and enclosure				
nmei	Insulation r	esistance	50 MΩ, or more, with 500 V DC megger between all	supply terminals connected together and enclosure				
Enviro	Vibration re	sistance	10 to 500 Hz frequency, double amplitude 3 mm 0.118 in or maximum accelerati bracket is mounted : 10 to 150 Hz frequency, double amplitude 0.75 mm 0.030 in	ion 196 m/s ² , in X, Y and Z directions for two hours each (when panel mounting n or maximum acceleration 49 m/s ² , in X, Y and Z directions for two hours each)				
	Shock resis	tance	100 m/s ² acceleration (10 G approx.) in	X, Y and Z directions three times each				
Tem	perature ch	aracteristics	Within ±0.5 % F.S. (ambient tempera	ture range based on +20 °C +68 °F)				
Mat	erial		Enclosure: PBT (glass fiber reinforced), LCD display: Acrylic, Mounti	ng threaded part: Brass (nickel plated), Switch part: Silicone rubber				
Con	inecting met	hod	Conn	ector				
Cab	le length		Total length up to 100 m 328.084 ft is p	bossible with 0.3 mm ² , or more, cable.				
Wei	ght .		Net weight: 25 g approx. (excluding connector	attached cable), Gross weight: 140 g approx.				
Acc	essories		CN-66A-C2 (Connector attached cable	2 m 6.562 ft), Pressure unit label: 1 set				

Notes: 1) Where measurement conditions have not been specified precisely, the conditions used were an ambient temperature of +20 °C +68 °F. 2) It changes automatically according to the connected pressure sensor head. 3) The values specified above are applied only to the controller.

I/O CIRCUIT AND WIRING DIAGRAMS

DPC-101

I/O circuit diagram



Notes: 1) Select and use the auto-reference function and remote zero-adjustment function. 2) Set the output load resistance during analog current output to 250 Ω (max.) 3) Note that a voltage of 5 V or higher is generated during analog current output.

Symbols D1 to D4	: Reverse supply polarity protection diode
ZD1 to ZD	3: Surge absorption zener diode
Tr1, Tr2	: NPN output transistor

*1



Terminal arrangement diagram



Connector for power supply / I-O cable (CN1)

①+V

- 2 Analog voltage/current output
- 30V
- (4) Comparative output 1
- (5) Comparative output 2
- ⑥ External input (auto-reference function / remote zero-adjustment function)

Connector for sensor head (CN2)

- ① Sensor head power supply
- ② Analog voltage input
- 30V
- (4) Model discrimination signal

For independent use of sensor head

NPN output type



- Notes: 1) in case the sensor head is used independently, insulate the white lead wire (terminal No.4) and keep it open.
 2) When the sensor head is used independently, devices connected to the analog output must have an input impedance set at 50 kΩ or more.
- Symbols ... D : Reverse supply polarity protection diode ZD: Surge absorption zener diode

I/O CIRCUIT AND WIRING DIAGRAMS

DPC-101-P

I/O circuit diagram



Notes: 1) Select and use the auto-reference function and remote zero-adjustment function. 2) Set the output load resistance during analog current output to 250 Ω (max.) 3) Note that a voltage of +5 V or higher is generated during analog current output.

Symbols D1 to D	4 : Reverse supply polarity protection diode
ZD1 to 2	ZD3: Surge absorption zener diode
Tr1, Tr2	: PNP output transistor

*1



Terminal arrangement diagram



Connector for power supply / I-O cable (CN1)

①+V

- 2 Analog voltage/current output
- 30V
- Comparative output 1
- (5) Comparative output 2
- ⑥ External input (auto-reference function / remote zero-adjustment function)

Connector for sensor head (CN2)

- ① Sensor head power supply
- 2 Analog voltage input
- 30V
- (4) Model discrimination signal

For independent use of sensor head

PNP output type



Notes: 1) In case the sensor head is used independently, insulate the white lead wire (terminal No.4) and keep it open.

- When the sensor head is used independently, devices connected to the analog output must have an input impedance set at 50 kΩ or more.
- Symbols ... D : Reverse supply polarity protection diode ZD: Surge absorption zener diode

PRECAUTIONS FOR PROPER USE

Never use this product as a sensing device for personnel protection.
In case of using sensing devices for



- personnel protection, use products which meet laws and standards, such as OSHA, ANSI or IEC etc., for personnel protection
- applicable in each region or country.
 The **DPH-100** series is designed for use with air and non-corrosive gas. It cannot be used with liquid or corrosive and inflammable gases.

Part description



Wiring

- Make sure that the power supply is off while wiring.
- Verify that the supply voltage variation is within the rating.
- If power is supplied from a commercial switching regulator, ensure that the frame ground (F.G.) terminal of the power supply is connected to an actual ground.
- In case noise generating equipment (switching regulator, inverter motor, etc.) is used in the vicinity of this sensor, connect the frame ground (F.G.) terminal of the equipment to an actual ground.
- Do not run the wires together with high-voltage lines or power lines or put them in the same raceway. This can cause malfunction due to induction.
- · Incorrect wiring will cause problems with operation.

Connection

• Do not apply stress directly to the connection cable leader or to the connector.





<Connector of connector attached cable> Housing: PAP-06V-S [Manufactured by J.S.T Mfg. Co. Ltd.]

\<u>Release lever</u> **<Connector of sensor head cable>** e-CON: 1473562-4 [Manufactured by Tyco Electronics Japan G.K.]

Mounting

 When tightening the controller to the controller mounting bracket MS-DP1-6 (optional), use a tightening torque of 0.5 N·m or less.



• The **MS-DP1-2** panel mounting bracket (optional) and the **MS-DP1-3** front protection cover (optional) are also available.



Piping

• Use a hexagonal wrench to install sensor head. For the tightening torque, refer to the following diagram. If excessive tightening torque is applied, the pressure port of the sensor head or the M5 male screw of the commercial coupling will get damaged. In case of R1/8 male thread type, wrap sealing tape around the coupler when connecting to prevent leakage.



Pressure port	Hexagonal wrench (bolt width)	Tightening torque
R1/8 male thread	5 mm 0.197 in	9.8 N·m or less
M3 male thread	2 mm 0 119 in	0.8 N m or less
M5 male thread	3 IIIII 0. 118 III	1.5 N·m or less

Others

- · Use within the rated pressure range.
- Do not apply pressure exceeding the pressure withstandability value. The diaphragm will get damaged and correct operation shall not be maintained.
- Do not use during the initial transient time (controller: 0.5 sec. approx, sensor head: 50 ms approx.) after the power supply is switched on.
- Avoid dust, dirt, and steam.
- Take care that the sensor does not come in direct contact with water, oil, grease, or organic solvents, such as, thinner, etc.
- Do not insert wires, etc., into the pressure port. The diaphragm will get damaged and correct operation shall not be maintained.
- · Do not operate the keys with pointed or sharp objects.

PRECAUTIONS FOR PROPER USE

RUN mode

• This is the normal operating mode.

Setting item	Description
Threshold value setting	The threshold values for ON/OFF operation can be changed directly by pressing the increment key (UP) and the decrement key (DOWN).
Zero-adjustment function	This forces the pressure value display to be reset to zero when the pressure port is open on the atmospheric pressure side.
Key lock function	Stops key operations from being accepted.
Peak hold / bottom hold function	Displays the peak value and bottom value for fluctuating pressure. The peak value appears in the main display, and the bottom value appears in the sub display.

MENU SETTING mode

- If the mode selection key is pressed and held for 2 sec. in RUN mode, the mode will switch to MENU SETTING mode.
- If the mode selection key is pressed while a setting is being made, the mode will switch to RUN mode. In this case, the settings that have been changed will be entered.

Setting item	Description
Comparative output 1 output mode setting	Sets the output mode for comparative output 1.
Comparative output 2 output mode setting	Sets the output mode for comparative output 2.
Analog voltage/current output selection	Selects analog voltage output or analog current output.
External input selection	Selects auto-reference function, or remote zero- adjustment function.
NO/NC selection	Normally open (NO) or normally closed (NC) can be selected.
Response time setting	Sets the response time. The response time can be selected from 0.5 ms, 1 ms, 2.5 ms, 5 ms, 10 ms, 25 ms, 50 ms, 100 ms, 250 ms, 500 ms, 1,000 ms and 5,000 ms.
Display color switching for main display	Allows the color for the main display to be changed. The colors can be set to "red/green" or "green/ red" to correspond to ON/OFF output, or it can be fixed at "red" or "green" all the time.
Unit switching	Pressure unit can be changed.

PRO mode

- If the mode selection key is pressed and held for 5 sec. in RUN mode, the mode will switch to PRO mode.
- If the mode selection key is pressed while a setting is being made, the mode will switch to RUN mode. In this case, the settings that have been changed will be entered.

Setting item	Description
Sub display switching	Changes the information in the sub display during RUN mode operation to the current pressure unit, number and desired alphanumeric display.
Display refresh rate switching	Changes the display refresh rate for the pressure value displayed in the main display.
Hysteresis fix value switching	Sets the hysteresis for EASY mode and window comparator mode. (8 steps)
Linked display color switching	Allows the display color for the main display to be switched in line with the output operation for comparative output 1 or comparative output 2.
External input relation selection	The setting contents set at the external input selection in MENU SETTING mode can be shifted to correspond to either comparative output 1, 2 or 1 / 2.
ECO mode setting	Allows power consumption to be reduced by dimming the display or turning it off.
Setting check code	Allows the setting details to be checked via codes. (Refer to below)
Setting copy mode	Allows the setting details for the master controller to be copied to slave controllers.
Reset setting	Resets the settings to the factory settings.

Table of codes

e	1st digit		2nd	digit	3rd	3rd digit		4th digit	
Coc	Comparative output 1 output mode	NO/NC selection	Comparative output 2 output mode	NO/NC selection	Analog output	Threshold display	External input		
0	EASY	NO	OFF	—		Threshold value 1	OFF	—	
1	EAST	NC	FACY	NO	NO Analog	Threshold value 2		Comparative output 1	
2		NO EASY NC voltage output	Threshold value 3	Auto-	Comparative output 2				
3	Hysteresis		Hysteresis	NO	συιρυι	Threshold value 4	reference	Comparative output 1/2	
Ч	Window	NO		NC		Threshold value 1	Remote zero- adjustment	Comparative output 1	
5	comparator	NC	Window	NO	Analog	Threshold value 2		Comparative output 2	
Б	_	—	comparator	NC	current output	Threshold value 3		Comparative output 1/2	
٦	—	_	—			Threshold value 4	—	—	



Code	5th digit		6th digit	7th digit	8th digit		
	Displayed color of the main display	Displayed color relation	Response time	Unit selection (Note)	Display refresh rate	Eco mode	
0	Red when ON	Comparative output 1	0.5 ms	MPa	250 ms	OFF	
1		Comparative output 2	1 ms	kPa		STD	
2	Green when ON	Comparative output 1	2.5 ms	kgf/cm ²		FULL	
3		Comparative output 2	5 ms	bar	500 ms	OFF	
Ч	Always red	Comparative output 1	10 ms	psi		STD	
5		Comparative output 2	25 ms	mmHg		FULL	
Б	Always green	Comparative output 1	50 ms	inHg	1,000 ms	OFF	
7		Comparative output 2	100 ms	_		STD	
8	—	_	250 ms	—		FULL	
9	_	_	500 ms	_	_	_	
Я	—	_	1,000 ms	—		—	
8	_	—	5,000 ms	—	—	_	

Note: When positive pressure type of the pressure sensor head is connected to the controller for use inside Japan, "[]" (MPa) or " {" (kPa) is displayed. When compound pressure type or vacuum pressure type is connected, only " {" (kPa) is displayed.

DIMENSIONS (Unit: mm in)

The CAD data can be downloaded from our website.



DPC-101(-P)

16







Controller mounting bracket (Optional)



29.95

30

ا 3.8 0.150

Assembly dimensions





 $\label{eq:Material} \begin{array}{l} \mbox{Material: Cold rolled carbon steel (SPCC) (Trivalent uni-chrome plated)} \\ \mbox{Two M3 (length 6 mm 0.236 in) screws with washers are attached.} \end{array}$

33.4

ക

FT.

4 0.157deep

M3 female thread

52 2.047

max.

View A

(A)

DIMENSIONS (Unit: mm in)

The CAD data can be downloaded from our website.

MS-DP1-2 MS-DP1-3

Panel mounting bracket (Optional), Front protection cover (Optional)

Assembly dimensions



Vertical mounting





View A Material: Polyacetal (Panel mounting bracket) Polycarbonate (Front protection cover)

Panel cut-out dimensions

When 1 unit is installed

When "n" units are installed horizontally in series



CN-66A-C2 CN-66A-C5



Note: The panel thickness should be 1 to 6 mm 0.039 to 0.236 in.

When "n" units are installed vertically in series

9.05



Connector attached cable (Optional, **CN-66A-C2** is attached to the controller)



Length L				
Model No.	Length L			
CN-66A-C2	2,000 78.740			
CN-66A-C5	5,000 196.850			

Disclaimer

The applications described in the catalog are all intended for examples only. The purchase of our products described in the catalog shall not be regarded as granting of a license to use our products in the described applications. We do NOT warrant that we have obtained some intellectual properties, such as patent rights, with respect to such applications, or that the described applications may not infringe any intellectual property rights, such as patent rights, of a third party.



Panasonic Industry Co., Ltd.

Industrial Device Business Division 7-1-1, Morofuku, Daito-shi, Osaka 574-0044, Japan industrial.panasonic.com/ac/e/