

Using the UCC28911EVM-718

User's Guide



Literature Number: SLUUBA1
March 2015

Using the UCC28911EVM-718 7.5W Universal Off-Line Flyback Converter with Primary-Side Regulation

1 Introduction

The UCC28911EVM-718 evaluation module is an offline flyback power supply that provides isolated output voltage and current regulation without the use of an optocoupler. The input accepts a voltage range of 85 V_{AC} to 265 V_{AC}, 47 Hz to 64 Hz.

2 Description

The evaluation module uses the UCC28911 CV/CC PWM HV Switcher. This device integrates a 700-V power MOSFET and controller that processes operating information from an auxiliary flyback winding and from the power MOSFET to provide precise output voltage and current control. Control algorithms in the UCC28911 allow operating efficiencies to meet or exceed applicable standards. Discontinuous Conduction Mode (DCM) with valley switching is used to reduce switching losses. A combination of switching frequency and peak-primary current amplitude modulation is used to keep conversion efficiency high across the full load and input voltage range. [Figure 1](#) below details the output V-I characteristic.

Low-system parts count and built-in advanced protection features result in a cost-effective solution that meets stringent world-wide energy efficiency requirements.

This user's guide provides the schematic, component list, assembly drawing, art work, and test set up necessary to evaluate the UCC28911 in a typical off-line converter application.




Figure 1. Output Voltage as a Function of Output Load

2.1 Applications

The UCC28911 is suited for use in isolated off-line systems requiring high efficiency and advanced fault protection features including:

- USB Compliant Adapters for Cell Phones, Tablets and Cameras
- 7-W to 10-W AC-to-DC Power Supplies

2.2 Features

The UCC28911EVM-718 features include:

- Isolated 7.5-W, 5-V Output
- Universal Off-Line Input Voltage Range
- Meets USB Specification 1.1
- Multiple Operating Modes and Valley Switching (for optimum efficiency over entire operating range)
- Primary-Side Control Eliminates Need for Optocoupler
- Output Over-Voltage Protection
- Input Under-Voltage Protection
- Primary Over-Current protection
- Thermal Shutdown
- Controlled Start Up and Restart After Fault Protection

CAUTION

High voltage levels are present on the evaluation module when energized. Proper precautions must be taken when working with the EVM. The large bulk capacitors, C1 and C2, and the output capacitors, C7 and C8, must be completely discharged before the EVM can be handled. Serious injury can occur if proper safety precautions are not followed.

3 Electrical Performance Specifications

Table 1. UCC28911EVM-718 Electrical Performance Specifications

PARAMETER		TEST CONDITIONS	Min	NOM	MAX	UNITS
Input Characteristics						
V_{IN}	Input voltage		85	115/230	265	V
f_{LINE}	Frequency		47	50/60	64	Hz
P_{NL}	No-load power	$V_{IN} = V_{NOM}$ $I_{OUT} = 0$ A		15	20	mW
$V_{IN(uvlo)}$	Brownout voltage	$I_{OUT} = I_{NOM}$		70		V
V_{INOV}	Brownout recovery voltage			80		V
I_{IN}	Input current	$V_{IN} = V_{MIN}$ $I_{OUT} = I_{OUT(max)}$		0.3		A
Output Characteristics						
V_{OUT}	Output voltage	$V_{IN} = V_{MIN}$ to V_{MAX} $I_{OUT} = 0$ to I_{NOM}	4.75	5	5.25	V
$I_{OUT(max)}$	Maximum output current	$V_{IN} = V_{MIN}$ to V_{MAX}	1.425	1.5	1.575	A
$I_{OUT(min)}$	Minimum output current	$V_{IN} = V_{MIN}$ to V_{MAX}		0		A
ΔV_{OUT}	Output voltage ripple	$V_{IN} = V_{MIN}$ to V_{MAX} $I_{OUT} = 0$ to I_{NOM}		150		mV
P_{OUT}	Output power	$V_{IN} = V_{MIN}$ to V_{MAX}		7.5		W
System Characteristics						
η	Average efficiency	$V_{IN} = V_{NOM}$ $I_{OUT} = 25\%$, 50%,75%,100% of I_{OUT}		75%		
Mechanical						
W	Dimensions	Width		3.5		in
L		Length		5		in
H		Component Height		1		in

4 Schematic




Figure 2. UCC28911EVM-718 Schematic

5 Circuit Description

A brief description of the circuit elements follows:

- Diode Bridge D1, input capacitors C1 and C2, transformer T1, UCC28911 switcher U1, Schottky rectifier D5 and capacitor C7 form the power stage of the converter.

NOTE: The UCC28911 U1 is also part of the power stage since the high-voltage MOSFET is internal to U1.

- Capacitor C8 filters the high-frequency noise directly across the electrolytic output capacitor.
- The input EMI filter is made up of C1 and C2 and differential mode inductors, L2 and L3.
- R1, R2 serve the dual function of dampening input filter oscillations and prevent a large voltage being developed across L2 and L3 in the event of an ESD pulse.
- Input-current protection is provided by fusible resistor, RF1.
- Resistors R5 and R6, capacitor C3, and diodes D2 and D3 make up the primary-side voltage clamp. The clamp prevents the drain voltage on U1 from exceeding its maximum rating. A secondary function of the clamp is to alleviate the EMI currents associated with the turnoff voltage of U1.
- Operating bias to the controller is provided by the auxiliary winding on T1, diode D4, resistor R7 and bulk capacitor C5.
- Capacitor C4 is a decoupling capacitor which should always be good quality low ESR/ESL type capacitors placed as close to the device pins as possible and returned directly to the device ground reference.
- Secondary-side snubber C6 and R11 are used to reduce the effects switching noise of D5.
- Resistor R9 programs the start-up voltage threshold.
- Resistors R8 and R10 program the output voltage set point.
- Resistors R3 and R4 program the maximum output current.
- Resistor R12 is used to adjust the no-load output voltage.

6 EVM Test Set Up

Figure 3 shows the equipment set up when measuring the input power consumption during no load. During the no-load test, the power analyzer should be set for long averaging in order to include several cycles of operation and an appropriate current scale factor should be used. Figure 4 shows the basic test set up recommended to evaluate the UCC28911EVM-718 with a load.

WARNING

High voltages that may cause injury exist on this evaluation module (EVM). Please ensure all safety procedures are followed when working on this EVM. Never leave a powered EVM unattended.

6.1 Test Equipment

See Figure 3 and Figure 4 for recommended test set ups.

AC Input Source: The input source shall be an isolated variable AC source capable of supplying between $85 V_{RMS}$ and $265 V_{RMS}$ at no less than 15 W and connected as shown in Figure 3 and Figure 4. For accurate efficiency calculations, a power meter should be inserted between the AC source and the EVM. For highest accuracy, connect the voltage terminals of the power meter directly across the power source.

NOTE: Connecting the voltage terminals directly to the EVM results in a small current error. This is very significant when measuring no load power.

Load: For the output load, a programmable electronic load set to constant current mode and capable of sinking 0 to $1.5 A_{DC}$ at $10 V_{DC}$ shall be used. For highest accuracy, V_{OUT} can be monitored by connecting a DC voltmeter, DMM V1, directly across the V_{OUT} and $-V_{OUT}$ terminals as shown in Figure 3 and Figure 4. A DC current meter, DMM A1, should be placed in series with the electronic load for accurate output current measurements.

Power Meter: The power analyzer (PM1) shall be capable of measuring low-input current, typically less than $100 \mu A$, and a long averaging mode if low-power standby mode input-power measurements are to be taken. An example of such an analyzer is the Yokogawa WT210 Digital Power Meter. To measure the intermittent bursts of current and power drawn from the line during no-load operation, the WT210 should be set to integrate.

Multimeters: Two digital multimeters are used to measure the regulated output voltage (DMM V1) and load current (DMM A1).

Oscilloscope: A digital or analog oscilloscope with a 500-MHz scope probe is recommended.

Recommended Wire Gauge: a minimum of AWG 24 wire is recommended. The wire connections between the AC source and the EVM, and the wire connections between the EVM and the load should be less than two feet long.

6.2 Recommended Test Set Up for Operation Without a Load




Figure 3. UCC28911EVM-718 Recommended Test Set Up without a Load

6.3 Recommended Test Set Up for Operation With a Load




Figure 4. UCC28911EVM-718 Recommended Test Set Up With a Load

7 Test Procedure

All tests should use the set up as described in Section 5 of this user's guide. The following test procedure is recommended primarily for power up and shutting down the evaluation module. Never leave a powered EVM unattended for any length of time.

7.1 Applying Power to the EVM

1. Set up the EVM as shown in [Section 6](#) of this user's guide.
 - (a) If no-load input power measurements are to be made, set the power analyzer to long averaging or integrating power measurement mode.
 - (b) For operation with a load, as shown in [Figure 4](#), set the electronic load to constant resistance mode.
2. Prior to turning on the AC source, set the voltage to between 85 V_{AC} and 265 V_{AC}.
3. Turn on the AC source.
4. Monitor the output voltage on DMM V1.
5. Monitor the output current on DMM A1.
6. The EVM is now ready for testing.

7.2 No-Load Power Consumption

1. Use the test set up shown in [Figure 3](#).
 - (a) Set the power analyzer to integrating average power mode.
 - (b) Set the current measurement scale to 0.25 A.
 - (c) Set the voltage range to 300 V.
 - (d) Set the measurement mode to RMS.
2. Apply power to the EVM per [Section 7.1](#).
3. Monitor the input power on the power analyzer while varying the input voltage.
4. Make sure the input power is off and the bulk capacitor and output capacitors are completely discharged before handling the EVM.

7.3 Output Voltage Regulation and Efficiency

1. For load regulation:
 - (a) Use the test set up shown in [Figure 4](#).
 - (b) Set the AC source to a constant voltage between 85 V_{AC} and 265 V_{AC}.
 - (c) Apply power to the EVM per [Section 7.1](#).
 - (d) Vary the load current from 0 A up to 1.5 A, as measured on DMM A1.
 - (e) Observe that the output voltage on DMM V1 remains between 4.75 V and 5.25 V from no load up to 1.5 A and thereafter the current remains between 1.425 A and 1.575 A until the output voltage drops to 2 V or lower. See [Figure 1](#) for details.
2. For line regulation:
 - (a) Set the load to sink 1.5 A.
 - (b) Vary the AC source from 85 V_{AC} to 265 V_{AC}.
 - (c) Observe that the output voltage on DMM V1 remains between 4.75 V and 5.25 V.
3. Make sure the input power is off and the bulk capacitor and output capacitors are completely discharged before handling the EVM.

7.4 Output Voltage Ripple

1. For output ripple measurements, solder a 0.1- μ F, 50-V ceramic capacitor and 4.7- μ F, 35-V tantalum capacitor on a BNC adapter as shown in [Figure 5](#) below. Connect the red test lead to the V_{OUT} output and the black test lead to the $-V_{OUT}$ on the EVM.
2. Connect the other end of the BNC cable to the oscilloscope and monitor the output ripple on the oscilloscope.
3. Apply power to the EVM per [Section 7.1](#).



Figure 5. Typical Example of Tip Measurement Technique

7.5 Equipment Shutdown

1. Ensure the load is at maximum; this quickly discharges the output capacitors.
2. Turn off the AC source.
3. Make sure the bulk capacitors, C1, C2 and output capacitor, C7 are completely discharged before handling the EVM.

8 Performance Data and Typical Characteristic Curves

Figure 6 through Figure 14 present typical performance curves for the UCC28911EVM-718.




Figure 6. Typical V-I Characteristic

Table 2. Average and 10% Load Efficiency

V_{IN} (V)	f (Hz)	P_{IN} (W)	I_{OUT} (A)	V_{OUT} (V)	P_{OUT} (W)	Eff (%)	Avg Eff (%)
115	60	10.27	1.497	5.131	7.68	74.79	75.48
		7.654	1.122	5.123	5.75	75.10	
		5.047	0.747	5.118	3.82	75.75	
		2.495	0.372	5.115	1.90	76.26	
		1.042	0.148	5.119	0.76	72.71	
230	50	10.02	1.493	5.148	7.69	76.71	76.32
		7.476	1.119	5.133	5.74	76.83	
		4.964	0.744	5.122	3.81	76.77	
		2.527	0.370	5.120	1.89	74.97	
		1.052	0.145	5.117	0.74	70.53	

Table 3. No-Load Power Consumption

V_{IN} (V)	f (Hz)	P_{IN} (mW)	V_{OUT} (V)
115	60	11.4	5.21
230	50	13.5	5.21

Table 4. Typical V-I Test Data

100 V _{AC}		115 V _{AC}		230 V _{AC}		265 V _{AC}	
I _{OUT} (A)	V _{OUT} (V)	I _{OUT} (A)	V _{OUT} (V)	I _{OUT} (A)	V _{OUT} (V)	I _{OUT} (A)	V _{OUT} (V)
1.387	5.147	1.387	5.148	1.387	5.148	1.387	5.148
1.401	5.147	1.401	5.148	1.401	5.149	1.401	5.148
1.415	5.147	1.416	5.148	1.416	5.149	1.416	5.149
1.429	5.147	1.43	5.149	1.431	5.149	1.43	5.148
1.444	5.147	1.445	5.149	1.445	5.149	1.445	5.149
1.46	5.147	1.46	5.149	1.461	5.149	1.461	5.149
1.472	5.136	1.476	5.15	1.476	5.149	1.476	5.149
1.473	5.086	1.48	5.108	1.492	5.15	1.492	5.15
1.474	5.033	1.481	5.058	1.508	5.15	1.508	5.15
1.476	4.987	1.482	5.004	1.513	5.11	1.525	5.15
1.477	4.933	1.483	4.952	1.514	5.057	1.524	5.089
1.477	4.88	1.484	4.902	1.515	5.004	1.525	5.037
1.478	4.829	1.485	4.85	1.516	4.951	1.526	4.983
1.479	4.777	1.485	4.796	1.517	4.899	1.527	4.93
1.48	4.726	1.486	4.743	1.518	4.843	1.527	4.874
1.481	4.673	1.487	4.691	1.519	4.791	1.528	4.821
1.482	4.621	1.488	4.64	1.519	4.736	1.529	4.766
1.483	4.568	1.489	4.585	1.52	4.681	1.53	4.712
1.483	4.516	1.49	4.532	1.521	4.629	1.531	4.659
1.484	4.461	1.49	4.479	1.521	4.574	1.531	4.603
1.485	4.409	1.491	4.426	1.522	4.519	1.532	4.547
1.486	4.357	1.491	4.373	1.523	4.465	1.533	4.494
1.486	4.302	1.492	4.32	1.523	4.41	1.533	4.438
1.487	4.25	1.493	4.267	1.524	4.355	1.534	4.384
1.487	4.195	1.494	4.214	1.524	4.3	1.534	4.328
1.488	4.143	1.494	4.158	1.525	4.244	1.535	4.273
1.489	4.091	1.495	4.106	1.525	4.189	1.536	4.217
1.489	4.036	1.495	4.051	1.526	4.136	1.536	4.162
1.49	3.982	1.496	3.999	1.526	4.08	1.537	4.106
1.49	3.928	1.497	3.944	1.527	4.022	1.537	4.051
1.49	3.874	1.497	3.89	1.527	3.969	1.537	3.993
1.491	3.82	1.497	3.835	1.528	3.914	1.538	3.939
1.492	3.767	1.497	3.781	1.528	3.859	1.539	3.884
1.493	3.713	1.499	3.727	1.529	3.803	1.539	3.827
1.493	3.659	1.499	3.672	1.53	3.747	1.54	3.771
1.494	3.605	1.499	3.618	1.53	3.692	1.541	3.718
1.495	3.551	1.5	3.563	1.531	3.636	1.541	3.661
1.495	3.497	1.501	3.51	1.531	3.581	1.542	3.606
1.495	3.443	1.502	3.455	1.532	3.525	1.542	3.549
1.496	3.388	1.502	3.401	1.532	3.469	1.543	3.493
1.497	3.334	1.502	3.347	1.533	3.413	1.543	3.436
1.498	3.281	1.503	3.292	1.533	3.358	1.543	3.381
1.498	3.225	1.503	3.237	1.534	3.302	1.544	3.325
1.498	3.171	1.504	3.181	1.534	3.246	1.544	3.267
1.499	3.117	1.504	3.127	1.534	3.188	1.546	3.213
1.498	3.062	1.504	3.072	1.535	3.133	1.546	3.157
1.5	3.011	1.505	3.016	1.535	3.077	1.546	3.1

Table 4. Typical V-I Test Data (continued)

100 V _{AC}		115 V _{AC}		230 V _{AC}		265 V _{AC}	
I _{OUT} (A)	V _{OUT} (V)	I _{OUT} (A)	V _{OUT} (V)	I _{OUT} (A)	V _{OUT} (V)	I _{OUT} (A)	V _{OUT} (V)
1.5	2.951	1.505	2.961	1.535	3.021	1.547	3.042
1.5	2.896	1.505	2.906	1.536	2.964	1.547	2.986
1.501	2.841	1.505	2.85	1.536	2.907	1.546	2.929
1.5	2.786	1.505	2.794	1.536	2.851	1.547	2.873
1.501	2.729	1.506	2.74	1.536	2.794	1.548	2.815
1.501	2.675	1.505	2.683	1.536	2.738	1.548	2.758
1.501	2.621	1.506	2.626	1.537	2.682	1.547	2.7
1.502	2.565	1.506	2.572	1.536	2.624	1.547	2.642
1.502	2.509	1.506	2.516	1.537	2.568	1.547	2.585
1.502	2.453	1.506	2.46	1.537	2.51	1.547	2.527
1.501	2.397	1.506	2.405	1.537	2.453	1.547	2.47
1.502	2.341	1.506	2.349	1.537	2.396	1.547	2.412
1.502	2.286	1.506	2.292	1.537	2.339	1.547	2.355
1.501	2.23	1.506	2.237	1.536	2.281	1.547	2.296
1.502	2.174	1.505	2.181	1.536	2.224	1.546	2.239
1.501	2.119	1.505	2.124	1.536	2.167	1.546	2.181
1.501	2.062	1.505	2.067	1.535	2.11	1.546	2.124
1.501	2.006	1.505	2.011	1.535	2.052	1.545	2.066
1.501	1.949	1.504	1.956	1.535	1.994	1.546	2.008
1.5	1.894	1.504	1.898	1.534	1.936	1.545	1.95
1.499	1.838	1.503	1.841	1.533	1.879	1.544	1.892
1.5	1.782	1.503	1.786	1.533	1.821	1.544	1.834
1.498	1.725	1.502	1.73	1.532	1.764	1.543	1.776
1.497	1.668	1.501	1.673	1.531	1.705	1.542	1.718
1.497	1.612	1.501	1.616	1.531	1.648	1.541	1.659
1.496	1.555	1.5	1.559	1.53	1.591	1.54	1.601
1.495	1.499	1.498	1.503	1.528	1.532	1.539	1.543




Figure 7. Ripple with 5 V, 1.5 A Out, 115 V_{AC} in 20 mV/div 100 µs/div




Figure 8. Ripple with 5 V, 1 A Out, 115 V_{AC} in 20 mV/div 100 µs/div




Figure 9. Step Load 1.5 A to 0.5 A, C4 200 mV/div, C3 2 A/div 200 ms/div




Figure 10. Step Load 1.5 A to 0 A, C4 500 mV/div, C3 2 A/div 200 ms/div




Figure 11. Output Voltage Start 115 V_{AC}, 1.5-A load, 1 V/div 50 ms/div




Figure 12. Output Voltage Start, 230 V_{AC}, 1.5-A load, 1 V/div 50 ms/div




Figure 13. Primary-Side Switching Waveforms 85 V_{AC}
 (1.5-A Load Drain Voltage, CH 1 100 V/div and Current, CH3 0.5 A/div 2 μs/div)




Figure 14. Primary-Side Switching Waveforms 265 V_{AC}
 (1.5-A Load Drain Voltage, CH 1 100 /div and Current, CH4 0.5 A/div 2 μs/div)

9 EVM Assembly Drawing and Layout

The following figures show the design of the UCC28911EVM-718 printed circuit board.



Figure 15. UCC28911EVM-718 (top view)




Figure 16. PCB (top)




Figure 17. PCB (bottom)

10 List of Materials

10.1 Flyback Transformer

10.1.1 Material List

- EE16/8/5 ferrite core pair.
- EE16/8/5 9-pin through hole, horizontal bobbin.
- 0.18-mm OD enamel copper wire.
- 0.35-mm Furukawa TEX-E triple insulated copper wire or equivalent.
- 10.6-mm wide mylar tape.

10.1.2 Winding Table

Table 5. Winding Table

WINDING	START	FINISH	WIRE	WINDING DIRECTION	TURNS	COMMENTS
WDG 1	2		0.18-mm OD	CW	50	WDG 1 is full single layer. Finish of WDG1 is lead out towards pin 2 and becomes start of WDG2.
			Tape	CW	2	
WDG 2		5	0.18-mm OD	CW	49	WDG 1 is full single layer. Finish of WDG1 is lead out towards pin 2 and becomes start of WDG2.
			10.6-mm tape	CW	2	
WDG 3	4	x	0.18-mm OD	CW	25	WDG 3 wound bifilar. single layer
			10.6-mm tape	CW	2	
WDG 4	x	4	0.18-mm OD	CW	25	WDG 4 wound bifilar, single layer
			10.6-mm tape	CW	2	
WDG 5	1	4	0.18-mm OD	CW	21	WDG 5 wound bifilar. single layer
			10.6-mm tape	CW	2	
WDG 6	3	NC	0.18-mm OD	CW	28	WDG 6 wound bifilar, single layer
			10.6-mm tape	CW	2	
WDG 7	6	8	0.35-mm TEX	CCW	6	WDG 7 wound bifilar
			10.6-mm tape	CCW	2	
WDG 8	7	9	0.35-mm TEX	CCW	6	WDG 8 wound bifilar
			10.6-mm tape	CCW	2	

10.1.3 Transformer Cross Section




Figure 18. Transformer Cross Section

10.1.4 Electrical Specifications

Table 6. Electrical Specifications

PARAMETER	PINS	TEST CONDITIONS	VALUE
DC resistance	1 to 4		0.685 Ω , 10%
DC resistance	2 to 5		2.680 Ω , 10%
DC resistance	6 to 9	Tie 6 to 7 and 8 to 9	0.021 Ω , 20%
Inductance	2 to 5	10 kHz, 100 mV	825 μ H, 10%
Dielectric	1 to 9	4500 V _{AC} , 1 s	No breakdown
Dielectric	1 to 5	625 V _{AC} , 1 s	No breakdown
Turns ratio	(2 to 5) and (1 to 4)		4.71:1, 1%
Turns ratio	(2 to 5) and (9 to 6)	Tie 6 to 7 and 8 to 9	16.5:1, 1%

10.1.5 Part View




Figure 19. Part View

11 Detailed List of Materials

Table 7. UCC28911EVM-718 List of Materials

QTY	DES	DESCRIPTION	MANUFACTURER	PART NUMBER
2	C1, C2	Capacitor, aluminum, 10 μ F, 400 V, \pm 20%, 2.864788 Ω , TH	Panasonic	EEUED2G100
1	C3	Capacitor, ceramic, 100 pF, 500 V, \pm 5%, C0G/NP0, 1206	Kemet	C1206C101JCGACTU
1	C4	Capacitor, ceramic, 0.1 μ F, 25 V, \pm 10%, X5R, 0603	AVX	06033D104KAT2A
1	C5	Capacitor, aluminum, 10 μ F, 35 V, \pm 20%, TH	Nichicon	UVR1V100MDD1TA
0	C6	Capacitor, ceramic, 2200 pF, 50 V, \pm 10%, X7R, 0805	AVX	08055C222KAT2A
1	C7	Capacitor, aluminum, 1200 μ F, 10 V, \pm 20%, TH	Panasonic	EEUFM1A122
1	C8	Capacitor, ceramic, 0.1 μ F, 50 V, \pm 5%, X7R, 1206	AVX	12065C104JAT2A
1	D1	Diode, switching-bridge, 600 V, 1 A, TH	Diodes Inc.	DF06M
1	D2	Diode, TVS, Uni, 170 V, 600 W, SMB	ST Microelectronics	SMBJ170A-TR
1	D3	Diode, switching, 600 V, 1 A, TH	Vishay-Semiconductor	1N4937-E3
1	D4	Diode, switching, 200 V, 0.2 A, SOD-123	Diodes Inc.	BAV21W-7-F
1	D5	Diode, Schottky, 40 V, 10 A, PowerDI5	Diodes Inc.	PDS1040L-13
4	H109, H110, H111, H112	Bump on, hemisphere, 0.44 X 0.20, clear	3M	SJ-5303 (CLEAR)
2	J1, J2	Conn term block, 2 position, 5.08 mm, TH	Phoenix Contact	1715721
2	L1, L2	Inductor, shielded drum core, metal composite, 1 mH, 0.5 A, 1.7 Ω , TH	Würth Elektronik	768772102
3	R1, R2, R12	Resistor, 6.8 k Ω , 5%, 0.25 W, 1206	Vishay-Dale	CRCW12066K80JNEA
1	R3	Resistor, 1.27 k Ω , 1%, 0.25 W, 1206	Vishay-Dale	CRCW12061K27FKEA
1	R5	Resistor, 1.50 k Ω , 1%, 0.25 W, 1206	Vishay-Dale	CRCW12061K50FKEA
1	R7	Resistor, 33.0 Ω , 1%, 0.25 W, 1206	Panasonic	ERJ-8ENF33R0V
1	R8	Resistor, 30.0 k Ω , 1%, 0.25 W, 1206	Panasonic	ERJ-8ENF3002V
1	R9	Resistor, 100.0 k Ω , 1%, 0.25 W, 1206	Vishay-Dale	CRCW1206100KFKEA
1	R10	Resistor, 430.0 k Ω , 1%, 0.25 W, 1206	Yageo America	RC1206FR-07430KL
1	RF1	Resistor, 4.7 Ω , 5%, 1 W, fusible, TH	Yageo America	FKN1WSJR-52-4R7
0	R4	Resistor, 15.0 k Ω , 1%, 0.25 W, 1206	Vishay-Dale	CRCW120615K0FKEA
0	R6	Resistor, 100 k Ω , 5%, 0.25 W, 1206	Vishay-Dale	CRCW1206100KJNEA
0	R11	Resistor, 180 Ω , 5%, 0.25 W, 1206	Vishay-Dale	CRCW1206180RJNEA
1	T1	Transformer, 825 μ H	Würth Elektronik eiSos	750315369
1	U1	High-Voltage Flyback Switcher with Primary-Side Regulation and Constant-Current Control, D0007A	Texas Instruments	UCC28911D
1	PCB	Printed Circuit Board	Any	PWR718

12 References

1. Datasheet, *UCC28910, UCC28911 High-Voltage Flyback Switcher with Constant-Current Control*, [Texas Instruments Literature Number, SLUS769](#).

STANDARD TERMS AND CONDITIONS FOR EVALUATION MODULES

1. *Delivery:* TI delivers TI evaluation boards, kits, or modules, including any accompanying demonstration software, components, or documentation (collectively, an "EVM" or "EVMs") to the User ("User") in accordance with the terms and conditions set forth herein. Acceptance of the EVM is expressly subject to the following terms and conditions.
 - 1.1 EVMs are intended solely for product or software developers for use in a research and development setting to facilitate feasibility evaluation, experimentation, or scientific analysis of TI semiconductors products. EVMs have no direct function and are not finished products. EVMs shall not be directly or indirectly assembled as a part or subassembly in any finished product. For clarification, any software or software tools provided with the EVM ("Software") shall not be subject to the terms and conditions set forth herein but rather shall be subject to the applicable terms and conditions that accompany such Software
 - 1.2 EVMs are not intended for consumer or household use. EVMs may not be sold, sublicensed, leased, rented, loaned, assigned, or otherwise distributed for commercial purposes by Users, in whole or in part, or used in any finished product or production system.
2. *Limited Warranty and Related Remedies/Disclaimers:*
 - 2.1 These terms and conditions do not apply to Software. The warranty, if any, for Software is covered in the applicable Software License Agreement.
 - 2.2 TI warrants that the TI EVM will conform to TI's published specifications for ninety (90) days after the date TI delivers such EVM to User. Notwithstanding the foregoing, TI shall not be liable for any defects that are caused by neglect, misuse or mistreatment by an entity other than TI, including improper installation or testing, or for any EVMs that have been altered or modified in any way by an entity other than TI. Moreover, TI shall not be liable for any defects that result from User's design, specifications or instructions for such EVMs. Testing and other quality control techniques are used to the extent TI deems necessary or as mandated by government requirements. TI does not test all parameters of each EVM.
 - 2.3 If any EVM fails to conform to the warranty set forth above, TI's sole liability shall be at its option to repair or replace such EVM, or credit User's account for such EVM. TI's liability under this warranty shall be limited to EVMs that are returned during the warranty period to the address designated by TI and that are determined by TI not to conform to such warranty. If TI elects to repair or replace such EVM, TI shall have a reasonable time to repair such EVM or provide replacements. Repaired EVMs shall be warranted for the remainder of the original warranty period. Replaced EVMs shall be warranted for a new full ninety (90) day warranty period.
3. *Regulatory Notices:*
 - 3.1 *United States*
 - 3.1.1 *Notice applicable to EVMs not FCC-Approved:*

This kit is designed to allow product developers to evaluate electronic components, circuitry, or software associated with the kit to determine whether to incorporate such items in a finished product and software developers to write software applications for use with the end product. This kit is not a finished product and when assembled may not be resold or otherwise marketed unless all required FCC equipment authorizations are first obtained. Operation is subject to the condition that this product not cause harmful interference to licensed radio stations and that this product accept harmful interference. Unless the assembled kit is designed to operate under part 15, part 18 or part 95 of this chapter, the operator of the kit must operate under the authority of an FCC license holder or must secure an experimental authorization under part 5 of this chapter.
 - 3.1.2 *For EVMs annotated as FCC – FEDERAL COMMUNICATIONS COMMISSION Part 15 Compliant:*

CAUTION

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Interference Statement for Class A EVM devices

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

FCC Interference Statement for Class B EVM devices

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

3.2 Canada

3.2.1 For EVMs issued with an Industry Canada Certificate of Conformance to RSS-210

Concerning EVMs Including Radio Transmitters:

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Concernant les EVMs avec appareils radio:

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Concerning EVMs Including Detachable Antennas:

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication. This radio transmitter has been approved by Industry Canada to operate with the antenna types listed in the user guide with the maximum permissible gain and required antenna impedance for each antenna type indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device.

Concernant les EVMs avec antennes détachables

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante. Le présent émetteur radio a été approuvé par Industrie Canada pour fonctionner avec les types d'antenne énumérés dans le manuel d'usage et ayant un gain admissible maximal et l'impédance requise pour chaque type d'antenne. Les types d'antenne non inclus dans cette liste, ou dont le gain est supérieur au gain maximal indiqué, sont strictement interdits pour l'exploitation de l'émetteur.

3.3 Japan

3.3.1 *Notice for EVMs delivered in Japan:* Please see http://www.tij.co.jp/lstds/ti_ja/general/eStore/notice_01.page 日本国内に輸入される評価用キット、ボードについては、次のところをご覧ください。
http://www.tij.co.jp/lstds/ti_ja/general/eStore/notice_01.page

3.3.2 *Notice for Users of EVMs Considered "Radio Frequency Products" in Japan:* EVMs entering Japan are NOT certified by TI as conforming to Technical Regulations of Radio Law of Japan.

If User uses EVMs in Japan, User is required by Radio Law of Japan to follow the instructions below with respect to EVMs:

1. Use EVMs in a shielded room or any other test facility as defined in the notification #173 issued by Ministry of Internal Affairs and Communications on March 28, 2006, based on Sub-section 1.1 of Article 6 of the Ministry's Rule for Enforcement of Radio Law of Japan,
2. Use EVMs only after User obtains the license of Test Radio Station as provided in Radio Law of Japan with respect to EVMs, or
3. Use of EVMs only after User obtains the Technical Regulations Conformity Certification as provided in Radio Law of Japan with respect to EVMs. Also, do not transfer EVMs, unless User gives the same notice above to the transferee. Please note that if User does not follow the instructions above, User will be subject to penalties of Radio Law of Japan.

【無線電波を送信する製品の開発キットをお使いになる際の注意事項】

本開発キットは技術基準適合証明を受けておりません。

本製品のご使用に際しては、電波法遵守のため、以下のいずれかの措置を取っていただく必要がありますのでご注意ください。

1. 電波法施行規則第6条第1項第1号に基づく平成18年3月28日総務省告示第173号で定められた電波暗室等の試験設備でご使用いただく。
2. 実験局の免許を取得後ご使用いただく。
3. 技術基準適合証明を取得後ご使用いただく。

なお、本製品は、上記の「ご使用にあたっての注意」を譲渡先、移転先に通知しない限り、譲渡、移転できないものとします。

上記を遵守頂けない場合は、電波法の罰則が適用される可能性があることをご留意ください。

日本テキサス・インスツルメンツ株式会社

東京都新宿区西新宿 6 丁目 2 4 番 1 号

西新宿三井ビル

3.3.3 *Notice for EVMs for Power Line Communication:* Please see http://www.tij.co.jp/llds/ti_ja/general/eStore/notice_02.page

電力線搬送波通信についての開発キットをお使いになる際の注意事項については、次のところをご覧ください。http://www.tij.co.jp/llds/ti_ja/general/eStore/notice_02.page

4 *EVM Use Restrictions and Warnings:*

4.1 EVMS ARE NOT FOR USE IN FUNCTIONAL SAFETY AND/OR SAFETY CRITICAL EVALUATIONS, INCLUDING BUT NOT LIMITED TO EVALUATIONS OF LIFE SUPPORT APPLICATIONS.

4.2 User must read and apply the user guide and other available documentation provided by TI regarding the EVM prior to handling or using the EVM, including without limitation any warning or restriction notices. The notices contain important safety information related to, for example, temperatures and voltages.

4.3 *Safety-Related Warnings and Restrictions:*

4.3.1 User shall operate the EVM within TI's recommended specifications and environmental considerations stated in the user guide, other available documentation provided by TI, and any other applicable requirements and employ reasonable and customary safeguards. Exceeding the specified performance ratings and specifications (including but not limited to input and output voltage, current, power, and environmental ranges) for the EVM may cause personal injury or death, or property damage. If there are questions concerning performance ratings and specifications, User should contact a TI field representative prior to connecting interface electronics including input power and intended loads. Any loads applied outside of the specified output range may also result in unintended and/or inaccurate operation and/or possible permanent damage to the EVM and/or interface electronics. Please consult the EVM user guide prior to connecting any load to the EVM output. If there is uncertainty as to the load specification, please contact a TI field representative. During normal operation, even with the inputs and outputs kept within the specified allowable ranges, some circuit components may have elevated case temperatures. These components include but are not limited to linear regulators, switching transistors, pass transistors, current sense resistors, and heat sinks, which can be identified using the information in the associated documentation. When working with the EVM, please be aware that the EVM may become very warm.

4.3.2 EVMs are intended solely for use by technically qualified, professional electronics experts who are familiar with the dangers and application risks associated with handling electrical mechanical components, systems, and subsystems. User assumes all responsibility and liability for proper and safe handling and use of the EVM by User or its employees, affiliates, contractors or designees. User assumes all responsibility and liability to ensure that any interfaces (electronic and/or mechanical) between the EVM and any human body are designed with suitable isolation and means to safely limit accessible leakage currents to minimize the risk of electrical shock hazard. User assumes all responsibility and liability for any improper or unsafe handling or use of the EVM by User or its employees, affiliates, contractors or designees.

4.4 User assumes all responsibility and liability to determine whether the EVM is subject to any applicable international, federal, state, or local laws and regulations related to User's handling and use of the EVM and, if applicable, User assumes all responsibility and liability for compliance in all respects with such laws and regulations. User assumes all responsibility and liability for proper disposal and recycling of the EVM consistent with all applicable international, federal, state, and local requirements.

5. *Accuracy of Information:* To the extent TI provides information on the availability and function of EVMs, TI attempts to be as accurate as possible. However, TI does not warrant the accuracy of EVM descriptions, EVM availability or other information on its websites as accurate, complete, reliable, current, or error-free.

6. *Disclaimers:*
- 6.1 EXCEPT AS SET FORTH ABOVE, EVMS AND ANY WRITTEN DESIGN MATERIALS PROVIDED WITH THE EVM (AND THE DESIGN OF THE EVM ITSELF) ARE PROVIDED "AS IS" AND "WITH ALL FAULTS." TI DISCLAIMS ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, REGARDING SUCH ITEMS, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT OF ANY THIRD PARTY PATENTS, COPYRIGHTS, TRADE SECRETS OR OTHER INTELLECTUAL PROPERTY RIGHTS.
- 6.2 EXCEPT FOR THE LIMITED RIGHT TO USE THE EVM SET FORTH HEREIN, NOTHING IN THESE TERMS AND CONDITIONS SHALL BE CONSTRUED AS GRANTING OR CONFERRING ANY RIGHTS BY LICENSE, PATENT, OR ANY OTHER INDUSTRIAL OR INTELLECTUAL PROPERTY RIGHT OF TI, ITS SUPPLIERS/LICENSORS OR ANY OTHER THIRD PARTY, TO USE THE EVM IN ANY FINISHED END-USER OR READY-TO-USE FINAL PRODUCT, OR FOR ANY INVENTION, DISCOVERY OR IMPROVEMENT MADE, CONCEIVED OR ACQUIRED PRIOR TO OR AFTER DELIVERY OF THE EVM.
7. *USER'S INDEMNITY OBLIGATIONS AND REPRESENTATIONS.* USER WILL DEFEND, INDEMNIFY AND HOLD TI, ITS LICENSORS AND THEIR REPRESENTATIVES HARMLESS FROM AND AGAINST ANY AND ALL CLAIMS, DAMAGES, LOSSES, EXPENSES, COSTS AND LIABILITIES (COLLECTIVELY, "CLAIMS") ARISING OUT OF OR IN CONNECTION WITH ANY HANDLING OR USE OF THE EVM THAT IS NOT IN ACCORDANCE WITH THESE TERMS AND CONDITIONS. THIS OBLIGATION SHALL APPLY WHETHER CLAIMS ARISE UNDER STATUTE, REGULATION, OR THE LAW OF TORT, CONTRACT OR ANY OTHER LEGAL THEORY, AND EVEN IF THE EVM FAILS TO PERFORM AS DESCRIBED OR EXPECTED.
8. *Limitations on Damages and Liability:*
- 8.1 *General Limitations.* IN NO EVENT SHALL TI BE LIABLE FOR ANY SPECIAL, COLLATERAL, INDIRECT, PUNITIVE, INCIDENTAL, CONSEQUENTIAL, OR EXEMPLARY DAMAGES IN CONNECTION WITH OR ARISING OUT OF THESE TERMS AND CONDITIONS OR THE USE OF THE EVMS PROVIDED HEREUNDER, REGARDLESS OF WHETHER TI HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. EXCLUDED DAMAGES INCLUDE, BUT ARE NOT LIMITED TO, COST OF REMOVAL OR REINSTALLATION, ANCILLARY COSTS TO THE PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES, RETESTING, OUTSIDE COMPUTER TIME, LABOR COSTS, LOSS OF GOODWILL, LOSS OF PROFITS, LOSS OF SAVINGS, LOSS OF USE, LOSS OF DATA, OR BUSINESS INTERRUPTION. NO CLAIM, SUIT OR ACTION SHALL BE BROUGHT AGAINST TI MORE THAN ONE YEAR AFTER THE RELATED CAUSE OF ACTION HAS OCCURRED.
- 8.2 *Specific Limitations.* IN NO EVENT SHALL TI'S AGGREGATE LIABILITY FROM ANY WARRANTY OR OTHER OBLIGATION ARISING OUT OF OR IN CONNECTION WITH THESE TERMS AND CONDITIONS, OR ANY USE OF ANY TI EVM PROVIDED HEREUNDER, EXCEED THE TOTAL AMOUNT PAID TO TI FOR THE PARTICULAR UNITS SOLD UNDER THESE TERMS AND CONDITIONS WITH RESPECT TO WHICH LOSSES OR DAMAGES ARE CLAIMED. THE EXISTENCE OF MORE THAN ONE CLAIM AGAINST THE PARTICULAR UNITS SOLD TO USER UNDER THESE TERMS AND CONDITIONS SHALL NOT ENLARGE OR EXTEND THIS LIMIT.
9. *Return Policy.* Except as otherwise provided, TI does not offer any refunds, returns, or exchanges. Furthermore, no return of EVM(s) will be accepted if the package has been opened and no return of the EVM(s) will be accepted if they are damaged or otherwise not in a resalable condition. If User feels it has been incorrectly charged for the EVM(s) it ordered or that delivery violates the applicable order, User should contact TI. All refunds will be made in full within thirty (30) working days from the return of the components(s), excluding any postage or packaging costs.
10. *Governing Law:* These terms and conditions shall be governed by and interpreted in accordance with the laws of the State of Texas, without reference to conflict-of-laws principles. User agrees that non-exclusive jurisdiction for any dispute arising out of or relating to these terms and conditions lies within courts located in the State of Texas and consents to venue in Dallas County, Texas. Notwithstanding the foregoing, any judgment may be enforced in any United States or foreign court, and TI may seek injunctive relief in any United States or foreign court.

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265
Copyright © 2015, Texas Instruments Incorporated

IMPORTANT NOTICE

Texas Instruments Incorporated and its subsidiaries (TI) reserve the right to make corrections, enhancements, improvements and other changes to its semiconductor products and services per JESD46, latest issue, and to discontinue any product or service per JESD48, latest issue. Buyers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All semiconductor products (also referred to herein as "components") are sold subject to TI's terms and conditions of sale supplied at the time of order acknowledgment.

TI warrants performance of its components to the specifications applicable at the time of sale, in accordance with the warranty in TI's terms and conditions of sale of semiconductor products. Testing and other quality control techniques are used to the extent TI deems necessary to support this warranty. Except where mandated by applicable law, testing of all parameters of each component is not necessarily performed.

TI assumes no liability for applications assistance or the design of Buyers' products. Buyers are responsible for their products and applications using TI components. To minimize the risks associated with Buyers' products and applications, Buyers should provide adequate design and operating safeguards.

TI does not warrant or represent that any license, either express or implied, is granted under any patent right, copyright, mask work right, or other intellectual property right relating to any combination, machine, or process in which TI components or services are used. Information published by TI regarding third-party products or services does not constitute a license to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

Reproduction of significant portions of TI information in TI data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations, and notices. TI is not responsible or liable for such altered documentation. Information of third parties may be subject to additional restrictions.

Resale of TI components or services with statements different from or beyond the parameters stated by TI for that component or service voids all express and any implied warranties for the associated TI component or service and is an unfair and deceptive business practice. TI is not responsible or liable for any such statements.

Buyer acknowledges and agrees that it is solely responsible for compliance with all legal, regulatory and safety-related requirements concerning its products, and any use of TI components in its applications, notwithstanding any applications-related information or support that may be provided by TI. Buyer represents and agrees that it has all the necessary expertise to create and implement safeguards which anticipate dangerous consequences of failures, monitor failures and their consequences, lessen the likelihood of failures that might cause harm and take appropriate remedial actions. Buyer will fully indemnify TI and its representatives against any damages arising out of the use of any TI components in safety-critical applications.

In some cases, TI components may be promoted specifically to facilitate safety-related applications. With such components, TI's goal is to help enable customers to design and create their own end-product solutions that meet applicable functional safety standards and requirements. Nonetheless, such components are subject to these terms.

No TI components are authorized for use in FDA Class III (or similar life-critical medical equipment) unless authorized officers of the parties have executed a special agreement specifically governing such use.

Only those TI components which TI has specifically designated as military grade or "enhanced plastic" are designed and intended for use in military/aerospace applications or environments. Buyer acknowledges and agrees that any military or aerospace use of TI components which have **not** been so designated is solely at the Buyer's risk, and that Buyer is solely responsible for compliance with all legal and regulatory requirements in connection with such use.

TI has specifically designated certain components as meeting ISO/TS16949 requirements, mainly for automotive use. In any case of use of non-designated products, TI will not be responsible for any failure to meet ISO/TS16949.

Products

Audio	www.ti.com/audio
Amplifiers	amplifier.ti.com
Data Converters	dataconverter.ti.com
DLP® Products	www.dlp.com
DSP	dsp.ti.com
Clocks and Timers	www.ti.com/clocks
Interface	interface.ti.com
Logic	logic.ti.com
Power Mgmt	power.ti.com
Microcontrollers	microcontroller.ti.com
RFID	www.ti-rfid.com
OMAP Applications Processors	www.ti.com/omap
Wireless Connectivity	www.ti.com/wirelessconnectivity

Applications

Automotive and Transportation	www.ti.com/automotive
Communications and Telecom	www.ti.com/communications
Computers and Peripherals	www.ti.com/computers
Consumer Electronics	www.ti.com/consumer-apps
Energy and Lighting	www.ti.com/energy
Industrial	www.ti.com/industrial
Medical	www.ti.com/medical
Security	www.ti.com/security
Space, Avionics and Defense	www.ti.com/space-avionics-defense
Video and Imaging	www.ti.com/video

TI E2E Community

e2e.ti.com