

# Power factor monitoring (cosφ) in 1- or 3-phase mains

### G2CU400V10AL10

Loadmonitors - GAMMA series

Underload monitoring

Fault latch

Recognition of disconnected consumers

Suitable for VFI (10 to 100Hz)

Supply voltage selectable via power modules / switching power supply

1 change-over contact

Width 22.5mm

Industrial design



## **Technical data**

#### 1. Functions

Underload monitoring  $(\cos\phi)$  in 1- or 3-phase mains with adjustable threshold, fixed hysteresis, seperately adjustable timing for start-up supression and tripping delay and the following functions which are selected by means of rotary switch:

UNDER Underload monitoring

UNDER+I<br/>
Underload monitoring with recognition of<br/>disconnected consumers (Rel.OFF if I=0)<br/>UNDER+LATCH<br/>UNDER+I<+LATCH<br/>UNDER+I<+LATCH<br/>Underload monitoring with fault latch<br/>Underload monitoring with fault latch and

recognition of disconnected consumers

(Rel.OFF if I=0)

2. Time ranges

Start-up suppression time: 1s 100s
Tripping delay: 0.1s 40s

3. Indicators

Green LED ON: indication of supply voltage
Green LED flashes: indication of start-up supression time

Yellow LED R ON/OFF: indication of relay output

Yellow LED I=0 ON/OFF: indication of disconnected consumers Red LED ON/OFF: indication of failure of the corresponding

threshold

Red LED flashes: indication of tripping delay of the

corresponding threshold

4. Mechanical design

Self-extinguishing plastic housing, IP rating IP40 Mounted on DIN-Rail TS 35 according to EN 60715

Mounting position: any

Shockproof terminal connection according to VBG 4 (PZ1 required),

IP rating IP20. Tightening torque: max. 1Nm

Terminal capacity:

1 x 0.5 to 2.5mm<sup>2</sup> with/without multicore cable end 1 x 4mm<sup>2</sup> without multicore cable end 2 x 0.5 to 1.5mm<sup>2</sup> with/without multicore cable end 2 x 2.5mm<sup>2</sup> flexible without multicore cable end

5. Input circuit

Supply voltage: terminals A1-A2 (galvanically separated)
12 to 400V a.c. selectable via power modules TR2 or
24V d.c. via switching power supply SNT2
Tolerance: according to specification TR2 / SNT2
Rated frequency: according to specification TR2 / SNT2

Rated consumption: 2VA (1.5W)
Duration of operation: 100%
Reset time: 500ms

Drop-out voltage: >30% of the supply voltage
Overvoltage category: III (in accordance with IEC 60664-1)

Rated surge voltage: 4kV

Residual ripple for d.c.

6. Output circuit

1 potential free change-over contact Rated voltage: 250V a.c.

Switching capacity: 750VA (3A / 250V a.c.)
If the distance between the devices is less than 5 mm.
Switching capacity: 1250VA (5A / 250V a.c.)
If the distance between the devices is greater than 5 mm.

Fusing: 5A fast acting
Mechanical life: 20 x 10<sup>6</sup> operations
Electrical life: 2 x 10<sup>5</sup> operations
at 1000VA resistive load

Switching frequency: max. 60/min at 100VA resistive load max. 6/min at 100VA resistive load

(in accordance with IEC 60947-5-1)
III (in accordance with IEC 60664-1)

Rated surge voltage: 4k\

7. Measuring circuit

Overvoltage category:

Measured variable: a.c. Sinus (10 to 100Hz)

Measuring-input voltage:

1-phase mains 40 to 415V a.c.

(max. 300V against ground) terminals L1i-L2/L3

3-phase mains 3~ 40/23 to 415/240V, terminals L1i-L2-L3

Overload capacity:

1-phase mains 500V 3-phase mains 3~ 500/289V Input resistance: ≥1MΩ

Measuring-input current: 0.5 to 10A, terminals L1i-L1k

(for I>8A distance >5mm)

Overload capacity: 11A permanently Input resistance:  $5m\Omega$ Switching threshold  $cos\phi$ : 0.1 to 1.0 Hysteresis: fixed, approx. 3°

fixed, approx.  $3^{\circ}$  (equivalent to 3% at  $\cos \varphi = 0.8$ )

Overvoltage category: III (in accordance with IEC 60664-1)

Rated surge voltage: 4kV

8. Accuracy

Base accuracy:  $\pm 5\%$  (equivalent to 5% at  $\cos \varphi = 0.8$ )

Frequency response:

Adjustment accuracy:  $\leq 5\%$  (at  $\cos \varphi = 0.8$ )

Repetition accuracy:  $\pm 1.8^{\circ}$  (equivalent to 1.8% at  $\cos \varphi = 0.8$ )

Voltage influence:

Pollution degree:

Temperature influence: ≤0.1% / °C

9. Ambient conditions

Ambient temperature: -25 to +55°C (in accordance with IEC 60068-1)

-25 to +40°C (in accordance with UL 508)

 $\begin{array}{lll} \text{Storage temperature:} & -25 \text{ to } +70^{\circ}\text{C} \\ \text{Transport temperature:} & -25 \text{ to } +70^{\circ}\text{C} \\ \text{Relative humidity:} & 15\% \text{ to } 85\% \end{array}$ 

(in accordance with IEC 60721-3-3 class 3K3)

3 (in accordance with IEC 60664-1)

Vibration resistance: 10 to 55Hz 0.35mm

(in accordance with IEC 60068-2-6)

Shock resistance: 15g 11ms

(in accordance with IEC 60068-2-27)


## **Functions**

When the supply voltage U is applied, the output relay switches into on-position (yellow LED R) and the set interval of the start-up suppression (START) begins (green LED U flashes). If the current doesn't flow during the start-up supression the yellow LED I=0 is illuminated.

Changes of the measured power factor  $(\cos\phi)$  during this period do not affect the state of the output relay. After the interval has expired the green LED is illuminated steadily.

### Underload monitoring (UNDER, UNDER+LATCH)


When the measured power factor falls below the value adjusted at the MIN-regulator, the set interval of the tripping delay (DELAY) begins (red LED MIN flashes). After the interval has expired (red LED MIN illuminated), the output relay switches into off-position (yellow LED R not illuminated). The output relay again switches into on-position (yellow LED R illuminated), when the measured power factor exceeds the value adjusted at the MIN-regulator by more than the fixed hysteresis.



### Underload monitoring with fault latch (UNDER+LATCH)

When the measured power factor falls below the value adjusted at the MIN-regulator, the set interval of the tripping delay (DELAY) begins (red LED MIN flashes). After the interval has expired (red LED MIN illuminated), the output relay switches into off-position (yellow LED R not illuminated). If the measured power factor exceeds the value adjusted at the MIN-regulator by more than the fixed hysteresis, the ouput relay stays in off-position.

After resetting the failure (interrupting and re-applying the supply voltage), the output relay switches into on-position and a new measuring cycle begins with the set interval of the start-up suppression.



#### Recognition of disconnected consumers


#### Overview:

Function	U	U + <del> </del> <	U +  < + L
Relay if I=0	ON	OFF	OFF
LED I=0 if I=0	ON	ON	ON
Fault latch	no	no	yes


When the current flow between i and k is interrupted and no fault has been stored, the output acts as shown in the table.

When the current flow is restored, the measuring cycle is restarted with the set interval of the start-up supression.(START).


### UNDER



#### UNDER + I<



UNDER + I< + L




### Fault latch (+LATCH)

If the fault latch is activated (+L), the recognition of disconnected consumers is not stored. The fault latch only stores failures of underload monitoring!


After the interval of the start-up surpression the output relay switches into on-position if the current flow is restored, the measured power factor remains above the set threshold and his hysteresis and no failure is stored.

# **Functions**


Connected to 3~ 400V mains with power module 24V a.c. without fault latch  $\mathbf{l_{u}} \!\!<\! \! 10\mathbf{A}$ 



Connected to 1~ 230V mains with power module 230V a.c. without fault latch  $~{\bf I_h}{<}{\bf 10A}$ 




Connected to 3~ 400V mains with power module 400V a.c. and fault latch  $~{\rm I_N}{<}10{\rm A}$ 




# **Connections**

Connected to 3~ 400V mains with power module 400V a.c. and fault latch  $I_{\rm N}\!\!>\!\!10A$ 



# **Dimensions**



### For your information:

Devices with batch number 205102 and below doesn't have an additional reversed recognition of disconnected consumers (+I<). They recognize disconnected consumers always as "good"-state which means the output relay switches into on-position (LED I=0 illuminated) if the current flow is interrupted and no fault is stored.

RELEASE 2015/11

Subject to alterations and errors

