OMRON

Switching Power Supply

S82J

Compact and Economical Switching Power Supplies with Capacities Up to 600 W

- Power range from 10 W up to 600 W.
- Output Voltages: 5 V, 12 V, 15 V, or 24 V.
- Wide AC input range

50-/100-W, 24-V output models: 100 to 240 VAC on one body 150-W models: 100 or 200 VAC selected automatically 300-/600-W models: 100 or 200 VAC selectable

- Open-frame and covered types available.
- Top terminal- and connector-type available in addition to front terminal type (100-/150-W models).
- Mounting brackets provided for mounting to control panels.
- Easily mounted to DIN track with S82Y (sold separately).
- Maintenance-free up to 300 W due to natural ventilation.
- Protection-ON alarm indicator shows valuable protection functions in action (300-/600-W models).
- Conforms to EMC standards: EN50081-2 and EN50082-2.
- With an external filter, achieves conformance to EN50081-1 for universal usage on EMI (300-/600-W models).
- Finger protection terminal block to meet VDE0106/P100 (50-/100-/150-W, 24-V output, covered type)
- Class 2 approved (50-W, 24-V output models)
- The UL Listed Power Supplies (50-/100-/150-W, 24-V output models) can be used at full rated power at any location
- Approved by UL/CSA standards, EN60950, and EN50178 (VDE0160).
- Six-language instruction manual provided.



S82J


Open-frame Type

<10 W to 100 W>

- 100-VAC input
- 200-VAC input
- 100 to 240 VAC (50-/100-W 24-V output models)

<150 W>

• 100 or 200 VAC (selected automatically)




<10 W to 100 W>

- 100-VAC input
- 200-VAC input
- 100 to 240 VAC (50-/100-W 24-V output models)

<150 W>

 100 or 200 VAC (selected automatically)



<300/600 W>

• 100 or 200 VAC (selectable)

■ S82J

Configuration	Input Voltage	Power ratings	Output voltage	Output current	Front terminals	Top terminals	Connector
Open-frame	100 VAC	10 W	5 V	2 A	S82J-0105		
type			12 V	1 A	S82J-0112		
			15 V	0.7 A	S82J-0115		
			24 V	0.5 A	S82J-0124		
		25 W	5 V	5 A	S82J-0205		
			12 V	2.1 A	S82J-0212		
			15 V	1.7 A	S82J-0215		
			24 V	1.1 A	S82J-0224		
		50 W	5 V	10 A	S82J-0505		
			12 V	4.2 A	S82J-0512		
		100 W	5 V	20.0 A	S82J-10005A1	S82J-10005B1	S82J-10005C1
			12 V	8.5 A	S82J-10012A1	S82J-10012B1	S82J-10012C1
			15 V	7.0 A	S82J-10015A1	S82J-10015B1	S82J-10015C1
	200 VAC	10 W	5 V	2 A	S82J-2105		
			12 V	1 A	S82J-2112		
			15 V	0.7 A	S82J-2115		
			24 V	0.5 A	S82J-2124		
		25 W	5 V	5 A	S82J-2205		
			12 V	2.1 A	S82J-2212		
			15 V	1.7 A	S82J-2215		
			24 V	1.1 A	S82J-2224		
		50 W	5 V	10 A	S82J-2505		
			12 V	4.2 A	S82J-2512		
		100 W	5 V	20.0 A	S82J-10005A2	S82J-10005B2	S82J-10005C2
			12 V	8.5 A	S82J-10012A2	S82J-10012B2	S82J-10012C2
			15 V	7.0 A	S82J-10015A2	S82J-10015B2	S82J-10015C2
	100 to	50 W	24 V	2.1 A	S82J-05024A		
	240 VAC	100 W	24 V	4.5 A	S82J-10024A		
	100 or 200 VAC (selected automatically)	150 W	24 V	6.5 A	S82J-15024A	S82J-15024B	S82J-15024C

Configuration	Input Voltage	Power ratings	Output voltage	Output current	Front terminals	Top terminals	Connector
Covered type	100 VAC	10 W	5 V	2 A	S82J-5105		
			12 V	1 A	S82J-5112		
			15 V	0.7 A	S82J-5115		
			24 V	0.5 A	S82J-5124		
		25 W	5 V	5 A	S82J-5205		
			12 V	2.1 A	S82J-5212		
			15 V	1.7 A	S82J-5215		
			24 V	1.1 A	S82J-5224		
		50 W	5 V	10 A	S82J-5505		
			12 V	4.2 A	S82J-5512		
		100 W	5 V	20.0 A	S82J-10005D1	S82J-10005E1	S82J-10005F1
			12 V	8.5 A	S82J-10012D1	S82J-10012E1	S82J-10012F1
			15 V	7.0 A	S82J-10015D1	S82J-10015E1	S82J-10015F1
	200 VAC	10 W	5 V	2 A	S82J-6105		
			12 V	1 A	S82J-6112		
			15 V	0.7 A	S82J-6115		
			24 V	0.5 A	S82J-6124		
		25 W	5 V	5 A	S82J-6205		
			12 V	2.1 A	S82J-6212		
			15 V	1.7 A	S82J-6215		
			24 V	1.1 A	S82J-6224		
		50 W	5 V	10 A	S82J-6505		
			12 V	4.2 A	S82J-6512		
		100 W	5 V	20.0 A	S82J-10005D2	S82J-10005E2	S82J-10005F2
			12 V	8.5 A	S82J-10012D2	S82J-10012E2	S82J-10012F2
			15 V	7.0 A	S82J-10015D2	S82J-10015E2	S82J-10015F2
	100 to	50 W	24 V	2.1 A	S82J-05024D		
	240 VAC	100 W	24 V	4.5 A	S82J-10024D		
	100 or 200 VAC (selected automatically)	150 W	24 V	6.5 A	S82J-15024D	S82J-15024E	S82J-15024F
Enclosure	100 or 200	300 W	24 V	14.0 A	S82J-30024		
type	VAC (selectable)	600 W	24 V	27.0 A	S82J-60024		
	(selectable)	300 W	24 V	14.0 A	S82J-30024N		
		600 W	24 V	27.0 A	S82J-60024N		

Model Number Legend:

50 (24 V)-/100-/150-/300-/600-W Models

•	_	_	 =	_	=	_	=
S82J -							

1.Power Ratings	2. Output Voltage			
050: 50 W	05: 5 V			
100: 100 W	12: 12 V			
150: 150 W	15: 15 V			
300: 300 W	24: 24 V			
600: 600 W				

4. Input Voltage 1: 100 VAC 200 VAC

None: 100 or 200 VAC, selectable (for 300-/600-W models) 100 or 200 VAC, selected automatically (for 150-W model) 100 to 240 VAC (for 50-/100-W, 24-V output models)

10-/25-/50 (5, 12 V)-W Models

S82J -			
	1	2	 3

1.Input Voltage/Configuration 2. Power Ratings 10 W 1:

3. Configuration

Open-frame type, front terminals Open-frame type, top terminals Open-frame type, connector A: B: C: D: Covered type, front terminals E: F: Covered type, top terminals Covered type, connector Without Mounting Brackets

None: Enclosure type, front terminals with

Mounting Brackets

3. Output Voltage

0: 100 VAC/Open-frame type 2: 200 VAC/Open-frame type 5: 100 VAC/Covered type 6: 200 VAC/Covered type 05: 5 V 25 W 12: 12 V 15: 15 V 50 W 24: 24 V

■ Accessories (Order Separately)

Name	S82J-□1□□	\$82J-□2□□	S82J-□5□□	\$82J-100 \\ \$82J-15024 \\ \\ \	S82J-30024□ S82J-60024□
DIN Track Mounting Bracket	S82Y-01N	S82Y-03N	S82Y-05N	S82Y-10N	
Mounting Bracket	S82Y-J10F for 100 W, 24 V (F-type) only				
Fan					S82Y-JFAN for 600-W models only
Ferrite Ring Core					S82Y-JC-T (set of 3 pieces in package)
Noise Filter					S82Y-JF3-N (for 30- W models) S82Y-JF6-N (for 600-W models)
Mounting Track	PFP-100N, PFP-50	N, PFP-100N2			

Specifications —

■ Ratings/Characteristics

	Item		10	00 VAC inpu	ut/200 VAC inp	out		200 VAC ctable)	100 to 240	VAC input	100 or 200 VAC (selected automatic ally)
			10 W	25 W	50 W (5, 12 V)	100 W (5, 12, 15 V)	300 W	600 W	50 W (24 V)	100 W (24 V)	150 W
Efficiency (t	ypical)		67% min.			76% min.	82% min.		77% min.	83% min.	82% min.
Input	Voltage	100 VAC input 200 VAC input	(see note 1	AC (85 to 132 VAC), 110 to 170 VDC ote 1) 100 (85 to 132) or 200 (170 to 253) VAC (selectable) 100 to 240 VAC (85 to 132) or 200 (170 to 253) VAC (selectable)		VAC (85 to	100 (85 to 132) or 200 (170 to 264) VAC (selected automatical ly)				
	Frequency		50/60 Hz (4	7 to 450 Hz)		1		l		ן עי
	Current	100 VAC	0.35 A	0.8 A	1.4 A	2.5 A	8 A max.	14 A max.	1.4 A	2.5 A	3.5 A max.
	(see note	input	max.	max.	max.	2.071	o / max.	117tmax.	max.	max.	o.o / t max.
	2)	200 VAC	0.3 A	0.6 A	0.8 A	1.4 A	4 A max.	7 A max.	0.8 A	1.5 A	2.1 A max.
		input	max.	max.	max.				max.	max.	
	Leakage current	100 VAC input	0.5 mA max	Κ.							
	(see note 2)	200 VAC input	1 mA max.								
	Inrush current (25°C,	100 VAC input	25 A max.					30 A max.	25 A max.		
	cold start) (see note 2)	200 VAC input	50 A max. 60 A max. 50 A max.								
	Noise filter		Yes					1	1		
Output (see note	Voltage adju	ustment	±10% (adjustable with variable resistor (V.ADJ))								
3)	Ripple (see	note 2)	2% (p-p) ma	ax.							
	Input variation influence	100 VAC input	/AC 0.4% max. (at 85 to 132 VAC input, 100% load) 0.4% max.								
		200 VAC input			64 VAC input,						
	Load variati influence				nput, 10% to 1						
	Temperature influence	e variation	0.03%/ СП	iax. (Willi Ia	ted input and o	output)					
	Rise time		200 ms ma rated input		% of output vol	tage at	300 ms ma 90% of outp at rated inp output)	out voltage		n. (up to 90% ated input an	
	Hold time (s	see note 2)	20 ms min.								
Additional function	ditional Overload protection 105% min. of rated load current, inverted L drop ty			nut OFF wher	n the overload	reset (For d exceeds	105 to 160° load curren drop/Interm operation ty automatic r	t, inverted L nittent /pe,	105% min. of rated load current, inverted L drop type, automatic reset		
	Overvoltage (see note 5)	•	No			Yes (5-V output models only)	Yes, protect alarm indicate		No	Yes	No
	Overheat pr	otection	No					Yes, protection -ON alarm indicator lit (see note 4)	No		
	Protection-C indicator	On alarm	No				Yes (color, red) No				
	Parallel ope	ration	No				Yes, 5 units	max.	No	<u></u>	
Series operation No Yes					Yes						

	Item		10	00 VAC input	t/200 VAC inp	put		200 VAC ctable)	100 to 240	VAC input	100 or 200 VAC (selected automatic ally)	
			10 W	25 W	50 W (5, 12 V)	100 W (5, 12, 15 V)	300 W	600 W	50 W (24 V)	100 W (24 V)	150 W	
Other	Ambient ter	mperature				the Engineering		on.	T.	•		
	Ambient hu	midity	Operating: Storage: 28	25% to 85% 5% to 90%	`		<u> </u>					
	Dielectric st	trength	3.0 kVAC,	50/60 Hz for	1 min (betwee	en all inputs a	nd all outputs)				
				50/60 Hz for outs/GR termin		en all inputs	2.2 kVAC, 5 terminals)	50/60 Hz for	1 min (betwee	n all inputs a	nd GR	
							1.0 kVAC, 5 terminal)	50/60 Hz for	1 min (betwee	n all outputs	and GR	
	Insulation re	esistance	100 MΩ mi	n. (between a	all outputs and	d all inputs/GF	R terminals at	500 VDC)				
	Vibration re	sistance	10 to 55 Hz	z, 0.375-mm (double amplit	ude for 2 h ea	ich in X, Y, an	d Z direction	S			
	Shock resis	stance	294 m/s ² , 3	3 times each i	in ±X, ±Y, and	±Z directions	5					
	Terminal screw tightening torque		0.74 N • m 1.08 N • m					0.74 N • m		1.08 N • m		
	Output indicator		Yes (green)								
	Electromag interference 2)	Conforms to FCC Class A										
	EMC		Emission A Immunity E Immunity R	Emission Enclosure: EN55011 class A Emission AC Mains: EN55011 class A Immunity ESD: EN61000-4-2: 4 kV contact discharge (level 3) Immunity RF-interference: ENV50140: 10 V/m² (80 MHz to 1 GHz) (Immunity Conducted Disturbance: ENV50141: 10 V (0.5 to 80 MHz) (Immunity Burst: EN61000-4-4: 2 kV power-line (level 3) 2 kV output line (level 4)								
	Approved standards		Conforms t	Conforms to EN50081-2 and EN50082-2						Conforms to EN50081-2 and EN50082-2		
			UL508/101	UL508/1012 UL508			UL508/1012	2	Class 2 (per UL1310), UL508 (Listing)/ 1950	UL508 (List 1012/1950 (see note 8	0,	
		CSA	CSA C22.2	2 No. 14			CSA EB140	02C	Class 2 (per CSA C22.2 No. 950), CSA C22.2 No. 14/ No. 950	CSA C22.2 950	No. 14/No.	
		VDE	EN50178 (VDE0160) an	nd EN60950				EN50178 (\	EN50178 (VDE0160) and EN60950 For covered types, conforms to VDE		

Weight

- Note: 1. DC inputs not included in safety standard approvals.
 - 2. At 100% load for rated input voltage (100 VAC or 200 VAC).

250 g max. (see

note 9)

3. The output specification is defined at the power supply output terminals.

350 g

note 9)

max. (see

4. For resetting, turn OFF the power supply, leave for more than three minutes, and then turn ON the power supply.

400 g max. (see

5. For resetting, turn OFF the power supply, leave for more than one minutes (90 seconds min. for the 300-W models and 3 minutes min. for the 600-W models), and then turn ON the power supply.

1,000 g

max.

2,000 g

max.

2,500 g

max.

0106/P100

600 g

max.

1,000 g

max.

500 g

max.

- 6. To ensure the Emission Enclosure rating ferrite ring cores (recommended model: S82Y-JC-T) should be used on all cabling.
- 7. To ensure the Emission AC Mains rating for EN50081-1 (only for 200-VAC input), a nose filter (recommended models: S82Y-JF3-N for 300-W, S82Y-JF6-N for 600-W) should be used on the input lines.
- 8. With UL508, 150-W connector type has "Recognized" approval.
- 9. The weight indicated is the weight of the open-frame type.


■ Reference Value

Item	Value		Definition		
Reliability (MTBF)	135,000 hours		MTBF stands for Mean Time Between Failures, which is calculated according to the probability of accidental device failures, and indicates reliability of devices. Therefore, it does not necessarily represent a life of the product.		
Life expectancy	10-/25-/50 (5, 12 V)-/100 (5, 12, 15 V)-/150-W Models	8 yrs. Min.	The life expectancy indicates average operating hours un the ambient temperature of 40°C and a load rate of 50%.		
	50 (24 V)-/100 (24 V)-/ 300-/600-W Models		Normally this is determined by the life expectancy of the built-in aluminum electrolytic capacitor.		


Engineering Data

■ Derating Curve 10-/25-/50-/100 (24 V)-/150-W Model


Open-frame type



Covered-type




Standard Installation




Note: The derating curve shown is for standard installation. The derating curve depends on the mounting direction of the Power Supply.

100 (5, 12, 15 V)-W Model


Open-frame Type




Covered Type



Standard Installation



Note: The derating curve shown is for standard installation. The derating curve depends on the mounting direction of the Power Supply.




Note: Provide a minimum clearance of 20 mm between the Power Supplies.


Overload Protection

10- to 300-W Models

The Power Supply is provided with an overload protection function that protects the load and the power supply from possible damage by overcurrent. When the output current rises above 105% of the rated output current (105% to 160% of the rated output current for 50 (24 V)-W and 100 (24 V)-W models), the protection function is triggered, decreasing the output voltage. When the output current falls within the rated range, the overload protection function is automatically cleared.

10- to 300-W Models (except for 50 (24 V)-W and 100 (24 V)-W Models)





600-W Models


If an excessive current flows for 5 s or more, the output will be turned off and simultaneously protection-ON alarm indicator will be lit. To reset the S82J, turn off the input voltage, leave the S82J for at least three minutes, and then apply the input voltage again.

Note: Do not continue using the S82J with the output terminals short-circuited or the overcurrent condition continued, otherwise the internal elements of the S82J may be damaged or broken.

■ Overvoltage Protection

100 (5, 24 V)-W Models

The Power Supply is provided with an overvoltage protection function that protects the load and the Power Supply from possible damage by overvoltage. When the output voltage rises above a set value (120% of the rated output voltage), the protection function is triggered, shutting off the output voltage. If this occurs, reset the Power Supply by turning it off for 1 minutes min. and then turning it on again.




300- and 600-W Models

If a voltage that is 120% of the rated output voltage or above is output, the output voltage will be turned off and simultaneously protection-ON alarm indicator will be lit. To reset the S82J, turn off the input voltage, leave the S82J for at least three minutes if it is a 600-W model or at least 90 seconds if it is a 300-W model, and then apply the input voltage again.

■ Overheat Protection Function 600-W Model Only


If the internal temperature of the S82J rises excessively as a result of fan failure or any other reason, the overheat protection circuit will be triggered to protect the internal elements of the S82J and simultaneously a protection-ON alarm indicator will be lit. To reset the S82J, turn off the input voltage, leave the S82J for at least three minutes, and then apply the input voltage again.

■ Inrush Current, Rise Time, Hold Time





Operation -

■ Block Diagrams




S82J-05024□ (50 W, 24-V Output)








S82J-10024 (100 W, 24-V Output)



S82J-15024 (150 W)









Dimensions

Note: All units are in millimeters unless otherwise indicated.




Mounting Holes (Surface Screw Mounting)

Side Mounting




Bottom Mounting






Mounting Holes (Surface Screw Mounting)

Side Mounting




Bottom Mounting







Mounting Holes


Side Mounting



Bottom Mounting









Dimensions with Provided Mounting Brackets

10-/25-/50-/100 (24 V)-W Models




Mounting Holes




Using the Mounting Bracket

Attach the mounting bracket to the panel and loosely tighten the two screws. Insert the projected parts of the bracket (b) to the square holes of the power supply (a). Then securely tighten the screws.


Note: The mounting screws are order separately.




100- (5, 12, 15 V) and 150-W Models




300-W Models



600-W Models





Note: To provide ventilation space, the body will shift forward by 23.6 mm from the mounting surface.


Accessories (Order Separately)

DIN Track Mounting Bracket


By attaching the DIN Track Mounting Bracket to the Switching Power Supply, the Switching Power Supply can be mounted to a DIN-track with ease.

Item	S82Y-01N	S82Y-03N	S82Y-05N	S82Y-10N
Applicable supply unit	S82J-□1□□	S82J-□2□□	S82J-□5□□	S82J-100□□□□ S82J-15024□
Dimensions	Power Supply L1 L2	PFP-100N or PFP-100N2 DIN track	47 104 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	
Dimensions: L1	113 mm	143 mm	163 mm	185 mm
L2 (see note)	114.8 mm	144.8 mm	164.8 mm	186.8 mm

Note: The values given for L2 are for when the PFP-100N Mounting Track is used. If the PFP-100N2 is used, added 10.5 mm to the values given for L2.




Mounting Track PFP-100N/PFP-50N




Note: The values shown in parentheses are for the PFP-50N.


PFP-100N2




S82J










Noise Filter S82Y-JF3-N for 300-W Models S82Y-JF6-N for 600-W Models






Model	Α	В	С	D
S82Y-JF3-N	107	75	90	26
S82Y-JF6-N	117	85	100	30

Front-mounting Bracket for 100-W, 24-V (F-type)

S82Y-J10F




Mounting Holes





Note: The Front Mounting Bracket cannot be used for 5-, 12-, or 15-V S82J (100-, 150-W models).

Installation

10-/25-/50-/100-/150-W Models Note: 10-/25-/50-/100 (24 V)-W models are available only as Front Terminal Models.








Connectors

Connector	Connector on the PCB side	Housing	Terminal
Input	Wafer (Made by Molex) 5277-04A-RE	Housing (Made by Molex) 5196-04-RE or 5196-04	Terminal (Made by Molex) 5194T or 5194TL
Output	Tab header (Made by Nippon AMP) 1-178140-5	Rise housing (Made by Nippon AMP) 1-178129-6	Rise contact (Made by Nippon AMP) 1-175196-5 or 1-175218-5

Note: The permissible current of the output connector is 8 A per pin.

300-W Models

600-W Models



- ${\bf 1.}\ \ \textbf{DC Output Terminals:}\ Connect\ the\ load\ lines\ to\ these\ terminals.$
- 2. **Input Terminals:** Connect the input lines to these terminals.
 - Note: A fuse is inserted into the AC (L) side.
- 3. Ground Terminal (GR): Connect a ground line to this terminal.
- 4. Input Voltage Terminals: Short-circuit the terminals if the input is 100 to 120 VAC and open the terminals if the input is 200 to 230 VAC
- 5. Output Indicator (DC ON): Lights while a Direct Current (DC) output is ON.
- 6. Output Voltage Adjuster (V.ADJ): It is possible to increase or decrease the output voltage by 10%.
- 7. **Protection-ON Alarm Indicator:** The red indicator will be lit if the overvoltage (for a 300-/600-W model) or overheat protection (for a 600-W model) circuit is triggered. This indicator will also be lit when overcurrent (for a 600-W model) is detected.
- 8. Parallel/Single Operation Selector: Set the selector to PARALLEL if the Units are in parallel operation.
- 9. **NC Terminals:** Leave unconnected.

Precautions

Mounting


To improve and maintain the reliability of the Power Supply over a long period of time, adequate consideration must be given to heat radiation.

The Power Supply is designed to radiate heat by means of natural air-flow. Therefore, mount the Power Supply so that air flow takes place around the Power Supply.

When mounting the Power Supply, mounting it to a metal plate is recommended.

When mounting two or more Power Supplies side-by-side, allow at least 20 mm spacing between them, as shown in the following illustration

Forced air-cooling is recommended.




Mounting Methods

The following mounting methods are available.


10-/25-/50-/100 (24 V)-W Models

- (A) Side mounting
- (B) Bottom mounting
- (C) Front mounting (see Accessories)




100 (5, 12, 15 V)/150-/300-/600-W Models

- (A) Side mounting
- (B) Bottom mounting (secured with screws from the inside of the Switching Power Supply)
- (C) Bottom mounting (secured with screws from the back of the Switching Power Supply)




(D) Front mounting

Front mounting is possible with the mounting brackets provided. Refer to *Dimensions*.



Generating Output Voltage (±)

An output of \pm can be generated by using two Power Supplies as shown below, because the Power Supply produces a floating output.



If operation amplifiers as loads are connected in series, connect a diode between the positive and negative output terminals of each Switching Power Supplies as shown in the illustration below. Without these diodes, the Power Supplies may not start when power is turned on, possibly damaging internal circuits over a period of time.


Use Schottky barrier diodes with a low forward voltage (V_F). Other types of diodes will not be effective.

Guidelines for the dielectric strength and current of the diodes are as follows:

Dielectric strength: At least twice the rated output voltage of the Power Supply

Forward current: At least twice the rated output current


No diodes are required for models that allow series operation.



Series Operation

Only models with power ratings of 50 (24 V)/100/150/300/600 W allow series operation.

As shown in the following diagram, the output voltage from each Switching Power Supply can be added.



With the S82J-05024 \square or S82J-10024 \square , if the load is shorted a reverse voltage may result in the Power Supply causing deterioration and damage. It is recommended that diodes are connected as shown in the previous diagram (D₁, D₂).

Parallel Operation


Only 300- and 600-W models can be in parallel operation. Do not operate any other models in parallel. The output of the models in parallel operation is a maximum of 80% of the rated output.

Set the parallel operation selector to PARALLEL if the Units are in parallel operation and make sure that the thickness and the length of all wires connected to the load are the same to ensure that the wires will have no voltage drop differences.

Fan Replacement

The service life of the fan is approximately 50,000 hours (at 25° C). The service life varies, however, depending on the ambient temperature or other surrounding environmental conditions such as dust. As a preventive maintenance measure, replace the fan within two years if it is used at an ambient temperature of 40° C.

Fans are available as replacements.




Model: S82Y-JFAN

Fan Set:

Fan (above), four M4 x 35 sems screws, instruction sheet, and packing case $\,$

Replace the fan as shown in the following illustration.



ALL DIMENSIONS SHOWN ARE IN MILLIMETERS.

 $To \ convert \ millimeters \ into \ inches, \ multiply \ by \ 0.03937. \ To \ convert \ grams \ into \ ounces, \ multiply \ by \ 0.03527.$

Cat. No. M047-E1-5 In the interest of product improvement, specifications are subject to change without notice.

OMRON Corporation

Industrial Automation Company

Measuring and Supervisory Controls Division 28th Fl., Crystal Tower Bldg., 1-2-27, Shiromi, Chuo-ku, Osaka 540-6028 Japan Tel: (81)6-6949-6035/Fax: (81)6-6949-6069

Printed in Japan 0200-1M (A)