

MATERIALS

1. OUTER INSULATION SLEEVE: Heat-shrinkable, radiation cross-linked modified fluoropolymer. Color: black.

2. SHIM SLEEVE: Heat-shrinkable, radiation cross-linked fluoroelastomer. Color: black.

- 3. BRAID: Nickel-plated copper alloy.
- 4. & 5. SOLDERSLEEVES:

INSULATION SLEEVE: Heat-shrinkable, transparent blue, radiation cross-linked modified polyvinylidene fluoride. SOLDER PREFORM WITH FLUX AND THERMAL INDICATOR:

- SOLDER: TYPE Sn96 per ANSI-J-STD-006.
- FLUX: TYPE ROM1 per ANSI-J-STD-004.
- THERMAL INDICATOR: Color changes from orange to colorless.

MELTABLE RINGS: Environment resistant thermoplastic. Color: blue.

6. SEALING SLEEVE: Qty: 2

INSULATION SLEEVE: Heat-shrinkable, transparent blue, radiation cross-linked modified polyvinylidene fluoride. SEALING RINGS: Immersion resistant thermoplastic. Color: one clear, one red.

7. CRIMP SPLICE: Nickel-plated copper alloy. Color code: red, Qty: 2 BASE METAL: Copper Alloy 101 or 102 per ASTM B-75.

PLATING: Ductile Nickel per SAE AMS-QQ-N-290.

tyco Electronics		Raychem Products 305 Constitution Drive Menlo Park, CA 94025, USA	TITLE FI	2 TO 1 SHIELDED TWISTED PAIR, LEXIBLE SOLDERSHIELD SPLICE KIT, MALL, Nj-PLATED CRIMP AND BRAID					
Unless otherwise Inches dimension TOLERANCES:	e specified dimer ns are shown in b ANGLES: N/A	sions are in millimeters. rackets. Tyco Electronics reserves the right to	amend	DOCUMENT NO.: D-150-0314-NF					
0.00 N/A 0.0 N/A 0 N/A	ROUGHNESS I MICRON	this drawing at any time. Users should evaluate the suitability of the product for their application.		PROD. REV.: A	DOC. ISSUE:	date: 24-F	Seb-03		
PREPARED BY: mforonda		DCR NUMBER: D030109	REPLAC	CES: D030029	SCALE: None	SIZE: A	SHEET: 1 of 2		

If this document is printed it becomes uncontrolled. Check for the latest revision.

SPECIFICATION CONTROL DRAWING

APPLICATION

- 1. This kit is used to provide an environmentally protected 2 to 1 splice in twisted shielded pair cables having nickel-plated primaries and shield, and having an insulation rated for at least 135°C, (eg. 2-Raychem 55PC2126-26-9/0-9 to
 - 1-Raychem 55PC2126-26-9/0-9).

Primary: total CMA on each side: 304 - 1510

Jacket diameter*: 9.56 (0.375) max.

* Jacket diameter can be built up with the use of shim sleeve. In this case, the jacket diameter is 4.75 (0.187) max.

2. Temperature range: -55°C to +150°C.

INSTALLATION PROCEDURE

- 1. Cable preparation. See figure below.
 - Tolerances: All lengths ± 0.50 (0.020).
 - a) Remove cable jacket and shield: 47.65 (1.875).
 - b) Cut 1 primary on each cable: 18.40 (0.725) from cable jacket.
 - Note: Short primaries on cable side A is to be connected to the long primaries on cable side B.
 - c) Strip primaries: 8.25 (0.325).
 - d) Remove cable jacket: 12.70 (0.500).



2. Application Equipment

- a) AD-1377 crimp tool or equivalent.
- b) Steinel HL1802E Heat Gun with a soldersleeve reflector (Setting of 13 14)
- 3. Assembly Procedure



- a) Place the tubing on one end of the assembly.
- b) Place the SO96-5-00 soldersleeve on the side with the 2 cables and the SO96-3-00 soldersleeve on the side with the single cable.
- c) Place one piece of shim tubing onto the single cable, position 3" pc. flush with jacket and recover.
- d) Place the Nickel Braid shield splice onto the other cable assembly.
- e) Primary Conductor Splice:
 - 1) Place a sealing sleeve onto the longer lead.
 - 2) Crimp primaries into opposite ends of the crimp splices using a calibrated Raychem AD-1377 crimp tool or equivalent.
 - 3) Center the sealing sleeves over the splices.
- 4) Apply heat to the center of the sleeve until it recovers, and then heat ends until sealing rings melt and flow along wires. f) Inspection:
 - 1) Conductors must be visible at point where they enter the crimp barrel.
 - 2) Both indentations of a crimp must be on the crimp barrel.
 - 3) Sealing sleeve inserts must have flowed along wire insulation.
 - 4) Sleeve must not have discolored to the degree that the crimp barrel cannot be inspected.
 - 5) Sleeve must not be cut or split.
- g) Shield Splice:
 - 1) Center the Nickel Braid shield splice over the splice and the exposed cable shields. Trim off excess length (as required) so that it will not cover the cable jacket. The jumper braid should overlap the cable braid.
 - 2) Position the soldersleeve over the end of the Nickel Braid and onto the cable jacket.
 - 3) Heat soldersleeves.
 - a) Apply heat to the center of the sleeve until the solder melts, flows and wets the solder to the cable shield and Nickel Braid.
 - b) Apply heat to end of sleeve until rings melt and flow along cable jacket.
 - c) Repeat for other end of sleeve.
 - 4) Position the tubing and center to overlap the splice equally on each end and apply heat to shrink the tubing.

Unless otherwise s	pecified	dimensions	are ii	n millimeters.	(Inches	dimensions	are in	between	brackets)	•
								-		

DOCUMENT NO. :	PROD. REV.	DOC ISSUE:	DCR NUMBER:	DATE:	SHEET:
D-150-0314-NF	А	3	D030109	24-Feb-03	2 of 2