

# 4WD MiniQ Complete Kit (SKU:ROB0050)



4WD MiniQ Complete Kit V2 (SKU:ROB0050)



4WD MiniQ Complete Kit V1 (SKU:ROB0050)

## Introduction

4WD MiniQ mobile robot is especially designed for learning purpose. It comes fully assembled and all your need is a PC with Arduino IDE and 4xAA battery.

This upgraded version of MiniQ 4WD Kit comes with new Arduino Leonardo controller (ATmega32u4)but also integrates such modules as 1 RGB LED, photosensitive diode, 2 infrared trasmitter, 1 infrared receiver, 5 infrared line tracking sensor, two light sensors, 5 buttons and 1 buzzer.

MiniQ 4WD offers 8 lessons for beginners ,from entry to hunting the line, obstacle avoidance, remote control. Users can easily grasp through the tutorial. Code Package download, tutorials download.

https://github.com/Arduinolibrary/Source/blob/master/Code.rar?raw=true https://github.com/Arduinolibrary/Source/blob/master/Tutorial%20pdf.rar?raw=true

- lesson1.Get you to know Your Robot
- lesson2.Control Buzzer
- lesson3.Light Direction Indication
- lesson4.Line follow
- lesson5.RGB LED
- lesson6.Obstacle Avoidance
- lesson7.Encoder
- lesson8.IR Remote Control

## Specification


Controller: Atmega32U4(Arduino Leonardo)
Power Supply: 4x AA batteries or Micro-USB

Working Voltage: 4.5 to 6V

Driving Mode: 4WDMax Speed: 79cm/sSize: 115x110x45mm

Weight:400g

### **Layout Introduction**



4WD MiniQ Complete Kit (SKU:ROB0050)

#### Function about every component:

- Infrared transmitter: transmit the infrared signal, the signal can be used for detecting obstacles
- Infrared receiver: receive infrared signal, the signal can be used for obstacle avoidance
- Photosensitive diode: sensitive with the light, so it can help you get some information about the light
- Button: can be programmed for your idea
- RGB LED: you can change its color use your code, it can show as an alarm and other things you want
- USB port : download your code and let your robot talk to your computer
- Buzzer (passive) : be an alarm bell or sing a simple song
- Controller : runs your code
- Motor: can be controlled to run forward or backward, so that the car can turn left or right freely
- Reset button; Reset the robot, the program in the robot will runs again from its initiation.
- Power switch : power switch of the robot
- Power port : power provided from this port
- Charge port: if your batteries can be charged, you can charge them from this port thus they can be hold in the car
- Infrared line-follow sensor: can be used for detecting for white or black lines

# Pin Mapping

#### Line follow sensor :

A0--IR0 (No.1 count from the left)

A1--IR1 (No.2 count from the left)

A2--IR2 (in middle)

A3--IR3 (No.2 count from the right)

A4--IR4 (No.1 count from the right)

• Follow light: A5

Motors

D5-- PWM control from left motor, D12--EN1 direction control from left motor

D6-- PWM control from right motor, D7--EN2 direction control from right motor

• RGB LED : D10

• Infrared obstacle avoidance :

Transmitter: D13—IRL left transmitter sensor, D8—IRR right transmitter sensor

Receiver: D17—IRS receiver sensor

• Button: A6

• Encoder :

D0--INT2 Right Motor

D1--INT3 Left Motor

Buzzer

D16(MOSI)— Buzzer