
Energy Management Energy Analyzer Type EM111





- · Easy connection or wrong current direction detection
- Compliant with the international accuracy standard IEC/ EN62053-21, and the IEC/EN61557-12 performance requirements (active power and active energy).
- · Certified according to MID Directive (option PF only): see "how to order" below

- Single phase energy analyzer
- · Class 1 (kWh) according to EN62053-21
- · Class B (kWh) according to EN50470-3
- Accuracy ±0.5% RDG (current/voltage)
- Current measurement via 333 mV current sensor up to 600 A
- Current measurement via CT up to 300 A (AV5)
- Rated primary current: 32 A (AV7, AV8)
- Max primary current: 45 A (AV7, AV8)
- Max cable cross section: 6 mm²
- · Backlit LCD display with integrated touch key-pad
- · Energy readout on display: 7 digit
- · Variable readout on display: 4 digit
- · Energy measurement: kWh and kvarh (imported/exported); kWh+ by 2 tariffs
- · System variables, kW, kvar, V, A, PF, Hz, kWdmd, kWdmd peak
- · Self power supply
- Dimensions: 1-DIN module
- · Protection degree (front): IP51
- Pulse output (by open collector PNP)
- RS485 Modbus port
- M-Bus port
- · Digital input (for tariff management)

Product description

energy Single-phase analyzer with backlit LCD display with integrated touch keypad. Particularly indicated for active energy metering and for cost allocation in

applications up to 32 A (direct connection) or up to 300 A (CT connection) or up to 600 A (333 mV current sensor), with dual tariff management availability. It can measure

imported and exported energy or be programmed to sum them into an unique totalizer. Housing for DINrail mounting, with IP51 front degree protection. The meter

is provided with pulse output proportional to the active energy being measured, RS485 Modbus port or M-Bus port.

Certified according to MID Directive, Module B MID and Module D of Annex II, for legal metrology relevant to active electrical energy meters (see Annex V, MI003, of MID). Can be used for fiscal (legal) metrology.

How to order EM111-DIN AV8 1 X O1 PF B

Model ————	· Т.	ΤΤ	Τ'	ТΤ
Range code ———				
System —		J		
Power supply ———				
Output —				
Option —				_
Measurement				

Type Selection

Rang	e code	Syst	em	Pow	er supply	Outp	ut
AV8:	230VLN AC - 5(45)A (Direct connection up to 32 A)	1: Mea	1-phase 2-wire surement	X:	Self power supply	O1: S1: M1:	pulse output RS485 Modbus port M-Bus port
PF:	Certified according to MID Directive. Can be used for fiscal	A :	The power is always integrated (both in case of positive imported and negative exported power) and the total energy meter is certified according to MID. Operating temperature: from –25 to +55°C/from –13 to +131°F				

(legal) metrology.

Only the total positive energy meter is certified according to MID. Operating B: temperature: from -25 to +55°C/from -13 to +131°F

The power is always integrated (both in case of positive imported and negative A70: exported power) and the total energy meter is certified according to MID. Operating temperature: from -25 to +70°C/from -13 to +158°F

Only the total positive energy meter is certified according to MID. Operating temperature: from -25 to +70°C/from -13 to +158°F

STANDARD

Not certified according to MID Directive. Cannot be used for fiscal (legal) metrology.

Type Selection

Rang	e code	Syst	tem	Pow	er supply	Outp	ut
AV8:	230VLN ac - 5(45)A (Direct connection up to 32 A)	1:	1-phase 2-wire	X:	Self power supply	O1: S1: M1:	pulse output RS485 Modbus port M-Bus port
AV7:	120VLN ac - 5(45) A (Direct connection up to 32 A). Available on request (MOQ 100 pcs)						M-Bus port
AV5:	230VLN ac - 5(6)A (CT connection), S1 output only						
MV5:	230VLN ac - 333 mV (current sensor connection), S1 output only						
Optio	n						

Option -

Input specifications

Rated Inputs			Power		0.1 kW or kvar
Current type			Frequency		0.1 KVV OI KVAI 0.1Hz
ourrein type	AV7, AV8	1-phase loads, direct	PF		0.001
	AVI, AVO	connection up to 32 A	Energies (posi	tivo)	0.1 or 0.001 kWh or kvarh
	AV5	1-phase loads, CT	Energies (posi		0.1 or 0.001 kWh or kvarh
	/NV U	connection (5A)	Energy addition		0.1 OI 0.001 KVVII OI KVAIII
		Note: max CT ratio = 60	Influence quan		According to EN62053-21
		(300 A)	Temperature di		≤200ppm/°C
	MV5	1-phase loads, current	Sampling rate	III.	4096 samples/s @ 50Hz
	IVIVO	sensor connection (333	Sampling rate		4096 samples/s @ 60Hz
		mV)	Bir day and the		+000 3ample3/3 @ 00112
		Note: max primary current	Display and tou	ıcn key-pad	D 111110D 7 11 11 10
		= 600 A	Туре		Backlit LCD, 7-digit, h 6
Nominal curren	nt range	33371	Dandaut		mm
rtommar carron	AV7, AV8	5(45)A, lb 5 A, lmax 45 A,	Read-out		Energy: 7 digit. Variables: 4
	,,,,,,,	Imin 0.25 A	Touch koy		digit
	AV5	5 (6) A, In 5A, Imax 6 A,	Touch key Max. and Min. i	ndication	2 (Enter/DOWN and UP). Max. 9 999 999
		Imin 0.25 A.	IVIAX. AIIU IVIIII. I	nuication	Min. 0.00
	MV5	333 mV (400 mV max)	Memory energy	, etorago	WIIII. U.UU
Nominal voltag	е	,		storage	10^10 cycles. Energy value
	AV5, AV8	230 VLN -30% +20 %	Energy		is saved every time the less
	AV7	120 VLN -20% +20%			significant digit increases.
	MV5	230 VLN -30% +20 %	Programming p	narameters	10^10 cycles. When a
Note		EM111 with direct	r rogramming p	Jarameters	parameter is modified, only
		connection (AV7, AV8) can			the relevant memory cell is
		be used up to 45 A if a 6			overwritten
		mm2 section wire complies	LEDs		Flashing red light pulses
		with local regulations and/	LLD3		according to EN50470-3,
		or installation needs.			EN62052-11
Accuracy			Pulse weight	AV7, AV8	1000 pulses/kWh (max.
(@25°C ±5°C,	R.H. ≤60%,		r dioo woight	7107,7100	frequency: 11 Hz)
45 to 65 Hz)				AV5	Depending on CT ratio:
Energies				7100	CT ≤ 25: 1000 pulse/kWh
Active energy	y	Class 1 according to			25 < CT < 60: 100 pulses/kWh
		EN62053-21		MV5	Depending on primary
		Class B (kWh) according			current:
		to EN50470-3 (option PF			Primary current ≤ 125 : 1000
		only)			pulses/kWh
Reactive ene	ergy	Class 2 according to			Primary current >125: 100
_		EN62053-23			pulses/kWh
Start-up curren			Note		Fix orange light: wrong
	AV7, AV8	20 mA, positive or negative			current direction only with
	AV5	10 mA, positive or negative			PFB option or with "B"
		Self-consumption is not			measurement selection in
	NA) /E	measured.			case of X option
O4===4 14	MV5	0.666 mV	Current overloa		
Start-up voltage		161 VI NI	Continuous	AV7, AV8	45 A
	AV5, AV8	161 VLN		AV5	6 A
	AV7	96 VLN		MV5	400 mV
Decelution	MV5	161 VLN	For 10ms	AV7, AV8	1350 A
Resolution Current		Display		AV5	120 A
		0.1 A 0.1 V	Voltage Overloa	ads	
Voltage Power		0.1 v 0.01 kW or kVar	Continuous		1.2 Un
		0.01 KW or kvar	For 500ms		2 Un
Frequency PF		0.1 HZ 0.01	Input impedance	ce	
	ive)	0.01 kWh or kvarh	Voltage input		2.8 Mohm
Energies (posit Energies (nega		0.01 kWh or kvarh	Current input	AV7, AV8	< 0.5 VA
Litergies (Hega	v <i>c)</i>	Serial communication		AV5	<0.05 VA
Current		0.001 A		MV5	1 kohm
Voltage		0.001 A 0.1 V			
•	ubioot to alcania				
opecification are s	ubject to change i	without notice EM111 DS 010921			3

Digital input specifications

Digital inputs

Function

Number of inputs Contact measurement voltage Input impedance Contact resistance

Free of voltage contact Tariff management (switch between t1-t2)

1 5 V 1kohm

≤ 1kohm, close contact ≥ 100kohm, open contact Overload

In case a voltage is erroneously applied to the digital input, the input is not damaged up to 30 V ac/dc.

Output specifications

RS485 serial port	RS485 by screw	
·	connection.	Other
Function	For communication	
	of measured data,	
	programming parameters	
Protocol	Modbus RTU (slave	
	function)	
Baud rate	9.6, 19.2, 38.4, 57.6, 115.2	
Dada Tato	kbaud,	
parity control	even or no parity,	Note
Address	1 to 247 (default: 1)	11010
Driver input capability	1/8 unit load. Maximum 247	Static output
Driver input capability	transceivers on the same	Purpose
	bus.	Fulpose
Data refresh time	1 s	
Read command	50 words available in 1	Pulse rate
Read Command	read command	ruise late
M Due nert		
M-Bus port	M-Bus by screw connection.	
Function	For communication of	
Function		Dulas ON donation
D 1	measured data	Pulse ON duration
Protocol	M-Bus according to	0
5	EN13757-3	Output type
Baud rate	0.3, 2.4, 9.6 kbaud	Load
Meters in the M-Bus network	250	
Primary address	Selectable	Note
Secondary address	Univocally defined in each	
	unit	
Secondary address	from 50000000 to	

69999999

Available functions: wild card, header, initialisation SND_NKE, and req_udr management. Management of primary address modification via M-Bus. VIF, VIFE, DIF and DIFE: see protocol not available with AV5 and MV5 range code

Purpose
For pulse output proportional to the active energy (kWh)
Selectable in multiple of 100
Max 1000 or 3000 pulses/

duration Selectable: 30ms or 100 ms according to EN62052-31 put type open collector PNP V_{ON} 1 VDC max. 100mA V_{OFF} 80 VDC max.

kWh according to pulse ON

not available with AV5 and MV5 range code

General specifications

Operating temperature PF option (standard or with suffixes from 01 to 60) PF option	From –25 to +55°C/from –13 to +131°F	Metrology	EN62053-21, EN62053- 23, EN50470-3 (PF option only) IEC/EN61557-12 (active power and active energy, MID models only)
(with suffixes from 61 to 99)	From -25 to +70°C/from -13 to +158°F	Approvals	CE, UKCA, MID (PF option only), cULus (AV7 option
X option	From -25 to +65°C/from -13 to +149°F indoor, (R.H. from 0 to 90% non- condensing @ 40°C)	Connections Cable cross-section area	only) Measuring inputs: max. 6 mm² with/without metallic
Storage temperature	-30°C to +80°C (R.H. < 90% non-condensing @ 40°C)	Other terminals	cable ferrule; Max. screw tightening torque: 1.1 Nm 1.5 mm², Min./Max. screws tightening torque: 0.4 Nm
Overvoltage category	Cat. III	Housing	0 0 1
Insulation (for 1 minute)	4000 VAC RMS between measuring inputs and digital/serial output (see table) 4000 VAC RMS	Dimensions (WxDxH) Material Sealing covers	17,5 x 63 x 91,5 mm PBT, self-extinguishing: UL 94 V-0 Included
Dielectric strength	4000 VAC RMS for 1 minute	Mounting	DIN-rail
EMC	According to EN62052-11 (X option) According to EN50470-1 (PF option)	Protection degree Front Screw terminals (cable inputs) Weight	IP51 IP20 Approx. 80 g (packing
Standard compliance Safety	EN62052-11 (X option) EN50470-1 (PF option)		included)

Power supply specifications

Power supply	self power supply	Power consumption	
			≤ 1.0W, ≤ 8VA

Insulation (for 1 minute) between inputs and outputs

AV7, AV8 model	Measuring input	Digital or serial output	Digital input
Measuring input	-	4 kV	4 kV
Digital or serial output	4 kV	-	-
Digital input	4 kV	-	-


AV5 model	CT input (5 A)	Voltage input	Serial output	Digital input
CT input (5 A)	-	2 kV	4 kV	4 kV
Voltage input	2 kV	-	4 kV	4 kV
Serial output	4 kV	4 kV	-	4 kV
Digital input	4 kV	4 kV	4 kV	-


MV5 model	CT input (333 mV)	Voltage input	Serial output	Digital input
CT input (333 mV)	-	2 kV	4 kV	4 kV
Voltage input	2 kV	-	4 kV	4 kV
Serial output	4 kV	4 kV	-	4 kV
Digital input	4 kV	4 kV	4 kV	-

MID compliance (PF option only)


Accuracy	0.9 Un \leq U \leq 1.1 Un; 0.98 fn \leq f \leq 1.02 fn; fn: 50 Hz; \cos_{θ} : 0.5 inductive to 0.8 capacitive. Class B Considering listed Ib or In values
Operating temperature	PF option (standard or with suffixes from 01 to 60): from –25 to +55°C/from –13 to +131°F PF option (with suffixes from 61 to 99): from –25 to +70°C/from –13 to +158°F X option: from –25 to +65°C/from –13 to +149°F indoor (R.H. from 0 to 90% non-condensing @ 40°C)
EMC compliance	E2
Mechanical compliance	M2

Accuracy (according to EN62053-21 and EN62053-23) - AV5 model






kvarh, accuracy (RDG) depending on the current




Accuracy (according to EN50470-3 and EN62053-23) - AV7/AV8 model

kWh, accuracy (RDG) depending on the current



kvarh, accuracy (RDG) depending on the current



Measurement accuracy according to IEC/EN61557-12 (MID versions)

Active power Performance class 1 Active energy Performance class 2

Display pages

No	Variable	"Full" mode	"Easy" mode	Note
0	kWh+ (imported)	X	Х	In PF version (MID) this is the only certified energy meter. In PFA version and in X version with Measurement menu set to "A", this is considering the total energy without considering the current direction.
1	kWh- (exported)	X	X	In PFB version and in X version with Measurement menu set to "B"
2	kW	Х	Х	
3	V	Х	Х	
4	A	Х	Х	
5	PF	Х		
6	Hz	Х		
7	kvarh+ (imported)	X		In PFA version and in X version with Measurement menu set to "A", this is considering the total positive reactive energy without considering the current direction.
8	kvarh- (exported)	Х		In PFB version and in X version with Measurement menu set to "B"
9	kvar	Х		
10	kW dmd	Х		
11	kW dmd peak	X		
12	kWh (t1)	X	Х	Only relevant to kWh+, with Tariff menu set to ON
13	kWh (t2)	Х	Х	Only relevant to kWh+, with Tariff menu set to ON

List of available menus

Menu name and description		Range	Default setting
PASS	Password request	From 0000 to 9999	0000
nPASS	New password	From 0000 to 9999	0000
Ct Ratlo (AV5)	Current transformer ratio	From 1 to 60	20
Prl Curr (MV5)	Primary current	From 1 to 600	100
MEASurE	Measurement type (A=easy connection; B=bidirectional, imported and exported energy). Not available in PFA and PFB versions (MID)		А
P int	Integration time for Wdmd calculation	1 to 30 min	1
Mode	Selection of complete or simplified set of variables on display		Full
Tariff	Tariff enabling	Yes/No	No
PULSE (O1 option)	Selection of pulse ON duration	30 or 100 ms	30
	Selection of the pulse weight (multiplies of 100 pulses/kWh)	100 to 1000 (if duration is 100ms) 100 to 3000 (if 30 ms)	1000
Address (S1 option)	Modbus serial address	1 to 247	01
Baud (S1)	Modbus baud rate 9.6; 19.2; 38.4; 57.6, 115.2 kbps		9.6
Parity (S1)	Modbus parity	No/even	No
Prl Add (M1 option)	M-Bus primary address	1 to 250	0
Baud (M1)	M-Bus baud rate	0.3; 2.4; 9.6 kbps	2.4
RESEt Allow the reset of tariff meters and W dmd peak (kWh/ kvarh partial meter reset available only via serial communication)		Yes/No	No
End	Exit to measuring mode		
	•	•	


Note: after the confirmation of a new parameter value, the value is stored in the memory without the need to exit the programming mode.


Additional available information on the display (*)


Туре	Page	Description	
Info page 1	YEAr (2013)	Year of production	
Info page 2	SErIAL (dddnnnA)	Serial number (ddd= day of the year; nnn=progressive number; A= production line, internal use only)	
Info page 3	rEV (A.01)	Firmware revision	
Info page 4	Ct Ratlo (AV5)	Current transformer ratio	
Info page 5	Prl Curr (MV5)	Primary current	
Info page 6	MEASurE	Measurement type	
Info page 7	P int	Integration time for Wdmd calculation	
Info page 8	ModE	Set of variables on display	
Info page 9	tArIFF	Tariff enabling	
Info page 10 (O1)	PULSE	Pulse ON duration	
		Pulse weight	
Info page 10 (S1)	AddrESS	Modbus serial address	
Info page 11 (S1)	bAud	Modbus baud rate	
Info page 12 (S1)	PArItY	Modbus parity	
Info page 10 (M1)	Prl Add	M-Bus primary address	
Info page 11 (M1)	bAud	M-Bus baud rate	
Info page 13	ChECk_S	FW checksum	

^(*) can be reached by pressing simultaneously the 2 touch keys


AV7, AV8 wiring diagrams










AV5 wiring diagrams






MV5 wiring diagrams







Input/output communication




The load resistance (Rc) must be designed so that the closed contact current is under 100 mA (V $_{\rm on}$ is equal to 1 V dc). DC voltage (V $_{\rm off}$) must be less than or equal to 80 V.






Additional instruments with RS485 are connected in parallel. The serial output must only be terminated on the last network device connecting terminals A- and T. For connections longer than 1000 m use a signal repeater. Maximum 247 transceivers on the same bus.



Front panel description



1. Display

Backlit LCD display with touch key-pad. Upper part: enter

LED

LED proportional to kWh reading

3. Serial number and MID data

Area reserved to serial number and MID-relevant data in PF versions

Dimensions (mm)

