# EZ-KIT Lite for Analog Devices ADSP-21369 SHARC Processor

# Key Features

- ADSP-21369 SHARC Processor
- 1 M × 8-bit flash memory
- 1 M × 32-bit × 4 banks SDRAM
- 512 K × 8-bit SRAM
- · 2 Mb SPI flash memory
- AD1835 stereo, 96 kHz, 24-bit codec
- 4 × 2 RCA jack for four channels of stereo audio output
- 1 × 2 RCA jack for one channel of stereo audio input
- Headphone jack (connected to one of stereo outputs)
- SPDIF In RCA jack
- SPDIF Out RCA jack
- ADM3202 RS-232 driver/receiver
- USB-based debugger interface
- JTAG ICE 14-pin header
- Evaluation suite of VisualDSP++ development tools
- Flash utility for downloading boot code to on-board flash memory
- Type A expansion interface with three connectors supporting external port, FLAG, DPI, and DAI interfaces
- · 20-pin DPI header
- · 26-pin DAI header
- Eight general-purpose LED
- Four push buttons: two general-purpose (connected to DAI), two IRQ (connected to flag pins)
- ELVIS interface
- USB cable
- · 3.5 mm stereo headphones
- · 6-foot RCA audio cable
- 6-foot 3.5 mm/RCA × 2 Y-cable
- CE certified

#### System Requirements

- Intel® Pentium® 166 MHz, or higher
- 32 MB RAM, minimum
- Microsoft<sup>®</sup> Windows<sup>®</sup> 98/2000/XP
- One available USB connector



## Overview

The ADSP-21369 EZ-KIT Lite<sup>®</sup> provides developers with a cost-effective method for initial evaluation of the ADSP-21367, ADSP-21368, and/or ADSP-21369 SHARC<sup>®</sup> Processor architecture via a USB-based, PC-hosted tool set. With this EZ-KIT Lite, users can learn more about the Analog Devices (ADI) ADSP-21369 hardware and software development, and quickly prototype a wide range of applications.

The EZ-KIT Lite includes an ADSP-21369 SHARC Processor desktop evaluation board along with an evaluation suite of the VisualDSP++ $^{\circ}$  development and debugging environment, including the C/C++ compiler, assembler, and linker. The evaluation suite of VisualDSP++ is designed to be used with the EZ-KIT Lite only.

An Analog Devices SHARC USB EZ-Extender<sup>®</sup> daughter board (sold separately) can attach to the ADSP-21369 EZ-KIT Lite using the three expansion connectors, allowing a USB 2.0 peripheral to directly connect to the ADSP-21369 external port and interface with the EZ-KIT Lite.



#### **CROSSCORE** Development Tools

The ADSP-21369 EZ-KIT Lite is a part of the Analog Devices CROSSCORE® Development Tools product line, which is composed of a comprehensive set of development tools providing engineers with easier and more robust methods for developing and optimizing systems.

#### The CROSSCORE components include:

- VisualDSP++ development and debugging environment
- EZ-KIT Lite evaluation kits
- · EZ-Extender daughter boards
- · Emulators

The easy-to-use VisualDSP++ integrated development environment speeds development, debugging, and deployment while shrinking product development cycles and improving time to market. The EZ-KIT Lite evaluation kits provide an easy way to investigate the performance of Analog Devices' family of embedded processors and DSPs. EZ-Extender daughter boards give developers access and ability to connect various peripherals from Analog Devices and third parties to the expansion interface of the EZ-KIT Lite evaluation kits. Emulators are available for both PCI and USB host platforms for rapid on-chip debugging.

#### **Embedded Processors and DSPs**

Analog Devices is a leading supplier of digital signal processing solutions, from the high performance Blackfin<sup>®</sup> Processors, TigerSHARC<sup>®</sup> Processors, and SHARC Processors to integrated mixed-signal DSPs for an increasing spectrum of applications. Our advances in design provide faster processing, more memory, lower power consumption, and simplified system integration. Analog Devices gives you a competitive edge by providing a complete solution, including expert technical support, comprehensive development tools, and an independent network of third-party developers called the Collaborative™. For more information about ADI processors and DSPs, visit *www.analog.com/processors*.

### CROSSCORE® Tools Support

#### Tel: 1.800.ANALOGD

Web: www.analog.com/processors/tools Analog Devices is committed to providing high quality, timely, accurate, and free technical support and software upgrades.

## **Ordering Information**

Please call your local Analog Devices sales representative or distributor for pricing and ordering information for part number: ADDS-21369-EZLITE. 
 Analog Devices, Inc.

 Worldwide Headquarters

 Analog Devices, Inc.

 One Technology Way

 P.O. Box 9106

 Norwood, MA 02062-9106

 U.S.A.

 Tel: 781.329.4700

 (800.262.5643,

 U.S.A. only)

 Fax: 781.461.3113

Analog Devices, Inc. Europe Headquarters Analog Devices SA 17-19 rue Georges Besse Antony, 92160 France Tel: 33.1.46.74.45.00 Fax: 33.1.46.74.45.01

## Analog Devices, Inc. Japan Headquarters

Analog Devices, KK New Pier Takeshiba South Tower Building 1-16-1 Kaigan, Minato-ku, Tokyo, 105-6891 Japan Tel: 813.5402.8200 Fax: 813.5402.1064

# Analog Devices, Inc. Southeast China Headquarters

Analog Devices 22/F One Corporate Avenue 222 Hu Bin Road Shanghai, 200021 China Tel: 86.21.5150.3000 Fax: 86.21.5150.3222

## Embedded Processing and DSP Support

U.S.A.: processor.support@analog.com Fax: 781.461.3010 Europe: processor.europe@analog.com Fax: 49.89.76903.157 www.analog.com/processors



© 2005 Analog Devices, Inc. All rights reserved. Trademarks and registered trademarks are the property of their respective owners. Printed in the U.S.A. PH05781-2-10/05

