## AS-Interface Power Supply with 8A

# **SLA8.100**

Input: AC 115V / 230VOutput: 30.55V / 8A

- AS Interface data decoupling
- Infrared (IR) addressing mode
- Overload protection by FUSE Mode
- For highly demanding industrial applications



# Data sheet

#### **Short description**

#### Data and energy:

The primary switched mode DIN rail power supply SLA8.100 specifically supplies AS Interface® systems with energy. The AS-Interface bus technology allows to connect up to 62 participants to a control and to supply them with energy with a single two-conductor cable. When connecting slaves, the yellow AS-Interface cable offers the high degree of protection IP67 in conjunction with the insulation displacement. The communication signals of the individual network participants are modulated onto the supply voltage. For this purpose, specific power supply units with integrated data decoupling are required for AS-Interface systems.

#### Fast addressing of slaves:

The "IR addressing mode" selectable via jumper interrupts the data communication on the yellow AS-Interface cable. Participants with an infrared interface can then quickly be assigned a new ID address by means of an infrared programming unit without the need to disconnect them from the AS-Interface cable. Afterwards, the "Communication Mode"

## Input

Rated voltage	AC 100-120/220-240V (selectable by front panel slide switch)			
Rated current	6.0A (switch in 115V position) 2.8A (switch in 230V position)			
Frequency	4763 Hz (alternatively also DC possible)			
Voltage range	AC 85132V/184264V, DC 230375V			
Power factor	>0.5			
Integrated internal fuse	T8A/250V HBC (ot accessible)			
Inrush current	Limited by NTC resistor (bypassed by a relay during normal operation) T <sub>amb</sub> = +50°C, cold start (line impedence acc. EN 61000-3-3)			
	AC 100V	AC 120V	AC 220V	AC 240V
Peak current I <sub>pk</sub>	<12A	<14A	<24A	<27A
I <sup>2</sup> t	<1.0A <sup>2</sup> s	<1.5A <sup>2</sup> s	<1.4A <sup>2</sup> s	<1.6A <sup>2</sup> s
Hold-up time	>10ms @ AC 100V or AC 196V and rated load (also see diagram)			

can be selected again to re-start the data communication.

#### Safe operation by FUSE Mode:

The device features a FUSE Mode, which permanently switches off the output in the event of failure and the unit at overload, short-circuit or overtemperature and thus protects the relatively thin AS-Interface line and the attached components. Triggering of the FUSE Mode is indicated by a flashing LED. System restart requires the intentional activation of a reset button on the front side of the unit. Thus, an accidental restart is prevented and the slaves are protected against damage.

#### Fit for the world market:

The input voltage range of the unit can be selected on the front panel. Thus, it can be operated worldwide on all usual single-phase line voltages. International (IEC 60950) and various national (CBscheme) approvals allow for worldwide application.

#### **Output**

Rated voltage	DC 30.55V ±3% (not adjustable)	
Rated current	8.0A	
Isolation	Safe low voltage	PELV (IEC364-4-41) SELV (IEC60950)
Current limitation	>8.4A	
Overload behaviour	FUSE Mode (25s co wards permanent sw	ntinuous current, after- vitch-off)
Short-circuit current	>12A <25A (max. 5s)	
Load regulation	stat. <200mV (no loa	d / full load)
Line regulation	stat. <30mV (AC 85	.132V/184264V)
Ripple	50mV <sub>PP</sub> (500kHz ba ohmic load)	indw., 50 $\Omega$ measurem.,
Noise (Spikes)	100mV <sub>PP</sub> (20MHz b ohmic load)	andw., $50\Omega$ measurem.,
Overvoltage protection	limited to max. 55V	
Operating indicator	Green LED (extinguis	shes at overload)
Output is protected aga	inst short-circuit, oper	n circuit and overload.
Use AS-Interface power	supplies only togethe	er with AS-Interface lines!

#### **Order information**

Order numb	per Description
SLA8.100	AS-Interface power supply unit
SLZ13	Adapter for S7-300 rail
SLZ02	Wall mounting set (two pcs. per package)

sla8e100 / 040225 1/4

#### **FUSE Mode**

The FUSE Mode (electronic fuse in the output) protects the unit from overload and overtemperature.

#### Shutdown:

 At overtemperature, overload or short-circuit (8.4A < I<sub>max</sub> < 12A), the unit switches off the output after 2...5s

#### Indicator

Activation of the FUSE Mode is indicated by a flashing red LED

#### **Reset / Restart:**

- by intentionally pushing the Reset button on the unit front panel
- by turning off the mains voltage. Before restarting the unit, wait at least twice the time the flashing red LED needed to extinguish after the mains voltage dropped.

## Operating and environmental data

Non-operating -25°C...+85°C temperature range

Operating -10°C...+70°C

temperature range (measured at 25mm below the unit)

Derating from 60°C 6W/°C onwards, power reduction

necessary (see diagram)

Cooling natural convection,

no forced air-cooling necessary

Over-temperature

protection

implemented

Humidity protect from moisture and condensation

Vibration 2 - 17.8Hz  $\pm 1.6$ cm

Sinus
 17.8Hz – 500Hz
 2g (IEC 68-2-6)
 Random
 2...800Hz
 0.5m² (s³) (IEC 68-2-64)
 Shock
 15g (6ms), 10g (11ms), (IEC 68-2-27)

Degree of pollution 2 (EN 60950) Overvoltage category III (EN 50178)


## **Electromagnetic Compatibility (EMC)**

Emissions	EN 50081-2 Class B (EN 55011, EN 55022)
Immunity • Electrostatic Discharge (ESD)	EN 61000-6-2 (also includes EN 55024) EN 61000-4-2, Level 4 (withstands 8kV direct discharge, 15kV air discharge)
• Electromagnetic radiated fields	EN 61000-4-3, Level 3 (10V/m) ENV 50204 (10V/m)
<ul><li>Burst, coupled to:</li><li>ACin lines</li><li>DCout lines</li></ul>	EN 61000-4-4, Level 4 (4 kV) Level 3 (2 kV)
<ul> <li>Surge transients</li> <li>Differential mode (L→PE)</li> <li>Common mode (L→N)</li> </ul>	EN 61000-4-5, Installation class 4 (4kV) Installation class 4 (2kV)
<ul> <li>Conducted noise immunity</li> </ul>	EN 61000-4-6, Level 3 (10V, 150kHz - 80MHz)
<ul> <li>Voltage dips</li> </ul>	EN 61000-4-11
• Transient immunity	Transient resistance acc. to VDE 0160 / W1 across entire load range

## Efficiency, Reliability

Efficiency	typ. 92%	(AC 230V, 8A)
Power dissipation	typ. 21.2W	(AC 230V, 8A)


#### **Schematic**



2/4 sla8e100 / 040225



## **Operating indicators and elements**



## **Connectors and terminals**

Terminals	screws for 5	n-proof terminals with captive 5.5mm slotted screwdriver or Philips ed screwdriver No. 2
Position	,	ch terminals on the front panel; output clearly separate from each
Tightening torque	0.8Nm	
Connector size range    flexible cable    solid cable	0.5-6mm <sup>2</sup>	(20-10AWG) (20-10AWG)
Ferrules	admissible	
Stripping length	7mm	

#### **Front elements**

<b>=</b>	PE terminal
N	Input neutral
L	Input phase
⊕ brown	Positive AS-Interface output voltage (twice)
⊝ blue	Negative AS-Interface output voltage (twice)
Shield	Connection of machine ground. (Functional earth for balancing the AS-Interface output. Connection is recommended for EMC)

#### **Construction / Mechanics**

Housing	Robust metal housing for built-in installation
Degree of protection	IP20 (EN 60529)
Class of protection	1 (IEC536); do not use without protective earth (PE)
Width w Height h Depth d	91mm 124mm 102mm (without DIN rail)
Weight	appr. 890g

## **Installation notes**

External fusing	<ul> <li>not necessary (internal fuse)</li> <li>observe national regulations</li> <li>circuit breaker with B-characteristic min. 6A or slower action, or alternatively 6A HBC fuse</li> </ul>
Mounting position	vertical; input below, output above
Free space for cooling	above / below 25mm recommended left / right 15mm recommended
Always connect PE bef	ore operating the unit!


**Operation without AS-Interface:** This AS-Interface PSU has an inductive output. When operating without AS-Interface structure (e.g. in a laboratory test) you should connect a  $470\mu\text{F}/35\text{V}$  capacitor between AS-Interface + and AS-Interface – as commercial electronic loads in combination with the data decoupling often tend to oscillate, and the oscillation may exceed the permitted modulation voltage. Otherwise, equipment may be destroyed.

sla8e100 / 040225 3 4 4




#### **Functional diagrams**


#### **Start behaviour**




## **Efficiency / Power dissipation**




## **Hold-up time**




#### **FUSE Mode / Signals and LED**



# Overload response until FUSE Mode is activated



## **Derating**



Unless otherwise stated, specifications are valid for AC 230V input voltage, +25°C ambient temperature, and 5 min. run-in time. They are subject to change without prior notice.

## Your partner in power supply:







PULS GmbH
Arabellastraße 15
D-81925 München
Tel.: +49 89 9278-0
Fax: +49 89 9278-199
www.puls-power.com

4/4 sla8e100 / 040225