

### SLDM-12D1Ax Non-Isolated DC-DC Converter

The SLDM-12D1Ax power modules are non-isolated dc-dc converters that can deliver up to 12 A of output current. These modules operate over a wide range of input voltage ( $V_{IN}$  = 3 Vdc-14.4 Vdc) and provide a precisely regulated output voltage from 0.45 Vdc to 5.5 Vdc, programmable via an external resistor and PMBus control.

Features include a digital interface using the PMBus protocol, remote On/Off, adjustable output voltage, over current and over temperature protection. The PMBus interface supports a range of commands to both control and monitor the module.

The module also includes the Tunable Loop<sup>™</sup> feature that allows the user to optimize the dynamic response of the converter to match the load with reduced amount of output capacitance leading to savings on cost and PWB area.

### **Key Features & Benefits**

- 3-14.4 VDC Input / 0.45-5.5 VDC @ 12 A Output
- Non-Isolated
- DOSA approved footprint
- Wide Input Voltage Range(3Vdc-14.4Vdc)
- Power Good Signal
- Remote On/Off
- Output Over Current Protection (non-latching)
- Small size: 20.32 mm x 11.43 mm x 2.8 mm (Max)(0.8 in x 0.45 in x 0.11 in)
- Ultra low height design for very dense power applications.
- Output voltage programmable from 0.6Vdc to 5.5Vdc via external resistor.
- Digitally adjustable down to 0.45Vdc
- Digital interface through the PMBus<sup>TM</sup> protocol
- Ability to Sink and Source Current
- Cost Efficient Open Frame Design
- Over Temperature Protection
- Tunable Loop<sup>™</sup> to Optimize Dynamic output voltage response





#### **Key Features & Benefits (Continued)**

- Compliant to RoHS II EU "Directive 2011/65/EU"
- Compliant to REACH Directive (EC) No 1907/2006
- Compatible in a Pb-free or SnPb reflow environment
- Flexible output voltage sequencing EZ-SEQUENCE
- Output overcurrent protection (non-latching)
- Wide operating temperature range [-40°C to 105°C]
- ISO 9001 and ISO 14001 certified manufacturing facilities
- Class 2, Category 2, Non-Isolated DC/DC Converter (refer to IPC-9592A)
- Compliant to RoHS II EU "Directive 2011/65/EU"
- Compliant to REACH Directive (EC) No 1907/2006
- Compatible in a Pb-free or SnPb reflow environment
- UL 60950-1Recognized, CSA C22.2 No. 60950-1-03 Certified
- VDE 0805:2001-12 (EN60950-1) Licensed

#### **Applications**

- Distributed power architectures
- Intermediate bus voltage applications
- Telecommunications equipment
- Servers and storage applications
- Networking equipment
- Industrial equipmen



#### 1. MODEL SELECTION

MODEL NUMBER	OUTPUT VOLTAGE	INPUT VOLTAGE	MAX. OUTPUT CURRENT	MAX. OUTPUT POWER	TYPICAL EFFICIENCY
SLDM-12D1A0	0.45-5.5 VDC	3-14.4 VDC	12 A	66 W	92%
SLDM-12D1AL	0.45-5.5 VDC	3-14.4 VDC	12 A	66 W	92%

NOTE: 1. Add "R" suffix at the end of the model number to indicate tape and reel packaging (Standard).2. Add "G" suffix at the end of the model number to indicate tray packaging (Option).

#### PART NUMBER EXPLANATION

S	LDM	- 12	D	1A	x	Y
Mounting Type	RoHS Status	Output Current	Wide input voltage range	Output Voltage	Enable	Package Type
Surface mount	Series code	12 A	3-14.4 V	With sequencing	L – active Low 0 –active High	G – Tray package R –tape and reel packaging

#### 2. ABSOLUTE MAXIMUM RATINGS

PARAMETER	DESCRIPTION	MIN	ТҮР	MAX	UNITS
Continuous non-operating Input Voltage		-0.3	-	15	V
Voltage on SEQ SYNC VS+		-	-	7	V
Voltage on CLK DATA SMBALERT terminal		-	-	3.6	V
Ambient temperature	See Thermal Considerations section	-40	-	105	°C
Storage Temperature		-55	-	125	°C
Altitude		-	-	2000	m

**NOTE:** Stresses in excess of the absolute maximum ratings can cause permanent damage to the device. These are absolute stress ratings only, functional operation of the device is not implied at these or any other conditions in excess of those given in the operations sections of the data sheet. Exposure to absolute maximum ratings for extended periods can adversely affect the device reliability.

#### 3. INPUT SPECIFICATIONS

All specifications are typical at 25°C unless otherwise stated.

PARAMETER		DESCRIPTION	MIN	ТҮР	MAX	UNIT
Operating Input Voltage			3	-	14.4	V
Input Current (full load)		VIN=3V to 14.4V	-	-	10	А
Input Current (no load)	Vo=0.6V Vo=5V	VIN = 12Vdc, IO = 0, module enabled	-	52 220	-	mA mA
Input Stand-by Current		$V_{IN}$ = 12.0Vdc, module disabled	-	20	-	mA
Input Reflected Ripple Curren	t (pk-pk)	<ol> <li>5Hz to 20MHz, 1μH source impedance; VIN =0 to 14V, IO= IOmax</li> <li>See Test Configurations</li> </ol>	-	50	-	mA
I <sup>2</sup> t Inrush Current Transient			-	-	1	A2s
Input Ripple Rejection (120Hz	<u>z</u> )		-	-55	-	dB

CAUTION: This converter is not internally fused. An input line fuse must be used in application.

This power module can be used in a wide variety of applications, ranging from simple standalone operation to an integrated part of sophisticated power architecture. To preserve maximum flexibility, internal fusing is not included; however, to achieve maximum safety and system protection, always use an input line fuse. The safety agencies require a fast-acting fuse with a maximum rating of 6A. Based on the information provided in this data sheet on inrush energy and maximum dc input current, the same type of fuse with a lower rating can be used. Refer to the fuse manufacturer's data sheet for further information.

Note: Unless otherwise indicated, specifications apply over all operating input voltage, resistive load, and temperature conditions.



Asia-Pacific Europe, Middle East +86 755 298 85888 +353 61 225 977

 ope, Middle East
 North America

 +353 61 225 977
 +1 408 785 5200

© 2016 Bel Power Solutions & Protection

### 4. OUTPUT SPECIFICATIONS

All specifications are typical at nominal input, full load at 25°C unless otherwise stated.

·		· ·				
PARAMETER		DESCRIPTION	MIN	ΤΥΡ	MAX	UNIT
Output Voltage Set Point		with 0.1% tolerance for external resistor used to set output voltage	-1.0	-	1.0	%Vo,set
Output Voltage		Over all operating input voltage, resistive load, and temperature conditions until end of life	-0.3	-	0.3	%Vo,set
PMBus Adjustable Outpu	ut Voltage Range		-25	0	25	%Vo,set
PMBus Output Voltage A	• •		0.4	-		%Vo,set
Adjustment Range		Some output voltages may not be possible depending on the input voltage – see Feature Descriptions Section	0.6	-	5.5	V
Remote Sense Range			-	-	0.5	V
Load Regulation	V <sub>0</sub> ≥ 2.5V V <sub>0</sub> < 2.5V	Io=Io, min to Io, max	-	-	10 10	mV mV
Line Regulation	V <sub>0</sub> ≥ 2.5V V <sub>0</sub> < 2.5V	$V_{IN}$ = $V_{IN, min}$ to $V_{IN, max}$	- -	- -	0.4 5	%Vo,set mV
Temperature Regulation		Tref=TA, min to TA, max	-	-	0.4	%Vo,set
Ripple and Noise(Pk-Pk)	)	5Hz to 20MHz BW, VIN=VIN, nom and Io=Io,	-	50	100	mV
Ripple and Noise(RMS)		<sub>min</sub> to I <sub>O, max</sub> Co = 0.1uF // 22 uF ceramic capacitors)	-	20	38	mV
Output Current Range		in either sink or source mode	0	-	12	А
Output Current Limit Ince	eption	Current limit does not operate in sink mode	-	130	-	%lo,max
Output Short-Circuit Curr	rent	Vo≤250mV, Hiccup Mode	-	1.5	-	Arms
Output Capacitance	ESR≥ 1 mΩ ESR≥0.15 mΩ ESR≥ 10 mΩ	Without the Tunable Loop™ With the Tunable Loop™ With the Tunable Loop™	2x47 2x47 2x47	- - -	2x47 1000 10000	uF uF uF
Turn-On Delay Times (VIN=VIN, nom, IO=IO, max , VO to within		Case 1: On/Off input is enabled and then input power is applied(delay from instant at which VIN = VIN, min until Vo = 10% of Vo, set) Case 2: Input power is applied for at least	-	0.9	-	ms
±1% of steady state)		one second and then the On/Off input is enabled (delay from instant at which Von/Off is enabled until Vo = 10% of Vo, set)	-	0.8	-	ms
Output voltage Rise time		time for Vo to rise from 10% of Vo, set to 90% of Vo, set	-	2	-	ms
Output voltage overshoo maximum external capac		TA = 25°C VIN= VIN, min to VIN, max,IO = IO, min to IO, max	-	-	3	% V <sub>O,set</sub>

Notes: 1. Some output voltages may not be possible depending on the input voltage.
2. External capacitors may require using the new Tunable Loop™ feature to ensure that the module is stable as well as getting the best transient response (See the Tunable Loop™ section for details).
3. Unless otherwise indicated, specifications apply over all operating input voltage, resistive load, and temperature conditions.



### 5. GENERAL SPECIFICATIONS

PARAMETER		DESCRIPTION	MIN	ТҮР	MAX	UNIT
Efficiency	Vo=0.6V Vo=1.2V Vo=1.8V Vo=2.5V Vo=3.3V Vo=5.0V	Vin= 12Vdc, Ta=25°C Io=Io, max , Vo= Vo,set		76.4 86.0 89.9 92.2 93.6 95.4	-	%
Switching Frequency			-	600	-	kHz
Synchronization Frequency	/ Range		510	-	720	kHz
High-Level Input Voltage			2.0	-	-	V
Low-Level Input Voltage			-	-	0.4	V
Input Current, SYNC			-	-	100	nA
Minimum Pulse Width, SYN	1C		100	-	-	ns
Maximum SYNC rise time			100	-	-	ns
Over Temperature Protecti	on		-	130	-	°C
PMBus Over Temperature Threshold	0		-	120	-	°C
PMBus Adjustable Input Ur Lockout Thresholds	nder Voltage		2.5	-	14	V
Resolution of Adjustable In Voltage Threshold			-	-	500	mV
Input Undervoltage Lockou Turn-on Threshold Turn-off Threshold Hysteresis	t		2.475 2.25 -	- - 0.25	3.025 2.75	V V V
Tracking Accuracy Power-Up: 2V/ms Power-Down: 2V/ms		Vin, min to Vin, max; lo, min to lo, max, Vseq < Vo	-	-	100 100	mV mV
PGOOD (Power Good) Overvoltage threshold for F Overvoltage threshold for F Undervoltage threshold for Undervoltage threshold for Pulldown resistance of PG Sink current capability into	PGOOD OFF PGOOD ON PGOOD OFF OOD pin	Signal Interface Open Drain, Vsupply ≤ 5Vdc	-	108 110 92 90 -	- - - 50 5	%Vo,set %Vo,set %Vo,set Ω mA
Weight		0.04oz	-	1.1	-	g
MTBF		Calculated MTBF (IO=0.8IO, max, TA=40°C) Telecordia Issue 2 Method 1 Case 3		15,223,204		hours
Dimensions Inches (L × W × H) Millimeters (L × W × H)				0. 8 x 0.45 x 0.1 20.32 x 11.43x 2.	-	Inches Millimeters

Note: Unless otherwise indicated, specifications apply over all operating input voltage, resistive load, and temperature conditions.



 Asia-Pacific
 Europe,

 +86 755 298 85888
 +355


Europe, Middle East +353 61 225 977 +1 408 785 5200

### 6. DIGITAL INTERFACE SPECIFICATIONS

PARAMETER	DESCRIPTION	MIN	TYP	MAX	UNIT
PMBus Signal Interface Characteristics					
Input High Voltage (CLK, DATA)		2.1	-	3.6	V
Input Low Voltage (CLK, DATA)		-	-	0.8	V
Input high level current (CLK, DATA)		-10	-	10	uA
Input low level current (CLK, DATA)		-10	-	10	uA
Output Low Voltage (CLK, DATA, SMBALERT#)	lout =2mA	-	-	0.4	V
Output high level open drain leakage current (DATA, SMBALERT#)	Vout =3.6V	0	-	10	uA
Pin capacitance		-	0.7	-	pF
PMBus Operating frequency range		10	-	400	kHZ
Data setup time		250	-	-	ns
Data hold time	<u>Receive Mode</u> Transmit Mode	0 300	-	-	ns
Measurement System Characteristics					
Read delay time		153	192	231	us
Output current measurement range		0	-	18	А
Output current measurement resolution		62.5	-	-	mA
Output current measurement gain accuracy		-	-	$\pm 5$	%
Output current measurement offset		-	-	0.1	А
Vour measurement range		0	-	5.5	V
V <sub>OUT</sub> measurement resolution		-	15.625	-	mA
Vout measurement gain accuracy		-15	-	15	%
Vour measurement offset		-3	-	3	%
VIN measurement range		3	-	14.4	V
VIN measurement resolution		-	32.5	-	mV
VIN measurement gain accuracy		-15	-	15	%
VIN measurement offset		-5.5	-	1.4	LSB



### 7. EFFICIENCY DATA






Asia-Pacific +86 755 298 85888


Europe, Middle East +353 61 225 977





bel power solutions & protection

tech.support@psbel.com belpowersolutions.com






 Asia-Pacific
 Europ

 +86 755 298 85888
 +3


Europe, Middle East +353 61 225 977 North America +1 408 785 5200

© 2016 Bel Power Solutions & Protection

#### **10. TRANSIENT RESPONSE WAVEFORMS**




Transient Response to Dynamic Load Change from 50% to 100% at 12Vin, Cout=1x47uF + 11x330uF, CTune=47nF, RTune=180. Vo=0.6V




TIME, t (20μs /div)

Transient Response to Dynamic Load Change from 50% to 100% at 12Vin, Cout= 2x47uF + 2x330uF, CTune=5600pF, RTune=220. Vo=1.8V



Transient Response to Dynamic Load Change from 50% to 100% at 12Vin, Cout= 2x47uF+ 1x330uF ,CTune=2700pF, RTune=300. Vo=3.3V





TIME, t (20µs /div)


Transient Response to Dynamic Load Change from 50% to 100% at 12Vin, Cout=3x47uF + 3x330uF, CTune=12nF, RTune=220. Vo=1.2V

VO (V) (50m V/div)

IO (A) (5Adiv)


OUTPUT VOLTAGE

OUTPUT CURRENT,



TIME, t (20µs /div)


Transient Response to Dynamic Load Change from 50% to 100% at 12Vin, Cout=2x47uF+ 1x330uF, CTune=3300pF, RTune=240. Vo=2.5V



Transient Response to Dynamic Load Change from 50% to 100% at 12Vin, Cout=2x47uF,CTune=2200pF, RTune=300. Vo=5.0V

tech.support@psbel.com belpowersolutions.com

### **11. STARTUP TIME**



Start-up Using On/Off Voltage (Io = Io,max), Vo=5.0V




Asia-Pacific +86 755 298 85888

Europe, Middle East +353 61 225 977

North America +1 408 785 5200

© 2016 Bel Power Solutions & Protection

### **STARTUP TIME(CONTINUED)**



bel power solutions & a bel group


tech.support@psbel.com belpowersolutions.com

#### **12. INPUT FILTERING**

The SLDM-12D1Ax module should be connected to a low ac-impedance source. A highly inductive source can affect the stability of the module. An input capacitance must be placed directly adjacent to the input pin of the module, to minimize input ripple voltage and ensure module stability.

To minimize input voltage ripple, ceramic capacitors are recommended at the input of the module. Figure 37 shows the input ripple voltage for various output voltages at 12A of load current with 1x22 µF or 2x22 µF ceramic capacitors and an input of 12V.

#### Figure 37



Note: Input ripple voltage for various output voltages with 2x22 µF or 3x22 µF ceramic capacitors at the input (12A load). Input voltage is 12V.



**Asia-Pacific** +86 755 298 85888

ic Europe, Middle East +353 61 225 977

 iddle East
 North America

 \$1 225 977
 +1 408 785 5200


© 2016 Bel Power Solutions & Protection

#### **13. OUTPUT FILTERING**

These modules are designed for low output ripple voltage and will meet the maximum output ripple specification with  $3x0.047 \ \mu\text{F}$  ceramic and  $2x47 \ \mu\text{F}$  ceramic capacitors at the output of the module. However, additional output filtering may be required by the system designer for a number of reasons. First, there may be a need to further reduce the output ripple and noise of the module. Second, the dynamic response characteristics may need to be customized to a particular load step change.

To reduce the output ripple and improve the dynamic response to a step load change, additional capacitance at the output can be used. Low ESR polymer and ceramic capacitors are recommended to improve the dynamic response of the module. Figure 38 provides output ripple information, measured with a scope with its Bandwidth limited to 20MHz for different external capacitance values at various Vo and a full load current of 12A. For stable operation of the module, limit the capacitance to less than the maximum output capacitance as specified in the electrical specification table. Optimal performance of the module can be achieved by using the Tunable LoopTM feature described later in this data sheet.

Figure 38



Note: Output ripple voltage for various output voltages with external 2x47 µF, 4x47 µF, 6x47 µF or 8x47 µF ceramic capacitors at the output (12A load). Input voltage is 12V.

#### **14. SAFETY CONSIDERATIONS**

For safety agency approval the power module must be installed in compliance with the spacing and separation requirements of the enduse safety agency standards, i.e., UL 60950-1 2nd, CSA C22.2 No. 60950-1-07, DIN EN 60950-1:2006 + A11 (VDE0805 Teil 1 + A11):2009-11; EN 60950-1:2006 + A11:2009-03.

For the converter output to be considered meeting the requirements of safety extra-low voltage (SELV), the input must meet SELV requirements. The power module has extra-low voltage (ELV) outputs when all inputs are ELV.

The input to these units is to be provided with a fast acting fuse (for example, Bel Fuse SMM series) with a maximum rating of 20 A in the positive input lead.



#### 14

### 15. REMOTE ON/OFF

PARAMETER		DESCRIPTION	MIN	TYP	MAX	UNIT
Signal Low (Unit On)	Active Low	The remote on off his energy light on	-0.2	-	0.6	V
Signal High (Unit Off)	Active Low	The remote on/off pin open, Unit on.	-	-	1	V
Signal Low (Unit Off)	Active High	The remote on/off pin open, Unit on.	-	-	2	V
Signal High (Unit On)	Active High		2.0	-	Vin,max	V

The module can be turned ON and OFF either by using the ON/OFF pin (Analog interface) or through the PMBus interface (Digital). The module can be configured in a number of ways through the PMBus interface to react to the two ON/OFF inputs: Module ON/OFF can be controlled only through the analog interface (digital interface ON/OFF commands are ignored) Module ON/OFF can be controlled only through the PMBus interface (analog interface is ignored) Module ON/OFF can be controlled by either the analog or digital interface

The default state of the module (as shipped from the factory) is to be controlled by the analog interface only. If the digital interface is to be enabled, or the module is to be controlled only through the digital interface, this change must be made through the PMBus. These changes can be made and written to non-volatile memory on the module so that it is remembered for subsequent use.



Asia-Pacific +86 755 298 85888

Europe, Middle East +353 61 225 977

North America +1 408 785 5200

© 2016 Bel Power Solutions & Protection


#### 16. ANALOG ON/OFF

The SLDM-12D1Ax power modules feature an On/Off pin for remote On/Off operation. Two On/Off logic options are available. In the Positive Logic On/Off option, (device code suffix "0" – see Ordering Information), the module turns ON during a logic High on the On/Off pin and turns OFF during a logic Low. With the Negative Logic On/Off option, (device code suffix "L" – see Ordering Information), the module turns OFF during logic Low. With the Negative Logic On/Off option, (device code suffix "L" – see Ordering Information), the module turns OFF during logic High and ON during logic Low. The On/Off signal should be always referenced to ground. For either On/Off logic option, leaving the On/Off pin disconnected will turn the module ON when input voltage is present.

For positive logic modules, the circuit configuration for using the On/Off pin is shown in Figure 39. When the external transistor Q2 is in the OFF state, the internal transistor Q7 is turned ON, which turn Q3 OFF which keeps Q6 OFF and Q5 OFF. This allows the internal PWM #Enable signal to be pulled up by the internal 3.3V, thus turning the module ON. When transistor Q2 is turned ON, the On/Off pin is pulled low, which turns Q7 OFF which turns Q3, Q6 and Q5 ON and the internal PWM #Enable signal is pulled low and the module is OFF. A suggested value for Rpullup is  $20k\Omega$ .


For negative logic On/Off modules, the circuit configuration is shown in Fig. 40. The On/Off pin should be pulled high with an external pull-up resistor (suggested value for the 3V to 14V input range is 20Kohms). When transistor Q2 is in the OFF state, the On/Off pin is pulled high, transistor Q3 is turned ON. This turns Q6 ON, followed by Q5 turning ON which pulls the internal ENABLE low and the module is OFF. To turn the module ON, Q2 is turned ON pulling the On/Off pin low, turning transistor Q3 OFF, which keeps Q6 and Q5 OFF resulting in the PWM Enable pin going high.

Figure 39



Circuit configuration for using positive On/Off logic

#### Figure 40



Circuit configuration for using negative On/Off logic



16

#### **17. DIGITAL ON/OFF**

Please see the Digital Feature Descriptions section.

#### **18. MONOTONIC START-UP AND SHUTDOWN**

The SLDM-12D1Ax module has monotonic start-up and shutdown behavior for any combination of rated input voltage, output current and operating temperature range.


#### **19. STARTUP INTO PRE-BIASED OUTPUT**

The SLDM-12D1Ax module can start into a prebiased output as long as the prebias voltage is 0.5V less than the set output voltage.

#### **20. OUTPUT VOLTAGE PROGRAMMING**


The output voltage of the module is programmable to any voltage from 0.6Vdc to 5.5Vdc by connecting a resistor between the Trim and SIG\_GND pins of the module. Certain restrictions apply on the output voltage set point depending on the input voltage. These are shown in the Output Voltage vs. Input Voltage Set Point Area plot in Fig. 41. The Upper Limit curve shows that for output voltages lower than 1V, the input voltage must be lower than the maximum of 14.4V. The Lower Limit curve shows that for output voltages higher than 0.6V, the input voltage needs to be larger than the minimum of 3V.

#### Figure 41



Output Voltage vs. Input Voltage Set Point Area plot showing limits where the output voltage can be set for different input voltages.

#### Figure 42



Circuit configuration for programming output voltage using an external resistor.



**Asia-Pacific** +86 755 298 85888

 cific
 Europe, Middle East

 888
 +353 61 225 977

 East
 North America

 25 977
 +1 408 785 5200

© 2016 Bel Power Solutions & Protection

#### **21. OUTPUT TRIM EQUATIONS**

Without an external resistor between Trim and SIG\_GND pins, the output of the module will be 0.6Vdc.To calculate the value of the trim resistor, Rtrim for a desired output voltage, should be as per the following equation:

$$Rtrim = \left[\frac{12}{(Vo - 0.6)}\right] k\Omega$$

Rtrim is the external resistor in  $K\Omega$  Vo is the desired output voltage.

Table 1 provides Rtrim values required for some common output voltages.

Table 1

VO, set (V)	Rtrim (KΩ)
0.6	Open
0.9	40
1.0	30
1.2	20
1.5	13.33
1.8	10
2.5	6.316
3.3	4.444
5.0	2.727

By using a  $\pm 0.5\%$  tolerance trim resistor with a TC of  $\pm 100$  ppm, a set point tolerance of  $\pm 1.5\%$  can be achieved as specified in the electrical specification.

#### **22. DIGITAL OUTPUT VOLTAGE ADJUSTMENT**

Please see the Digital Feature Descriptions section.

#### **23. REMOTE SENSE**


The SLDM-12D1Ax power modules has a Remote Sense feature to minimize the effects of distribution losses by regulating the voltage between the sense pins (VS+ and VS-). The voltage drop between the sense pins and the VOUT and GND pins of the module should not exceed 0.5V.



### 24. VOLTAGE MARGINING

Output voltage margining can be implemented in the SLDM-12D1Ax modules by connecting a resistor, Rmargin-up, from the Trim pin to the ground pin for margining-up the output voltage and by connecting a resistor, Rmargin-down, from the Trim pin to output pin for margining-down. Figure 43 shows the circuit configuration for output voltage margining. Please consult your local Bel Power technical representative for additional details.

Figure 43



Circuit Configuration for margining Output voltage

#### **25. DIGITAL OUTPUT VOLTAGE MARGINING**

Please see the Digital Feature Descriptions section.



**Asia-Pacific** +86 755 298 85888 Europe, Middle East +353 61 225 977

 st
 North America

 77
 +1 408 785 5200

© 2016 Bel Power Solutions & Protection


#### **26. OUTPUT VOLTAGE SEQUENCING**

The SLDM-12D1Ax module includes a sequencing feature, EZ-SEQUENCE that enables users to implement various types of output voltage sequencing in their applications. This is accomplished via an additional sequencing pin. When not using the sequencing feature, leave it unconnected.

The voltage applied to the SEQ pin should be scaled down by the same ratio as used to scale the output voltage down to the reference voltage of the module. This is accomplished by an external resistive divider connected across the sequencing voltage before it is fed to the SEQ pin as shown in Fig. 44. In addition, a small capacitor (suggested value 100pF) should be connected across the lower resistor R1.

For SLDM-12D1Ax modules, the minimum recommended delay between the ON/OFF signal and the sequencing signal is 10ms to ensure that the module output is ramped up according to the sequencing signal. This ensures that the module soft-start routine is completed before the sequencing signal is allowed to ramp up.

Figure 44



Circuit showing connection of the sequencing signal to the SEQ pin

When the scaled down sequencing voltage is applied to the SEQ pin, the output voltage tracks this voltage until the output reaches the set-point voltage. The final value of the sequencing voltage must be set higher than the set-point voltage of the module. The output voltage follows the sequencing voltage on a one-to-one basis. By connecting multiple modules together, multiple modules can track their output voltages to the voltage applied on the SEQ pin.

To initiate simultaneous shutdown of the modules, the SEQ pin voltage is lowered in a controlled manner. The output voltage of the modules tracks the voltages below their set-point voltages on a one-to-one basis. A valid input voltage must be maintained until the tracking and output voltages reach ground potential.

Note that in all of modules, the PMBus Output Undervoltage Fault will be tripped when sequencing is employed. This will be detected using the STATUS\_WORD and STATUS\_VOUT PMBus commands. In addition, the SMBALERT# signal will be asserted low as occurs for all faults and warnings. To avoid the module shutting down due to the Output Undervoltage Fault, the module must be set to continue operation without interruption as the response to this fault (see the description of the PMBus command VOUT\_UV\_FAULT\_RESPONSE for additional information).

#### **27. OVERCURRENT PROTECTION**

To provide protection in a fault (output overload) condition, the unit is equipped with internal current-limiting circuitry and can endure current limiting continuously. At the point of current-limit inception, the unit enters hiccup mode. The unit operates normally once the output current is brought back into its specified range.

#### **28. DIGITAL ADJUSTABLE OVERCURRENT WARNING**

Please see the Digital Feature Descriptions section.

#### **29. OVERTEMPERATURE PROTECTION**

To provide protection in a fault condition, the unit is equipped with a thermal shutdown circuit. The unit will shut down if the overtemperature threshold of  $150^{\circ}$  (typ) is exceeded at the thermal reference point Tref. Once the unit goes into thermal shutdown it will then wait to cool before attempting to restart.



tech.support@psbel.com belpowersolutions.com

20

#### **30. DIGITAL TEMPERATURE STATUS VIA PMBUS**

Please see the Digital Feature Descriptions section.

#### **31. DIGITAL ADJUSTABLE OUTPUT OVER AND UNDER VOLTAGE PROTECTION**

Please see the Digital Feature Descriptions section

### **32. INPUT UNDERVOLTAGE LOCKOUT**

At input voltages below the input undervoltage lockout limit, the module operation is disabled. The module will begin to operate at an input voltage above the undervoltage lockout turn-on threshold.

#### **33. DIGITAL ADJUSTABLE INPUT UNDERVOLTAGE LOCKOUT**

Please see the Digital Feature Descriptions section


#### **34. DIGITAL ADJUSTABLE POWER GOOD THERSHOLDS**

Please see the Digital Feature Descriptions section

#### **35. SYNCHRONIZATION**

The module switching frequency can be synchronized to a signal with an external frequency within a specified range. Synchronization can be done by using the external signal applied to the SYNC pin of the module as shown in Fig. 45, with the converter being synchronized by the rising edge of the external signal. The Electrical Specifications table specifies the requirements of the external SYNC signal. If the SYNC pin is not used, the module should free run at the default switching frequency. **If synchronization is not being used, connect the SYNC pin to GND.** 

Figure 45



External source connections to synchronize switching frequency of the module.

#### **36. MEASURING OUTPUT CURRENT, OUTPUT VOLTAGE AND INPUT VOLTAGE**

Please see the Digital Feature Descriptions section.



**Asia-Pacific** +86 755 298 85888

ic Europe, Middle East +353 61 225 977

Idle East No 225 977 +1 4

© 2016 Bel Power Solutions & Protection

North America +1 408 785 5200




#### 37. TUNABLE LOOPTM

The SLDM-12D1Ax has a feature that optimizes transient response of the module called Tunable Loop™ .

External capacitors are usually added to the output of the module for two reasons: to reduce output ripple and noise (see Figure 38) and to reduce output voltage deviations from the steady-state value in the presence of dynamic load current changes. Adding external capacitance however affects the voltage control loop of the module, typically causing the loop to slow down with sluggish response. Larger values of external capacitance could also cause the module to become unstable.

The Tunable Loop<sup>™</sup> allows the user to externally adjust the voltage control loop to match the filter network connected to the output of the module. The Tunable Loop<sup>™</sup> is implemented by connecting a series R-C between the VS+ and TRIM pins of the module, as shown in Fig. 46. This R-C allows the user to externally adjust the voltage loop feedback compensation of the module.

Figure 46



Circuit diagram showing connection of RTUME and CTUNE to tune the control loop of the module

Recommended values of RTUNE and CTUNE for different output capacitor combinations are given in Tables 2 and 3. Table 3 shows the recommended values of RTUNE and CTUNE for different values of ceramic output capacitors up to 1000uF that might be needed for an application to meet output ripple and noise requirements. Selecting RTUNE and CTUNE according to Table 3 will ensure stable operation of the module.

In applications with tight output voltage limits in the presence of dynamic current loading, additional output capacitance will be required. Table 3 lists recommended values of RTUNE and CTUNE in order to meet 2% output voltage deviation limits for some common output voltages in the presence of a 6A to 6A step change (50% of full load), with an input voltage of 12V.

Please contact your Bel Power technical representative to obtain more details of this feature as well as for guidelines on how to select the right value of external R-C to tune the module for best transient performance and stable operation for other output capacitance values.

Table 2

Со	2x47μF	4x47μF	6x47μF	10x47μF	20x47μF
RTUNE	430	390	300	240	180
CTUNE	390pF	15000pF	2700pF	3300pF	8200pF

General recommended values of of RTUNE and CTUNE for Vin=12V and various external ceramic capacitor combinations.

Table 3

Vo	5V	3.3V	2.5V	1.8V	1.2V	0.6V
Со	1x47uF + 330μF Polymer	1x47uF + 330μF Polymer	2x47uF + 330μF Polymer	1x47uF + 2x330μF Polymer	3x47uF +3x 330μF Polymer	1x47uF + 11x330μF Polymer
RTUNE	300	300	240	220	220	180
CTUNE	2200pF	2200pF	3300pF	5600pF	12nF	47nF
ΔV	55mV	58mV	47mV	31mV	21mV	8mV

Recommended values of RTUNE and CTUNE to obtain transient deviation of 2% of Vout for a 3A step load with Vin=12V

Note: The capacitors used in the Tunable Loop tables are 47 µF/3 mΩ ESR ceramic and 330 µF/12 mΩ ESR polymer capacitors



tech.support@psbel.com belpowersolutions.com

22

#### 38. PMBUS INTERFACE CAPABILITY

The SLDM-12D1Ax power modules have a PMBus interface that supports both communication and control. The PMBus Power Management Protocol Specification can be obtained from www.pmbus.org. The modules support a subset of version 1.1 of the specification (see Table 6 for a list of the specific commands supported). Most module parameters can be programmed using PMBus and stored as defaults for later use


All communication over the module PMBus interface must support the Packet Error Checking (PEC) scheme. The PMBus master must generate the correct PEC byte for all transactions, and check the PEC byte returned by the module.

The module also supports the SMBALERT response protocol whereby the module can alert the bus master if it wants to talk. For more information on the SMBus alert response protocol, see the System Management Bus (SMBus) specification.

The module has non-volatile memory that is used to store configuration settings. Not all settings programmed into the device are automatically saved into this non-volatile memory, only those specifically identified as capable of being stored can be saved (see Table 6 for which command parameters can be saved to non-volatile storage).

### **39. PMBUS DATA FORMAT**

For commands that set thresholds, voltages or report such quantities, the module supports the "Linear" data format among the three data formats supported by PMBus. The Linear Data Format is a two byte value with an 11-bit, two's complement mantissa and a 5-bit, two's complement exponent. The format of the two data bytes is shown below:



The value is of the number is then given by Value = Mantissa x 2 Expone



Asia-Pacific +86 755 298 85888

Europe, Middle East +353 61 225 977

North America

© 2016 Bel Power Solutions & Protection

+1 408 785 5200

#### 40. PMBUS ADDRESSING

The power module can be addressed through the PMBus using a device address. The module has 64 possible addresses (0 to 63 in decimal) which can be set using resistors connected from the ADDR0 and ADDR1 pins to SIG\_GND. Note that some of these addresses (0, 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11 12, 40, 44, 45, 55 in decimal) are reserved according to the SMBus specifications and may not be useable. The address is set in the form of two octal (0 to 7) digits, with each pin setting one digit. The ADDR1 pin sets the high order digit and ADDR0 sets the low order digit. The resistor values suggested for each digit are shown in Table 4 (1% tolerance resistors are recommended).


Note that if either address resistor value is outside the range specified in Table 4, the module will respond to address 127.

Table 4

Digit	Resistor Value (KΩ)
0	10
1	15.4
2	23.7
3	36.5
4	54.9
5	84.5
6	130
7	200

The user must know which I<sup>2</sup>C addresses are reserved in a system for special functions and set the address of the module to avoid interfering with other system operations. Both 100kHz and 400kHz bus speeds are supported by the module. Connection for the PMBus interface should follow the High Power DC specifications given in section 3.1.3 in the SMBus specification V2.0 for the 400kHz bus speed or the Low Power DC specifications in section 3.1.2. The complete SMBus specification is available from the SMBus web site, smbus.org.

Figure 48



Circuit showing connection of resistors used to set the PMBus address of the module.



24

#### **41. PMBUS ENABLE ON/OFF**

The SLDM-12D1Ax module can also be turned on and off via the PMBus interface. The OPERATION command is used to actually turn the module on and off via the PMBus, while the ON\_OFF\_CONFIG command configures the combination of analog ON/OFF pin input and PMBus commands needed to turn the module on and off. Bit [7] in the OPERATION command data byte enables the module, with the following functions:

#### 0 : Output is disabled

1 : Output is enabled

This module uses the lower five bits of the ON\_OFF\_CONFIG data byte to set various ON/OFF options as follows:

Bit Position	4	3	2	1	0
Access	r/w	r/w	r/w	r/w	r
Function	PU	CMD	CPR	POL	CPA
Default Value	1	0	1	1	1

PU: Sets the default to either operate any time input power is present or for the ON/OFF to be controlled by the analog ON/OFF input and the PMBus OPERATION command. This bit is used together with the CP, CMD and ON bits to determine startup.

Bit Value	Action
0	Module powers up any time power is present regardless of state of the analog ON/OFF pin
1	Module does not power up until commanded by the analog ON/OFF pin and the OPERATION command as programmed in bits [2:0] of the ON_OFF_CONFIG register.

CMD: The CMD bit controls how the device responds to the OPERATION command.

Bit Value	Action
0	Module ignores the ON bit in the OPERATION command
1	Module responds to the ON bit in the OPERATION command

CPR: Sets the response of the analog ON/OFF pin. This bit is used together with the CMD, PU and ON bits to determine startup.

Bit Value	Action
0	Module ignores the analog ON/OFF pin, i.e. ON/OFF is only controlled through the PMBUS via the OPERATION command
1	Module requires the analog ON/OFF pin to be asserted to start the unit



Asia-Pacific Europe, Middle East +86 755 298 85888 +353 61 225 977

 ope, Middle East
 North America

 +353 61 225 977
 +1 408 785 5200

25

© 2016 Bel Power Solutions & Protection

#### 42. PMBUS ADJUSTABLE SOFT START RISE TIME

The soft start rise time can be adjusted in the module via PMBus. When setting this parameter, make sure that the charging current for output capacitors can be delivered by the module in addition to any load current to avoid nuisance tripping of the overcurrent protection circuitry during startup. The TON\_RISE command sets the rise time in ms, and allows choosing soft start times between 600µs and 9ms, with possible values listed in Table 5. Note that the exponent is fixed at -4 (decimal) and the upper two bits of the mantissa are also fixed at 0

Table 5

Rise Time	Exponent	Mantissa
600µs	11100	0000001010
900µs	11100	0000001110
1.2ms	11100	0000010011
1.8ms	11100	00000011101
2.7ms	11100	00000101011
4.2ms	11100	00001000011
6.0ms	11100	00001100000
9.0ms	11100	00010010000

#### 43. OUTPUT VOLTAGE ADJUSTMENT USING THE PMBUS

The VOUT\_SCALE\_LOOP parameter is important for a number of PMBus commands related to output voltage trimming, margining, over/under voltage protection and the PGOOD thresholds. The output voltage of the module is set as the combination of the voltage divider formed by RTrim and a  $20k\Omega$  upper divider resistor inside the module, and the internal reference voltage of the module. The reference voltage VREF is nominally set at 600mV, and the output regulation voltage is then given by

$$V_{OUT} = \left[\frac{20000 + RTrim}{RTrim}\right] \times V_{REF}$$

Hence the module output voltage is dependent on the value of RTrim which is connected external to the module. The information on the output voltage divider ratio is conveyed to the module through the VOUT SCALE LOOP parameter which is calculated as follows:

$$VOUT\_SCALE\_LOOP = \frac{RTrim}{20000 + RTrim}$$

The VOUT\_SCALE\_LOOP parameter is specified using the "Linear" format and two bytes. The upper five bits [7:3] of the high byte are used to set the exponent which is fixed at -9 (decimal). The remaining three bits of the high byte [2:0] and the eight bits of the lower byte are used for the mantissa. The default value of the mantissa is 0010000000 corresponding to 256 (decimal), corresponding to a divider ratio of 0.5. The maximum value of the mantissa is 512 corresponding to a divider ratio of 1. Note that the resolution of the VOUT\_SCALE\_LOOP command is 0.2%.

When PMBus commands are used to trim or margin the output voltage, the value of VREF is what is changed inside the module, which in turn changes the regulated output voltage of the module.

The nominal output voltage of the module can be adjusted with a minimum step size of 0.4% over a ±25% range from nominal using the VOUT\_TRIM command over the PMBus.

The VOUT\_TRIM command is used to apply a fixed offset voltage to the output voltage command value using the "Linear" mode with the exponent fixed at -10 (decimal). The value of the offset voltage is given by

$$V_{OUT(offset)} = VOUT \_ TRIM \times 2^{-10}$$

This offset voltage is added to the voltage set through the divider ratio and nominal VREF to produce the trimmed output voltage. The valid range in two's complement for this command is \_\_\_\_\_4000h to 3FFFh. The high order two bits of the high byte must both be either 0 or 1. If a value outside of the +/-25% adjustment range is given with this command, the module will set it's output voltage to the nominal value (as if VOUT\_TRIM had been set to 0), assert SMBALRT#, set the CML bit in STATUS\_BYTE and the invalid data bit in STATUS\_CML.



tech.support@psbel.com belpowersolutions.com

#### 44. OUTPUT VOLTAGE MARGINING USING THE PMBUS

The module can also have its output voltage margined via PMBus commands. The command VOUT\_MARGIN\_HIGH sets the margin high voltage, while the command VOUT\_MARGIN\_LOW sets the margin low voltage. Both the VOUT\_MARGIN\_HIGH and VOUT\_MARGIN\_LOW commands use the "Linear" mode with the exponent fixed at –10 (decimal). Two bytes are used for the mantissa with the upper bit [7] of the high byte fixed at 0. The actual margined output voltage is a combination of the VOUT\_MARGIN\_HIGH or VOUT\_MARGIN\_LOW and the VOUT\_TRIM values as shown below:

$$V_{OUT(MH)} =$$

$$(VOUT\_MARGIN\_HIGH+VOUT\_TRIM) \times 2^{-10}$$

 $V_{OUT(ML)} =$ 

### (VOUT MARGIN LOW+VOUT TRIM) $\times 2^{-10}$

Note that the sum of the margin and trim voltages cannot be outside the ±25% window around the nominal output voltage. The data associated with VOUT\_MARGIN\_HIGH and VOUT\_MARGIN\_LOW can be stored to non-volatile memory using the STORE\_DEFAULT\_ALL command.

The module is commanded to go to the margined high or low voltages using the OPERATION command. Bits [5:2] are used to enable margining as follows:

00XX : Margin Off 0101 : Margin Low (Ignore Fault) 0110 : Margin Low (Act on Fault) 1001 : Margin High (Ignore Fault) 1010 : Margin High (Act on Fault)

#### 45. PMBUS ADJUSTABLE OVERCURRENT WARNING

The module can provide an overcurrent warning via the PMBus. The threshold for the overcurrent warning can be set using the parameter  $IOUT_OC_WARN\_LIMIT$ . This command uses the "Linear" data format with a two byte data word where the upper five bits [7:3] of the high byte represent the exponent and the remaining three bits of the high byte [2:0] and the eight bits in the low byte represent the mantissa. The exponent is fixed at -1 (decimal).

The upper five bits of the mantissa are fixed at 0 while the lower six bits are programmable. Note that the actual value for IOUT\_OC\_WARN\_LIMIT will vary from module to module due to calibration during production test, The resolution of this warning limit is 500mA. The value of the IOUT\_OC\_WARN\_LIMIT can be stored to non-volatile memory using the STORE\_DEFAULT\_ALL command.

#### 46. TEMPERATURE STATUS VIA PMBUS

The SLDM-12D1Ax module can provide information related to temperature of the module through the STATUS\_TEMPERATURE command. The command returns information about whether the pre-set over temperature fault threshold and/or the warning threshold have been exceeded.



**Asia-Pacific** +86 755 298 85888

 Europe, Middle East

 38
 +353 61 225 977

 East
 North America

 977
 +1 408 785 5200

© 2016 Bel Power Solutions & Protection

#### 47. PMBUS ADJUSTABLE OUTPUT OVER AND UNDER VOLTAGE PROTECTION

The SLDM-12D1Ax module has output over and under voltage protection capability. The PMBus command VOUT\_OV\_FAULT\_LIMIT is used to set the output over voltage threshold from four possible values: 108%, 110%, 112% or 115% of the commanded output voltage. The command VOUT\_UV\_FAULT\_LIMIT sets the threshold that causes an output under voltage fault and can also be selected from four possible values: 92%, 90%, 88% or 85%. The default values are 112% and 88% of commanded output voltage. Both commands use two data bytes formatted as two's complement binary integers. The "Linear" mode is used with the exponent fixed to –10 (decimal) and the effective over or under voltage trip points given by:

$$V_{OUT (OV\_REQ)} = (VOUT\_OV\_FAULT\_LIMIT) \times 2^{-10}$$
$$V_{OUT (UV\_REQ)} = (VOUT\_UV\_FAULT\_LIMIT) \times 2^{-10}$$

Values within the supported range for over and undervoltage detection thresholds will be set to the nearest fixed percentage. Note that the correct value for VOUT\_SCALE\_LOOP must be set in the module for the correct over or under voltage trip points to be calculated.

In addition to adjustable output voltage protection, the 6A Digital module can also be programmed for the response to the fault. The VOUT\_OV\_FAULT RESPONSE and VOUT\_UV\_FAULT\_RESPONSE commands specify the response to the fault. Both these commands use a single data byte with the possible options as shown below.

- Continue operation without interruption (Bits [7:6] = 00, Bits [5:3] = xxx).
- Continue for four switching cycles and then shut down if the fault is still present, followed by no restart or continuous restart (Bits [7:6] = 01, Bits [5:3] = 000 means no restart, Bits [5:3] = 111 means continuous restart).
- Immediate shut down followed by no restart or continuous restart (Bits [7:6] = 10, Bits [5:3] = 000 means no restart, Bits [5:3] = 111 means continuous restart).
- Module output is disabled when the fault is present and the output is enabled when the fault no longer exists (Bits [7:6] = 11, Bits [5:3] = xxx).

Note: that separate response choices are possible for output over voltage or under voltage faults.

#### 48. PMBUS ADJUSTABLE INPUT UNDERVOLTAGE LOCKOUT

The SLDM-12D1Ax module allows adjustment of the input under voltage lockout and hysteresis. The command VIN\_ON allows setting the input voltage turn on threshold, while the VIN\_OFF command sets the input voltage turn off threshold. For the VIN\_ON command, possible values are 2.75V, and 3V to 14V in 0.5V steps. For the VIN\_OFF command, possible values are 2.5V to 14V in 0.5V steps. If other values are entered for either command, they will be mapped to the closest of the allowed values.

VIN\_ON must be set higher than VIN\_OFF. Attempting to write either VIN\_ON lower than VIN\_OFF or VIN\_OFF higher than VIN\_ON results in the new value being rejected, SMBALERT being asserted along with the CML bit in STATUS\_BYTE and the invalid data bit in STATUS\_CML.

Both the VIN\_ON and VIN\_OFF commands use the "Linear" format with two data bytes. The upper five bits represent the exponent (fixed at -2) and the remaining 11 bits represent the mantissa. For the mantissa, the four most significant bits are fixed at 0.



#### 49. POWER GOOD

The SLDM-12D1Ax module provides a Power Good (PGOOD) signal that is implemented with an open-drain output to indicate that the output voltage is within the regulation limits of the power module. The PGOOD signal will be de-asserted to a low state if any condition such as overtemperature, overcurrent or loss of regulation occurs that would result in the output voltage going outside the specified thresholds. The PGOOD thresholds are user selectable via the PMBus (the default values are as shown in the Feature Specifications Section). Each threshold is set up symmetrically above and below the nominal value. The POWER\_GOOD\_ON command sets the output voltage level above which PGOOD is asserted (lower threshold). For example, with a 1.2V nominal output voltage, the POWER\_GOOD\_ON threshold can set the lower threshold to 1.14 or 1.1V. Doing this will automatically set the upper thresholds to 1.26 or 1.3V.

The POWER\_GOOD\_OFF command sets the level below which the PGOOD command is de-asserted. This command also sets two thresholds symmetrically placed around the nominal output voltage. Normally, the POWER\_GOOD\_ON threshold is set higher than the POWER\_GOOD\_OFF threshold.

Both POWER\_GOOD\_ON and POWER\_GOOD\_OFF commands use the "Linear" format with the exponent fixed at -10 (decimal). The two thresholds are given by

$$V_{OUT(PGOOD\_ON)} = (POWER\_GOOD\_ON) \times 2^{-10}$$
$$V_{OUT(PGOOD\_OFF)} = (POWER\_GOOD\_OFF) \times 2^{-10}$$

Both commands use two data bytes with bit [7] of the high byte fixed at 0, while the remaining bits are r/w and used to set the mantissa using two's complement representation. Both commands also use the VOUT\_SCALE\_LOOP parameter so it must be set correctly. The default value of POWER\_GOOD\_ON is set at 1.1035V and that of the POWER\_GOOD\_OFF is set at 1.08V. The values associated with these commands can be stored in non-volatile memory using the STORE DEFAULT ALL command.

The PGOOD terminal can be connected through a pullup resistor(suggested value 100 K $\Omega$ ) to a source of 5VDC or lower.

#### 50. MEASURREMENT OF OUTPUT CURRENT, OUTPUT VOLTAGE AND INPUT VOLTAGE

The SLDM-12D1Ax module is capable of measuring key module parameters such as output current and voltage and input voltage and providing this information through the PMBus interface. Roughly every 200µs, the module makes 16 measurements each of output current, voltage and input voltage. Average values of of these 16 measurements are then calculated and placed in the appropriate registers. The values in the registers can then be read using the PMBus interface.



**Asia-Pacific** +86 755 298 85888

**Europe, Middle East** +353 61 225 977

t North America 7 +1 408 785 5200

© 2016 Bel Power Solutions & Protection

#### **51. MEASURING OUTPUT CURRENT USING THE PMBUS**

The SLDM-12D1Ax module measures current by using the inductor winding resistance as a current sense element. The inductor winding resistance is then the current gain factor used to scale the measured voltage into a current reading. This gain factor is the argument of the IOUT\_CAL\_GAIN command, and consists of two bytes in the linear data format. The exponent uses the upper five bits [7:3] of the high data byte in two's complement format and is fixed at –15 (decimal). The remaining 11 bits in two's complement binary format represent the mantissa.

The current measurement accuracy is also improved by each module being calibrated during manufacture with the offset in the current reading. The IOUT\_CAL\_OFFSET command is used to store and read the current offset. The argument for this command consists of two bytes composed of a 5-bit exponent (fixed at -4d) and a 11-bit mantissa. This command has a resolution of 62.5mA and a range of -4000mA to +3937.5mA. During manufacture, each module is calibrated by measuring and storing the current gain factor and offset into non-volatile storage.

The READ\_IOUT command provides module average output current information. This command only supports positive or current sourced from the module. If the converter is sinking current a reading of 0 is provided. The READ\_IOUT command returns two bytes of data in the linear data format. The exponent uses the upper five bits [7:3] of the high data byte in two-s complement format and is fixed at –4 (decimal). The remaining 11 bits in two's complement binary format represent the mantissa with the 11th bit fixed at 0 since only positive numbers are considered valid.

Note that the current reading provided by the module is not corrected for temperature. The temperature corrected current reading for module temperature TModule can be estimated using the following equation

$$I_{OUT,CORR} = \frac{I_{READ_OUT}}{1 + [(T_{IND} - 30) \times 0.00393]}$$

where IOUT\_CORR is the temperature corrected value of the current measurement, IREAD\_OUT is the module current measurement value, TIND is the temperature of the inductor winding on the module. Since it may be difficult to measure TIND, it may be approximated by an estimate of the module temperature.

#### 52. MEASURING OUTPUT VOLTAGE USING THE PMBUS

The SLDM-12D1Ax module can provide output voltage information using the READ\_VOUT command. The command returns two bytes of data all representing the mantissa while the exponent is fixed at -10 (decimal).

During manufacture of the module, offset and gain correction values are written into the non-volatile memory of the module. The command VOUT\_CAL\_OFFSET can be used to read and/or write the offset (two bytes consisting of a 16-bit mantissa in two's complement format) while the exponent is always fixed at -10 (decimal). The allowed range for this offset correction is -125 to 124mV. The command VOUT\_CAL\_GAIN can be used to read and/or write the gain correction - two bytes consisting of a five-bit exponent (fixed at -8) and a 11-bit mantissa. The range of this correction factor is -0.125V to +0.121V, with a resolution of 0.004V. The corrected output voltage reading is then given by:

$$\begin{split} V_{OUT}(Final) &= \\ [V_{OUT}(Initial) \times (1 + VOUT\_CAL\_GAIN)] \\ &+ VOUT\_CAL\_OFFSET \end{split}$$

#### 53. MEASURING INPPUT VOLTAGE USING THE PMBUS

The SLDM-12D1Ax module can provide output voltage information using the READ\_VIN command. The command returns two bytes of data in the linear format. The upper five bits [7:3] of the high data form the two's complement representation of the mantissa which is fixed at -5 (decimal). The remaining 11 bits are used for two's complement representation of the mantissa, with the 11th bit fixed at zero since only positive numbers are valid.

During module manufacture, offset and gain correction values are written into the non-volatile memory of the module. The command VIN\_CAL\_OFFSET can be used to read and/or write the offset - two bytes consisting of a five-bit exponent (fixed at -5) and a11-bit mantissa in two's complement format. The allowed range for this offset correction is -2 to 1.968V, and the resolution is 32mV. The command VIN\_CAL\_GAIN can be used to read and/or write the gain correction - two bytes consisting of a five-bit exponent (fixed at -8) and a 11-bit mantissa. The range of this correction factor is -0.125V to +0.121V, with a resolution of 0.004V. The corrected output voltage reading is then given by:

 $V_{IN}(Final) = [V_{IN}(Initial) \times (1 + VIN \_ CAL \_ GAIN)] + VIN \_ CAL \_ OFFSET$ 



tech.support@psbel.com belpowersolutions.com

#### 54. READING THE STATUS OF THE MODULE USING THE PMBUS

The SLDM-12D1Ax module supports a number of status information commands implemented in PMBus. However, not all features are supported in these commands. A 1 in the bit position indicates the fault that is flagged.

STATUS\_BYTE : Returns one byte of information with a summary of the most critical device faults.

Bit Position	Flag	Default Value
7	Х	0
6	OFF	0
5	VOUT Overvoltage	0
4	IOUT Overcurrent	0
3	VIN Undervoltage	0
2	Temperature	0
1	CML (Comm. Memory Fault)	0
0	None of the above	0

STATUS\_WORD : Returns two bytes of information with a summary of the module's fault/warning conditions.

Bit Position	Flag	Default Value
7	Х	0
6	OFF	0
5	VOUT Overvoltage	0
4	IOUT Overcurrent	0
3	VIN Undervoltage	0
2	Temperature	0
1	CML (Comm. Memory Fault)	0
0	None of the above	0

Bit Position	Flag	Default Value
7	VOUT fault or warning	0
6	IOUT fault or warning	0
5	Х	0
4	Х	0
3	POWER_GOOD# (is negated)	0
2	Х	0
1	Х	0
0	Х	0



Asia-Pacific +86 755 298 85888

Europe, Middle East +353 61 225 977 North America +1 408 785 5200

© 2016 Bel Power Solutions & Protection

### **READING THE STATUS OF THE MODULE USING THE PMBUS(CONTINUED)**

STATUS\_VOUT : Returns one byte of information relating to the status of the module's output voltage related faults.

Bit Position	Flag	Default Value
7	VOUT OV Fault	0
6	Х	0
5	Х	0
4	VOUT UV Fault	0
3	Х	0
2	Х	0
1	Х	0
0	Х	0

STATUS\_IOUT : Returns one byte of information relating to the status of the module's output voltage related faults.

Bit Position	Flag	Default Value
7	IOUT OC Fault	0
6	Х	0
5	IOUT OC Warning	0
4	Х	0
3	Х	0
2	Х	0
1	Х	0
0	Х	0

#### STATUS\_TEMPERATURE : Returns one byte of information relating to the status of the module's temperature related faults.

Bit Position	Flag	Default Value
7	OT Fault	0
6	OT Warning	0
5	Х	0
4	Х	0
3	Х	0
2	Х	0
1	Х	0
0	X	0

STATUS\_CML : Returns one byte of information relating to the status of the module's communication related faults.

Bit Position	Flag	Default Value
7	Invalid/Unsupported Command	0
6	Invalid/Unsupported Command	0
5	Packet Error Check Failed	0
4	Х	0
3	Х	0
2	Х	0
1	Other Communication Fault	0
0	Х	0



tech.support@psbel.com belpowersolutions.com

#### **READING THE STATUS OF THE MODULE USING THE PMBUS(CONTINUED)**

MFR\_VIN\_MIN : Returns minimum input voltage as two data bytes of information in Linear format (upper five bits are exponent – fixed at -2, and lower 11 bits are mantissa in two's complement format – fixed at 12)

MFR\_VOUT\_MIN : Returns minimum output voltage as two data bytes of information in Linear format (upper five bits are exponent – fixed at -10, and lower 11 bits are mantissa in two's complement format – fixed at 614)

**MFR\_SPECIFIC\_00**: Returns information related to the type of module and revision number. Bits [7:2] in the Low Byte indicate the module type (000000 corresponds to the SLDN-06D1Ax series of module), while bits [7:3] indicate the revision number of the module.

Flag	Default Value
Module Name	000101
Reserved	10
High Byte	
Flag	Default Value
Module Revision Number	None
Reserved	000
	Module Name Reserved High Byte Flag Module Revision Number

Low Byte



Asia-Pacific +86 755 298 85888

Europe, Middle East +353 61 225 977 North America +1 408 785 5200

© 2016 Bel Power Solutions & Protection

33

### 55. SUMMARY OF SUPPORTED PMBUS COMMANDS

Please refer to the PMBus 1.1 specification for more details of these commands. Table 6  $\,$ 

Hex Code	Command	Brief Description									Non-Volatile Memory Storage	
		Turn Module on or	Turn Module on or off. Also used to margin the output voltage									
	OPERATION	Format Unsigned Binary										
		Bit Position	7	6	5	4	3	2	1	0		
01		Access	r/w	r	r/w	r/w	r/w	r/w	r	r		
		Function	On	X		Ma	rgin		X	X		
		Default Value	0	0	0	0	0	0	X	X		
-		Configurat the ONL	OFF fun	tionalit		mhinat	ion of a		N/OFF	in and		
		Configures the ON/OFF functionality as a combination of analog ON/OFF pin and PMBus commands										
		Format Unsigned Binary										
02	ON OFF CONFIG										YES	
UL.		Access	r	r	r	r/w	r/w	r/w	r/w	r		
		Function	X	X	X	DU	cmd	cpr	pol	cpa		
		Default Value	0	0	0	1	0	1	1	1		
				-		-	-	-	-		0	
03	CLEAR_FAULTS	Clear any fault bits	and the second sec	A STREET BOARD AND A STREET BOARD	een set	, also re	eases th	ne SMB/	ALERT#	signal if		
		the device has been		-						-		
		Used to control wri										
		setting in the modu						value in	the dat	a byte		
		into non-volatile m	emory (E	EPRON		and the second se				1		
		Format	-	-	1	Unsigne		1				
		Bit Position	7	6	5	4	3	2	1	0		
	WRITE_PROTECT	Access	r/w	r/w	r/w	X	X	X	X	X		
		Function	bit7	bit6	bit5	X	X	X	X	X		
10		Default Value	0	0	0	X	X	X	X	X	WEE.	
10		Bit5: 0 - Enables al									YES	
		1 - Disables all writes except the WRITE_PROTECT, OPERATION										
		and ON_OFF_CONFIG (bit 6 and bit 7 must be 0)										
		Bit 6: 0 – Enables all writes as permitted in bit5 or bit7										
		1 - Disables all writes except for the WRITE_PROTECT and OPERATION commands (bit5 and bit7 must be 0)										
		Bit7: 0 – Enables all writes as permitted in bit5 or bit6										
		Bit/: 0 = Enables all writes as permitted in bits or bits 1 = Disables all writes except for the WRITE_PROTECT command										
		(bit5 and bi										
W2020		Copies all current n	egister s	ettings i	n the m	odule in	to non-	volatile	memor	v		
11	STORE_DEFAULT_ALL	(EEPROM) on the m										
		Restores all current	register	setting	s in the	module	from va	lues in t	the mod	dule non-		
12	RESTORE_DEFAULT_ALL	volatile memory (E	EPROM)									
		Copies the current	register	setting i	n the m	odule w	hose co	mmand	code m	atches		
		the value in the dat	a byte in	to non-	volatile	memor	Y (EEPR	OM) on	the mo	dule		
13	STORE_DEFAULT_CODE	Bit Position	7	6	5	4	3	2	1	0		
		Access	w	w	w	w	W	w	W	w		
		Function				Comma	nd code					
		Restores the currer										
		the value in the data byte from the value in the module non-volatile memory										
		(EEPROM)						201	-	20		
14	RESTORE_DEFAULT_CODE	Bit Position	7	6	5	4	3	2	1	0		
		Access	w	W	W	w	W	W	W	W		
		Function Command code										
		The module has MODE set to Linear and Exponent set to -10. These values cannot										
		be changed										
20	VOUT_MODE	Bit Position	7	6	5	4	3	2	1	0		
20		Access	r	(r)	r	r	( <b>r</b> )	r	r	Г		
		Function		Mode			1	Exponen	it			
		Default Value	0	0	0	1	0	1	1	0		



tech.support@psbel.com belpowersolutions.com

### SUMMARY OF SUPPORTED PMBUS COMMANDS(CONTINUED)

Hex Code	Command		Non-Volatile Memory Storage										
		Apply a fixed offset	Apply a fixed offset voltage to the output voltage command value										
		Format											
		Bit Position	7	6	5	4	3	2	1	0			
		Access	r/w	r	r/w	r/w	r/w	r/w	r/w	r/w			
		Function				High	Byte						
22	VOUT_TRIM	Default Value	0	0	0	0	0	0	0	0	YES		
		Bit Position	7	6	5	4	3	2	1	0			
		Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w			
		Function				Low	Byte						
		Default Value	0	0	0	0	0	0	0	0			
2		E-s-sh-s-s-s						0.2911	56270				
		Sets the target volta	age tor r		-			an biana	30				
			Format Linear, two's complement binary										
		Bit Position	7	6	5	4	3	2	1	0			
		Access	r	r/w	r/w	r/w	r/w	r/w	r/w	r/w			
25	VOUT_MARGIN_HIGH	Function		-		-	Byte				YES		
		Default Value	0	0	0	0	0	1	0	1			
		Bit Position	7	6	5	4	3	2	1	0			
		Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w			
		Function	-		28.0		Byte						
		Default Value	0	1	0	0	0	1	1	1			
26	VOUT_MARGIN_LOW	Sets the target volta			inear, t	wo's co	mpleme	-	-				
		Bit Position	7	6	5	4	3	2	1	0			
		Access	٢	r/w	r/w	r/w	r/w	r/w	r/w	r/w			
		Function			-	-	Byte			-	YES		
		Default Value	0	0	0	0	0	1	0	0			
		Bit Position	7	6	5	4	3	2	1	0			
		Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w			
		Function			1	1	Byte						
		Default Value	0	1	0	1	0	0	0	1			
	VOUT_SCALE_LOOP	Sets the scaling of the output voltage – equal to the feedback resistor divider ratio Format Linear, two's complement binary											
		Bit Position	7	6	5	4	3	2	1	0			
		Access	r	r	r	r	г	r	r/w	r/w			
		Function			Exponen			-	Mantiss		( Charles and C		
29		Default Value	1	0	1	1	1	0	0	1	YES		
		Bit Position	7	6	5	4	3	2	1	0			
		Access	r/w	r/w	r/w	r/w	r/w	r/w	r/w	r/w			
		Function				Mar	tissa						
		Default Value	0	0	0	0	0	0	0	0			
5			0.000										
		Sets the value of in	put volta	-									
	VIN_ON	Format	-				mpleme		1				
		Bit Position	7	6	5	4	3	2	1	0			
		Access	r	r	r	r	r	r	r	r			
35		Function			Exponen				Mantiss		YES		
		Default Value	1	1	1	1	0	0	0	0			
		Bit Position	7	6	5	4	3	2	1	0			
		Access	r	r/w	r/w	r/w	r/w	r/w	r/w	r/w			
		Function				10007.55	itissa						
		Default Value	0	0	0	0	1	0	1	1	í l		



Asia-Pacific Eur +86 755 298 85888

 ific
 Europe, Middle East

 888
 +353 61 225 977

 East
 North America

 5 977
 +1 408 785 5200

35

### SUMMARY OF SUPPORTED PMBUS COMMANDS(CONTINUED)

Hex Code	Command	Brief Description									Non-Volatile Memory Storage			
		Sets the value of in than VIN_OFF. Sup 2.5V to 1												
		Format												
		Bit Position	7	6	5	4	3	2	1	0				
36	VIN_OFF	Access	r	r	г	E.	ſ	٢	٢	r	YES			
		Function	-	-	Exponen			-	Mantiss	-				
		Default Value	1	1	1	1	0	0	0	0				
		Bit Position	7	6	5	4	3	2	1	0				
		Access	r	r/w	r/w	r/w	0W	ťw	r/w	tíw				
		Function					tissa							
		Default Value	0	0	0	0	1	0	1	0				
		Returns the value of output current	of the ga		Lesse ration again			1010/1010-1-		be				
		Format		-	Linear, t	-		-	<u> </u>					
		Bit Position	7	6	5	4	3	2	1	0				
38	IOUT CAL GAIN	Access	r	r	r	r.	r	r	r	t/w	YES			
30	IOUT_CAL_GAIN	Function			Exponer				Mantiss	-	TES			
		Default Value	1	0	0	0	1	0	0	V				
		Bit Position	7	6	5	4	3	2	1	0				
		Access	r/w	r/w	r/w	r/w	r/w tissa	t/w	t/w	tiw				
		Function	-											
		Default Value		V: V	ariable	based o	n factor	y calibr	ation					
		Returns the value of the offset correction term used to correct the measured output current Format Linear, two's complement binary												
	IOUT_CAL_OFFSET	Format Bit Position	7	6	5	woscor 4	npieme 3	nt binar	1	0				
		Access	ſ	r	r	-	r	z/w	7	r	4			
39		Function	1		Exponen		1		Mantiss	15	YES			
		Default Value	1		1	0	0	V	0	0				
		Bit Position	7	6	5	4	3	2	1	0				
		Access	r	r	r/w	r/w	t/w	t/w	t/w	ťw	•			
		Function					tissa				1			
		Default Value	0	0	V-V			n facto	ry calibri	ation	1			
				for an output overvoltage fault. Exponent is fixed at -10. s of 108%, 110%, 112% and 115% are available Linear, two's complement binary 7 6 5 4 3 2 1 0										
40	VOUT_OV_FAULT_LIMIT	Access	7	r/w	o r/w	e r/w	5 r/w	z/w	t/w	r/w				
		Function	r	1/W	SH/₩.		Byte	1/W	1/W	TrW	YES			
		Default Value	0	0	0		0	1	0	1				
		Bit Position	7	6	5	4	3	2	1	0				
		Access	r/w	c/w	r/w	r/w	t/w	ے تاw	t/w	ťw	•			
		Function		12.99	17.84		Byte	17.66		11 11				
		Default Value	0	0	0	0	a yue	0	1	0				



tech.support@psbel.com belpowersolutions.com

### SUMMARY OF SUPPORTED PMBUS COMMANDS(CONTINUED)

Hex Code	Command	Brief Description								Non-Volatile Memory Storage				
41	VOUT_OV_FAULT_RESPONSE	Instructs the modul fault. The options a 00 - Module 01 Module 101 - Module 11 - Module s RS[2:0] 000 - Module 111 - Module	YES											
		Format												
		Bit Position	7	6	5	4	3	2	1	0				
		Access	r/w	D'W	r/w	r/w	t/w	ſ	r	r				
		Function	RSP [1]	RSP [0]	RS[2]	RS[1]	RS[0]	x	x	x				
		Default Value	1	1	1	1	1	1	0	0				
		Sets the voltage lev Four fixed percenta								at -10.				
		Format		1	inear, t	wo's con	mpleme	nt bina	ry					
		Bit Position	7	6	5	4	3	2	1	0				
44	VOUT_UV_FAULT_LIMIT	Access	r	D/W	DW	r/w	r/w	DW.	dw.	t/w				
		Function				-	Byte				YES			
		Default Value	0	0	0	0	0	1	0	0				
		Bit Position Access	r/w	6 r/w	5 r/w	4 r/w	3 r/w	2 p/w	t/w	0 r/w				
		Function Low Byte												
		Default Value	1	0	0	0	dyte 1	1	1	1				
45	VOUT_UV_FAULT_RESPONSE	The options are: RS 02 - Module 13 Module 1 fault per 02- Module shuts 11 - Module shuts RS[2:0] 000 - Module does 111- Module goes t Format Bit Position Access	OD0 – Module does not attempt to restart           111- Module goes through normal startup continuously.           Format         Unsigned Binary           Bit Position         7         6         5         4         3         2         1         0							YES				
		Function Default Value	RSP [1] 0	RSP [0]	RS[2]	RS[1]	RS[0]	X	X	X				
		Sets the output over												
		Format				1	mpleme		ry					
		Bit Position	7	6	5	4	3	2	1	0				
		Access	r	r	r	r	г	r	r	r				
46	IOUT OC FAULT LIMIT	Function			Exponen	10			Mantiss		YES			
-	NOCI_CO_ ADDI_CMIN	Default Value	1	1	1	1	1	0	0	0	TES			
		Bit Position	7	6	5	4	3	2	1	0				
		Access	r	1	r	1	r	r	r -	r				
		Function Default Value	0	0	0	Man	tissa		~					



**Asia-Pacific** +86 755 298 85888

 ific
 Europe, Middle East

 888
 +353 61 225 977

 e East
 North America

 25 977
 +1 408 785 5200

© 2016 Bel Power Solutions & Protection

### SUMMARY OF SUPPORTED PMBUS COMMANDS(CONTINUED)

Hex Code	Command		Brief Description								Non-Volatile Memory Storage				
		Sets the output ov													
		Format Linear, two's complement binary													
		Bit Position	7	6	5	4	3	2	1	0	1				
		Access	1	r	r	ſ	r	r	r	r	1				
4A	INT OR WARDIN INT	Function		1	Expone	int			Mantiss	a	YES				
44	IOUT_OC_WARN_LIMIT	Default Value	1	1	1	1	1	0	0	0	TES				
		Bit Position	7	6	5	4	3	2	1	0					
		Access	r	r	r/w	riw	t/w	r/w	d/w	r/w	]]				
		Function	1			Ma	ntissa								
		Default Value	0	0	0	1	1	1	0	1					
		Sets the output vo Exponent is fixed		evel at	which t	he PG(	DOD pin	is ass	erted hi	ġh.					
		Format		L	inear, I	wo's co	mplem	ent bina	ary	94	1				
		Bit Position	7	6	5	4	3	2	1	0	11				
		Access	r	r/w	r/w	r/w	t/w	ťw	d/w	r/w					
		Function			50 20	Hig	h Byte		1	10 63					
	POWER_GOOD_ON	Default Value	0	0	0	0	0	1	0	0	11				
		Bit Position	7	6	5	4	3	2	1	0	YES				
5E		Access	¢/w	r/w	r/w	riw	t/w	r/w	r/w	r/w					
UL.		Function				Lov	Byte	-							
		Default Value	0	1	1	0	1	0	1	0					
		POWER_GOOD_ON LEVELS													
		LOW HIGH													
		95% 10													
		92% 108%													
	7	90% 110% Sets the output voltage level at which the PGOOD pin is de-asserted low.													
		Exponent is fixed		aver at	eringer t		100 pill	ia uero	53301 (B)	u iuw.					
		Format		two's	comple	mont	hinary				1				
		Bit Position	7	6	5	4	3	2	1	0	11				
		Access	r	r/w	r/w	r/w	r/w	rlw	r/w	ť/w	11				
		Function	High E							10.00	1				
		Default Value	0	0	0	0	0	1	0	0	1				
CORE		Bit Position	7	6	5	4	3	2	1	0	100000000				
5F	POWER_GOOD_OFF	Access	r/w	r/w	r/w	t/w	r/w	r/w	r/w	t/w	YES				
		Function	Low B	yte					100 C						
		Default Value	0	1	0	1	0	0	1	0					
		POWER_GOOD_	OFF L	EVELS	3			- C.	1.1	8.	ʻ				
		92% 10 90% 11	GH 8% 0% 2%												



### SUMMARY OF SUPPORTED PMBUS COMMANDS(CONTINUED)

Hex Code	Command			Brie	f Des	criptie	on				Non-Volatile Memory Storage	
		Sets the rise time										
		0.6ms, 0.9ms, 1.2										
		Format										
		Bit Position	7	6	5	4	3	2	1	0		
		Access	r	r	r	r	r	r	7	r/w		
61	TON RISE	Function		E	xpone	nt		٨	lantiss	a	YES	
		Default Value	1	1	1	0	0	0	0	0		
		Bit Position	7	6	5	4	3	2	1	0		
		Access	r/w	r/w	r/w	r/w	t/w	t/w	r/w	r/w		
		Function				Man	tissa					
		Default Value	0	0	1	0	1	0	1	0		
		Returns one byte faults	of infor	mation	with a s	summar	ry of the	e most d	critical i	module		
		Format		10	1	Jnsigne	d Binar	'Y		a - 14		
78	STATUS BYTE	Bit Position	7	6	5	4	3	2	1	0		
10	aTATUA_BTTE	Access	r	٢	r	1	r	٦	ſ	r		
		Flag	x	OFF			VIN_ UV	TEMP	CML	OTHE		
		Default Value	0	0	0	0	0	0	0	0		
			Returns two bytes of information with a summary of the module's fault/warning conditions									
		Format			1	Jnsigne	d Binar	'y				
		Bit Position	7	6	5	4	3	2	1	0		
	STATUS_WORD	Access	r	r	r	r	r	r	r	r		
79		Flag	VOUT	IOUT OC	x	x	PGO OD	x	x	×		
100480		Default Value	0	0	0	0	0	0	0	0		
		Bit Position	7	6	5	4	3	2	1	0		
		Access	٢	٢	r	r	r	٢	r	r		
		Flag	x	OFF			VIN_ UV	TEMP	CML	OTHE R		
		Default Value	0	0	0	0	0	0	0	0		
		Returns one byte voltage related fau		mation			1		's outp	ut		
		Format				Jnsigne		<u> </u>				
7A	STATUS_VOUT	Bit Position	7		6 3	5	4	3	2 1	0		
		Access		t.		r	٢		r r	r.		
		Flag	VOUT	VO_T	X )	( VOL	JT_UV		XX	_		
		Default Value	0		0 0		0	100 Aug 100	0 0	0		
		Returns one byte current related fau		mation	with the	e status	of the	module	's outp	ut		
		Format	6			Unsigne	d Binar					
7B	STATUS IOUT	Bit Position	7		6	5		4 3	2	1 0		
18	STATUS_1001	Access	ſ	ee	r	r	_	r r	٢	r r		
		Flag	IOUT	<u>_oc</u>	X	DUT_O		x x	x	x x		
		Default Value	0	)	0	0		0 0	0	0 0		



**Asia-Pacific** +86 755 298 85888

ic Europe, Middle East +353 61 225 977

 Ile East
 North America

 225 977
 +1 408 785 5200

### SUMMARY OF SUPPORTED PMBUS COMMANDS(CONTINUED)

Hex Code	Command	Brief Description									Non-Volatile Memory Storage	
		Returns one byte related faults	perature									
		Format Unsigned Binary										
7D	STATUS TEMPERATURE	Bit Position	7		6	5	4	3	2	1 0		
10		Access			1		r	r	r		r r	
		Flag	OT F				X	X	X		XX	
		Default Value	0	1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1	0	100 C	0	0	0	1000	0 0	
		Returns one byte	of infor	matior	n with th	e statu	us of	the r	nodule	e's		
		communication related faults										
		Format				Unsign	ned E	Binar	/			
		Bit Position	7		6	5	4	3	2	1	0	
7E	STATUS_CML	Access	r		r	r	r	r	r	r	r	
		Flag	Inva Comn		Invalid Data	PEC Fail	x	x	x	Other Comm Fault	n X	
		Default Value	0		Ó	0	0	0	0	Ô	Ó	
		Returns the value	of the i	nput v	oltage a	applied	to ti	he m	odule			
		Format			Linear, I							
		Bit Position	7	6	5	4		3	2	1	0	
88		Access	r	r	r	r		r	٢	٢	r	
	READ VIN	Function	tion Exponent					Mantiss	a			
	READ_VIN	Default Value	1	1	0	1		1	0	0	0	
		Bit Position	7	6	5	4		3	2	1	0	
		Access	٢	r	1	r	_	r	r	r	٢	
		Function					antiss	sa				
-		Default Value	0	0	0	0	_	0	0	0	0	
		Returns the value of the output voltage of the module. Exponent is fixed at -10.										
		Format										
		Bit Position	7	6	5	4		3	2	1	0	
1000		Access	r	r	ſ	f		٢	r	r	E	
88	READ_VOUT	Function					antiss					
		Default Value	0	0	0	0		0	0	0	0	
		Bit Position	7	6	5	4		3	2	1	0	
		Access	r	r	ſ	1		r	r	Ē	1	
		Function				-	antise		2		1	
		Default Value	0	0	0	0	_	0	0	0	0	
		Returns the value	of the d									
		Format	-	-	Linear, I	_	omp	-	_			
		Bit Position	7	6	5	4	+	3	2	1	0	
		Access	r	r	r Evenend	T I		r	r	r Mantiss	1	
8C	READ_IOUT	Default Value	1	1	Expone 1		-	0	0	Mantiss	0	
		Bit Position	7	6	5	4	+	3	2	1	0	
		Access	r	r	r	r	+	r	r	r	r	
		Function	1040				antiss					
		Default Value	0	0	0	0		0	0	0	0	
		Returns one byte (read only)				-	_	-	-	-	-	
		Format				Unsign	ned E	Binar	y			
98	PMBUS_REVISION	Bit Position	7	6	5	4		3	2	1	0	YES
		Access	г	г	r	ſ		r	r	ĩ	r	
		Default Value	0	0	0	1		0	0	0	1	



### SUMMARY OF SUPPORTED PMBUS COMMANDS(CONTINUED)

Hex Code	Command			Brie	f Des	criptio	on				Non-Volatile Memory Storage		
		Returns the minim	um inp	ut volta	ge the	module	is spec	cified to	operat	e at	,		
		(read only)			000				1150				
AO		Format		L	inear, tv	NO'S CO	mpleme	ent bina	ary				
		Bit Position	7	6	5	4	3	2	1	0			
		Access	٢	r	r	r	r	r	r	r			
	MFR_VIN_MIN	Function			xponer			-	Mantiss		YES		
										0			
		Bit Position	7	6	5	4	3	2	1	0			
		Access	r	r	r	r	r	r	r	r			
		Function					tissa						
		Default Value	0	0	0	0	1	1	0	0			
-		Returns the minim	-			-	rom the	modul	-	-			
		Format			inear, ty		The second second second			Gally/			
		Bit Position	7	6	5	4	3	2	1	0			
		Access	r	r	r		r	r	r	r			
		Function			11. 1		tissa	E	E	I.			
A4	MFR_VOUT_MIN	Default Value	0	0	0	0	0	0	1	0	YES		
		Bit Position	7	6	5	4	3	2	1	0			
			-										
		Access Function	٢	٢	r	1	r	r	ŕ	r			
			-	1	1		1	1	1				
		Default Value	0			0	0	ા	1	0			
		Returns module na											
		Format	_		-	Insigne		-	r				
		Bit Position	7	6	5	4	3	2	1	0			
	MFR_SPECIFIC_00	Access	1	r	r	ſ	r	r	٢	r			
DO		Function				-	erved				YES		
		Default Value	0	0	0	0	0	0	0	0	120		
		Bit Position	7	6	5	4	3	2	1	0			
		Access	٢	r	٢	٢	r	1	٢	r			
		Function				e Name	_			erved			
		Default Value	0	0	0	0	0	1	X	X			
l l		Applies an offset t											
		offset errors in module measurements of the output voltage (between -											
		125mV and +124mV). Exponent is fixed at -10.  Format Linear, two's complement binary											
		Format		1	-	1	1	-					
		Bit Position	7	6	5	4	3	2	1	0			
D4	VOUT_CAL_OFFSET	Access	r/w	r	r	ſ	r	r	r	r	YES		
		Function	1.	-	1 -		tissa	L é					
		Default Value	V	0	0	0	0	0	0	0			
		Bit Position	7	6	5	4	3	2	1	0			
		Access	r/w	r/w	r/w	r/w	r/w	r/w	¢/w	r/w			
		Function		1		-	tissa		1				
		Default Value	V	V	V	V	V	V	V	V			
l l		Applies a gain con									9		
		out gain errors in r	nodule	measu	irement	s of the	output	voltage	e (betw	een -			
		0.125 and 0.121)							2007				
		Format			inear, tv								
		Bit Position	7	6	5	4	3	2	1	0			
D5	VOUT CAL GAIN	Access	٢	r	٢	r	r	r	r	ríw	YES		
00	COL_OUT_OUN	Function		_	xpone				Mantiss	-	100		
		Default Value	1	1	0	0	0	0	0	V			
		Bit Position	7	6	5	4	3	2	1	0			
		Access	t/w	r/w	r/w	r/w	r/w	t/w.	tiw	r/w			
		Function				1	tissa						
		Default Value	V	V	V	V	V	V	V	V	11		



**Asia-Pacific** +86 755 298 85888

 fic
 Europe, Middle East

 888
 +353 61 225 977

 East
 North America

 977
 +1 408 785 5200

### SUMMARY OF SUPPORTED PMBUS COMMANDS(CONTINUED)

Hex Code	Command	Brief Description							Non-Volatile Memory Storage		
		Applies an offset c out offset errors in and +1.968V)									
		Format		L	inear, ti	wo's co	mpleme	ent bina	ary		
		Bit Position	7	6	5	4	3	2	1	0	
		Access	r	r	r	r	r/w	r	r	r/w	
D6	VIN_CAL_OFFSET	Function		E	xpone	nt	÷		Mantiss	a	YES
		Default Value	1	1	0	1	V	0	0	V	
		Bit Position	7	6	5	4	3	2	1	0	
		Access	r	r	r/w	r/w	r/w	r/w	r/w	r/w	
		Function	Function Mantissa								
		Default Value	0	0	V	V	V	V	V	V	
		Applies a gain corr out gain errors in n 0.125 and 0.121)									
		Format									
		Bit Position	7	6	5	4	3	2	1	0	
		Access	r	r	r	r	r/w	r	1	ríw	
D7	VIN_CAL_GAIN	Function		E	xpone	nt			Mantiss	â	YES
		Default Value	1	1	0	0	V	0	0	V	
		Bit Position	7	6	5	4	3	2	1	0	
		Access	r	r	r	r/w	r/w	r/w	r/w	r/w	
		Function		- C.e.	50	Mar	tissa				
		Default Value	0	0	0	V	V	V	V	V	

Please refer to the PMBus 1.1 specification for more details of these commands.




#### **56. THERMAL CONSIDERATIONS**

The SLDM-12D1Ax power modules operate in a variety of thermal environments; however, sufficient cooling should always be provided to help ensure reliable operation.

Considerations include ambient temperature, airflow, module power dissipation, and the need for increased reliability. A reduction in the operating temperature of the module will result in an increase in reliability. The thermal data presented here is based on physical measurements taken in a wind tunnel. The test set-up is shown in Figure 49. The preferred airflow direction for the module is in Figure 50.

Figure 49




Thermal Test Setup

The thermal reference points, Tref used in the specifications are also shown in Figure 50. For reliable operation the temperatures at these points should not exceed 120°C. The output power of the module should not exceed the rated power of the module (Vo,set x Io,max)

Please refer to the Application Note "Thermal Characterization Process For Open-Frame Board-Mounted Power Modules" for a detailed discussion of thermal aspects including maximum device temperatures.

Figure 50



#### Preferred airflow direction and location of hot-spot of the module (Tref).



**Asia-Pacific** +86 755 298 85888

 a-Pacific
 Europe, Middle East

 98 85888
 +353 61 225 977

North America +1 408 785 5200

© 2016 Bel Power Solutions & Protection

Rev. AC

#### **57. EXAMPLE APPLICATION CIRCUIT**

Requirements: Vin: Vout: lout: ΔVout: Vin, ripple		1.5% of Vo	vorst case load transie out (27mV) for worst c n (180mV, p-p)		
	Vin+				Vout+
	1 1		VIN VOUT		
			-pgood <sup>VS+</sup> - MODULE - clk -seq		
	$\pm C13 \pm 0$	CI2 <sup>+</sup> CI1	DATA TRIM	1	$\pm \text{CO1} \pm \text{CO2} \pm \text{CO3}$
			SMBALRT# ADDR ADDR		
			ON/OFF	<b>≷RADDR≹RADDR</b> 0	
	GND		SIG_GNE SYNC GND VS-		

Cl1 Decoupling cap - 1x0.047µF/16V ceramic capacitor (e.g. Murata LLL185R71C473MA01)

- Cl2 2x22 µF/16V ceramic capacitor (e.g. Murata GRM32ER61C226KE20)
- CI3 470µF/16V bulk electrolytic

CO1 Decoupling cap - 1x0.047μF/16V ceramic capacitor (e.g. Murata LLL185R71C473MA01) + 0.1uF/16V 0402size ceramic capacitor

CO2 1 x 47µF/6.3V ceramic capacitor (e.g. Murata GRM31CR60J476ME19)

CO3 1 x 330µF/6.3V Polymer (e.g. Sanyo Poscap)

CTune 2700pF ceramic capacitor (can be 1206, 0805 or 0603 size)

RTune 221 ohms SMT resistor (can be 1206, 0805 or 0603 size)


RTrim 10kΩ SMT resistor (can be 1206, 0805 or 0603 size, recommended tolerance of 0.1%)

Note: The DATA, CLK and SMBALRT pins do not have any pull-up resistors inside the module. Typically, the SMBus master controller will have the pull-up resistors as well as provide the driving source for these signals.




44

#### **58. MECHANICAL DIMENSIONS**



TOP VIEW



Dimensions are in millimeters and (inches).

Tolerances: x.x mm  $\pm$  0.5 mm (x.xx in.  $\pm$  0.02 in.) [unless otherwise indicated] x.xx mm  $\pm$  0.25 mm (x.xxx in  $\pm$  0.010 in.)



Asia-Pacific +86 755 298 85888

Europe, Middle East +353 61 225 977


North America +1 408 785 5200

© 2016 Bel Power Solutions & Protection

45

#### **MECHANICAL DIMENSIONS (CONTINUED)**

Recommended Pad Layout



RECOMMENDED FOOTPRINT -THROUGH THE BOARD-

Dimensions are in millimeters and (inches). Tolerances: x.x mm  $\pm$  0.5 mm (x.xx in.  $\pm$  0.02 in.) [unless otherwise indicated] x.xx mm  $\pm$  0.25 mm (x.xxx in  $\pm$  0.010 in.)


Note: This module is recommended and compatible with Pb-Free Reflow Soldering and must be soldered using a reflow profile with a peak temperature of no more than 260 °C for less than 5 seconds.



#### **59. PACKAGING DETAILS**

The SLDM-12D1Ax modules are supplied in tape & reel as standard.

All Dimensions are in millimeters and (in inches).



Reel Dimensions: Outside Dimensions: Inside Dimensions: Tape Width:

330.2 mm (13.00) 177.8 mm (7.00") 44.00 mm (1.732")



Asia-Pacific Eur +86 755 298 85888

Europe, Middle East +353 61 225 977 North America +1 408 785 5200

© 2016 Bel Power Solutions & Protection

Rev. AC

#### **60. SURFACE MOUNT INFORMATION**

#### **Pick and Place**

The SLDM-12D1Ax modules use an open frame construction and are designed for a fully automated assembly process. The modules are fitted with a label designed to provide a large surface area for pick and place operations. The label meets all the requirements for surface mount processing, as well as safety standards, and is able to withstand reflow temperatures of up to 300oC. The label also carries product information such as product code, serial number and the location of manufacture.

#### **Nozzle Recommendations**

The SLDM-12D1Ax module weight has been kept to a minimum by using open frame construction. Variables such as nozzle size, tip style, vacuum pressure and placement speed should be considered to optimize this process. The minimum recommended inside nozzle diameter for reliable operation is 3mm. The maximum nozzle outer diameter, which will safely fit within the allowable component spacing, is 7 mm.

#### **Lead Free Soldering**

The SLDM-12D1Ax modules are lead-free (Pb-free) and RoHS compliant and fully compatible in a Pb-free soldering process. Failure to observe the instructions below may result in the failure of or cause damage to the modules and can adversely affect long-term reliability.

#### **Pb-free Reflow Profile**

Power Systems will comply with J-STD-020 Rev. C (Moisture/Reflow Sensitivity Classification for Nonhermetic Solid State Surface Mount Devices) for both Pb-free solder profiles and MSL classification procedures. This standard provides a recommended forced-air-convection reflow profile based on the volume and thickness of the package (table 4-2). The suggested Pb-free solder paste is Sn/Ag/Cu (SAC). The recommended linear reflow profile using Sn/Ag/Cu solder is shown in Fig. 50. Soldering outside of the recommended profile requires testing to verify results and performance.

#### **MSL** Rating

The SLDM-12D1Ax modules have a MSL rating of 2A.




#### **SURFACE MOUNT INFORMATION(CONTINUED)**

#### **Storage and Handling**

The recommended storage environment and handling procedures for moisture-sensitive surface mount packages is detailed in J-STD-033 Rev. A (Handling, Packing, Shipping and Use of Moisture/Reflow Sensitive Surface Mount Devices). Moisture barrier bags (MBB) with desiccant are required for MSL ratings of 2 or greater. These sealed packages should not be broken until time of use. Once the original package is broken, the floor life of the product at conditions of  $\leq$  30°C and 60% relative humidity varies according to the MSL rating (see J-STD-033A). The shelf life for dry packed SMT packages will be a minimum of 12 months from the bag seal date, when stored at the following conditions:  $< 40^{\circ}$  C, < 90% relative humidity.

Figure51

Reflow Temp (°C)



Recommended linear reflow profile using Sn/Ag/Cu solder.

#### **Post Solder Cleaning and Drying Considerations**

Post solder cleaning is usually the final circuit-board assembly process prior to electrical board testing. The result of inadequate cleaning and drying can affect both the reliability of a power module and the testability of the finished circuit-board assembly. For guidance on appropriate soldering, cleaning and drying procedures, refer to Board Mounted Power Modules: Soldering and Cleaning Application Note (AN04-001).



**Asia-Pacific** +86 755 298 85888 Europe, Middle East +353 61 225 977 North America +1 408 785 5200

© 2016 Bel Power Solutions & Protection

Rev. AC

### For more information on these products consult: tech.support@psbel.com

NUCLEAR AND MEDICAL APPLICATIONS - Products are not designed or intended for use as critical components in life support systems, equipment used in hazardous environments, or nuclear control systems. TECHNICAL REVISIONS - The appearance of products, including safety agency certifications pictured on labels, may change depending on the date manufactured. Specifications are subject to change without notice.

