

Din Rail Mount 17.5 mm Phase Sequence & Phase Failure MWS Part number 84873029



- Control of 3-phase networks : phase sequence, total phase failure
- Multi-voltage from 3 x 208 to 3 x 480 V AC
- Controls its own supply voltage
- True RMS measurement
- LED status indication

| num | |
|-----|--|
| | |
| | |

| | le a | D | |
|---------------------|-------------------------------|--|--------------------------------|
| Туре | Function | Nominal voltage (V) | Output |
| 84873029 MWS | Phase sequence, phase failure | $3 \times 208 \rightarrow 3 \times 480 \text{ V AC}$ | 1 single pole changeover relay |

Specifications

Supply

| AC supply voltage frequency | 50 / 60 Hz ± 10 % |
|--|-------------------|
| Galvanic isolation of power supply/measurement | No |
| Immunity from micro power cuts | 60 ms |

Inputs and measuring circuit

Frequency of measured signal 50 →60 Hz ± 10 %

Output

| Type of contacts | No cadmium |
|---|---------------------------------------|
| Max. breaking current | EMWS - MWS2 : 5 A AC/DC |
| | MWS: 8 A AC 250 V AC - 8 A DC 30 V DC |
| Maximum rate | 360 operations/hour at full load |
| Operating categories acc. to IEC/EN 60947-5-1 | AC12, AC13, AC14, AC15, DC12, DC13 |

Insulation

| Insulation coordination (IEC/EN 60664-1) | Overvoltage category III: degree of pollution 3 |
|--|---|
| Rated impulse withstand voltage (IEC/EN 60664-1) | 4 kV (1,2 / 50 μs) |
| Dielectric strength (IEC/EN 60664-1) | 2 kV AC 50 Hz 1 min. |
| | |

General characteristics

| Display relay | Yellow LED |
|---|---|
| Casing | 17,5 mm |
| Mounting | On 35 mm symmetrical DIN rail, IEC/EN 60715 |
| Mounting position | All positions |
| Material : enclosure plastic type VO to UL94 standard | Incandescent wire test according to IEC/EN 60695-2-11 |
| Protection (IEC/EN 60529) | Terminal block : IP20 |
| | Casing: IP30 |
| Operating temperature IEC/EN 60068-2 | -20 →+50 °C |
| Storage temperature IEC/EN 60068-2 | -40 →+70 °C |
| Humidity IEC/EN 60068-2-30 | 2 x 24 hr cycle 95 % RH max. without condensation 55 °C |
| Vibrations according to IEC/EN60068-2-6 | 10 →150 Hz, A = 0.035 mm |
| Shocks IEC/EN 60068-2-6 | 5 g |

Standards

| otanua d | |
|--|--|
| Product standard | IEC/EN 50178 |
| Electromagnetic compatibility (EMC) | IEC/EN 61000-6-1, IEC/EN 61000-6-2, IEC/EN 61000-6-3, IEC/EN 61000-6-4 |
| Certifications | MWS, MWS2 : CE, UL, CSA |
| | EMWS: CE, UL (cULus) |
| Conformity with environmental directives | RoHS |

Supply

| Supply voltage Un | 3 x 208 →3 x480 V AC* |
|------------------------------|-----------------------|
| Voltage supply tolerance | -12 % / +10 % |
| Operating range | 183 →528 V AC |
| Power consumption at Un | 1,8 VA |
| Inputs and measuring circuit | |

02/11/2015 www.crouzet.com


| 02/11/2015 | www.crouzet.co |
|--|--|
| Measurement ranges | 183 →528 V AC |
| Guaranteed phase failure detection threshold | < 30 VAC |
| Voltage threshold hysteresis | |
| Display precision | |
| Maximum regeneration (phase failure) | < 30 VAC |
| Timing | |
| Alarm on delay time max. | 130 ms |
| Delay on pick-up | ≤ 650 ms |
| Output | |
| Type of output | 1 single pole changeover relay |
| Maximum breaking voltage | 250 VAC / 8 AAC - 250 VDC / 0,3 A |
| Max. breaking current | 8 AAC 250 VAC - 8 ADC 30 VDC |
| Min. breaking current | 10 mA / 5 VDC |
| Electrical life (number of operations) | 1 x 10 ⁵ |
| Breaking capacity (V resistive) | 2000 VA/80W |
| Mechanical life (operations) | 10 x 10 ⁶ |
| Insulation | |
| Nominal insulation voltage IEC/EN 60664-1 | 400 V |
| Insulation resistance (IEC/EN 60664-1) | > 500 MΩ / 500 VDC |
| General characteristics | |
| "Fault" indication | |
| Weight | 80 g |
| Connecting capacity IEC/EN 60947-1 | Rigid: 1 x 4 ² - 2 x 2,5 ² mm ² 1 x 11 AWG - 2 x 14 AWG |
| | Flexible with ferrules : 1 x 2,5 ² - 2 x 1,5 ² mm ² 1 x 14 AWG - 2 x 16 AWG |
| Max. tightening torques IEC/EN 60947-1 | 0,6 →1 Nm / 5,3 →8,8 Lbf.In |

Comments

Accessories

| Description | Code |
|---|----------|
| Removable sealable cover for 17.5 mm casing | 84800000 |

10 →150 Hz, A = 0,035 mm



Operating principle

MWS-MWS2 : Phase controller

The relay monitors its own supply voltage.

The relay controls :

- correct sequencing of the three phases,
- total failure of one of the three phases.


When the phase sequence and voltages are correct (> 183 VAC), the output relay (s) are closed and the yellow LED is lit.

In the event of a phase sequence or total phase failure fault (detected when one of the voltages drops below 100 V), the relay opens instantly and its LED is extinguished.


When the unit is powered up with a measured fault, the relay stays open. $\label{eq:control}$

| Nº | Legend |
|----------|--|
| | MWS : Relais R MWS2 : Relais R1/R2 |
| ② | Temps de réponse à l'apparition d'un défaut (Tr) |

www.crouzet.com



mm



| No | Legend |
|----|-----------------------|
| • | 100 mA fast-blow fuse |

CA MWS

www.crouzet.com

× CA MWS



Customisable colours and labels