

VGA Camera Sensor PICtail™ Plus Daughter Board Information Sheet

Thank you for purchasing a VGA Camera Sensor PICtail Plus Daughter Board. This information sheet provides some important details that will help you successfully use the board as quickly as possible.

Additional information can be accessed at: <http://www.microchip.com>

Basic Requirements

The VGA Camera Sensor PICtail Plus Daughter Board was designed to work with a PICtail™ Plus connector. This connector can be found on many boards including the Explorer 16 Development Board (DM240001) and the Starter Kit I/O Expansion Board (DM320002).

The VGA Camera Sensor PICtail Plus Daughter Board uses an OmniVision Technologies CameraCubeChip™ to receive digital video images. These images are then controlled by the microcontroller via I/O ports. Depending on the desired use, there are eight DATAx jumpers on the daughter board that can be used to switch between I/O lines. There is another jumper (J10) that can be used to switch between using an external clock source or the microcontroller as a clock source for the OmniVision Technologies CameraCubeChip™.

Getting Started

To get started with the VGA Camera Sensor PICtail Plus Daughter Board, follow these steps:

1. Ensure that MPLAB® IDE is installed.
2. Download a project file for the daughter board from the Microchip web site.
3. Power the daughter board.
4. Connect a debugger/programmer.
5. Using MPLAB IDE, open the project that was previously downloaded.
6. Select a debugger/programmer in MPLAB IDE.
7. Click **Build**. This builds the downloaded project.
8. Click **Program all memories**.
9. Click **Run**.

Your VGA Camera Sensor PICtail Plus Daughter Board should now be up and running. To begin viewing the camera sensor image, either online or on an LCD, follow the guide that accompanies the chosen demonstration.

Americas

Atlanta - 678-957-9614
Boston - 774-760-0087
Chicago - 630-285-0071
Cleveland - 216-447-0464
Dallas - 972-818-7423
Detroit - 248-538-2250
Indianapolis - 317-773-8323
Los Angeles - 949-462-9523
Phoenix - 480-792-7200
Santa Clara - 408-961-6444
Toronto - 905-673-0699

Europe

Austria - Wels - 43-7242-2244-39
Denmark - Copenhagen - 45-4450-2828
France - Paris - 33-1-69-53-63-20
Germany - Munich - 49-89-627-144-0
Italy - Milan - 39-0331-742611
Netherlands - Drunen - 31-416-690399
Spain - Madrid - 34-91-708-08-90
UK - Wokingham - 44-118-921-5869

Asia/Pacific

Australia - Sydney - 61-2-9868-6733
China - Beijing - 86-10-8569-2100
China - Chengdu - 86-28-8665-5511
China - Chongqing - 86-23-8980-9588

Asia/Pacific (Continued)

China - Hangzhou - 86-571-2819-3187
China - Hong Kong SAR - 852-2401-1200
China - Nanjing - 86-25-8473-2460
China - Qingdao - 86-532-8502-7355
China - Shanghai - 86-21-5407-5533
China - Shenyang - 86-24-2334-2829
China - Shenzhen - 86-755-8203-2660
China - Wuhan - 86-27-5980-5300
China - Xiamen - 86-592-2388138
China - Xian - 86-29-8833-7252
China - Zhuhai - 86-756-3210040
India - Bangalore - 91-80-3090-4444
India - New Delhi - 91-11-4160-8631
India - Pune - 91-20-2566-1512
Japan - Osaka - 81-66-152-7160
Japan - Yokohama - 81-45-471-6166
Korea - Daegu - 82-53-744-4301
Korea - Seoul - 82-2-554-7200
Malaysia - Kuala Lumpur - 60-3-6201-9857
Malaysia - Penang - 60-4-227-8870
Philippines - Manila - 63-2-634-9065
Singapore - 65-6334-8870
Taiwan - Hsin Chu - 886-3-5778-366
Taiwan - Kaohsiung - 886-7-536-4818
Taiwan - Taipei - 886-2-2500-6610
Thailand - Bangkok - 66-2-694-1351

11/29/11



Microchip Technology Inc. • 2355 West Chandler Blvd. • Chandler, AZ 85224-6199

www.microchip.com

The Microchip name and logo, the Microchip logo, and MPLAB are registered trademarks of Microchip Technology Incorporated in the U.S.A. and other countries. All other trademarks mentioned herein are property of their respective companies. © 2012, Microchip Technology Incorporated, Printed in the U.S.A. All Rights Reserved. 11/11

DS52091A

VGA Camera Sensor PICTail™ Plus Daughter Board Information Sheet

