Effective February 2023 Superseds March 2021

BUSSMANN SERIES

Fuse accessory selection guide

		4							Sec.
	Fuse family	Size	PCB fuse clip	PCB mount holder	Panel mour	anel mount holder		e holder	Fuse block
3 3	ABC AGC	1/4" x 1 1/4" 6.3 mm x 32 mm	<u>1Axxxx</u>	<u>HBH-I</u> HBV-I	<u>HTB</u> <u>HK</u> <u>HKP</u>	<u>HMR</u> HGA HTJ	HRK HHB HFA HHK	<u>HHN</u> <u>HFB</u> <u>HHJ</u>	<u>S-4000</u> <u>S-8000</u>
	AGA	1/4" x 5/8"	<u>1Axxxx</u>	-	-		-		-
	AGW	1/4" x 7/8"	<u>1Axxxx</u>	-	-		<u>HRK</u> <u>HHB</u>		-
	AGX	1/4" x 1"	<u>1Axxxx</u>	-	<u>HJL</u> HJM		HRK HHB HHI		3828-1
	<u>AHC(A)</u> <u>ADC</u>	1/4" x 1 1/4" 6.3 mm x 32 mm	<u>1Axxxx</u>	<u>HBH-I</u> HBV-I	<u>HVP</u>		<u>HVI</u>		<u>S-8000</u>
• • • • • • • • • • • • • • • • • • •	AMH & AML	55.4 mm x 17.7 mm x 12 mm	-	-	-		-		<u>FMG</u> BSCR101
	AMX(L)	48 mm x 12 mm x 8.5 mm	-	-	-		-		HMX
	ATC	Auto Blade Fuse 19.1 mm x 18.7 mm	<u>1A5600</u>	-	-		<u>HHF-</u> <u>JFCU</u>		-
	ATM	Mini Blade Fuse 10.92 mm x 16.25 mm	<u>1A5778</u>	-	-		<u>HHM</u>		-
	<u>C519</u>	5 mm x 15 mm	<u>1Axxxx</u>	-	-		HHT		-
	<u>C520</u>	5 mm x 15 mm	<u>1Axxxx</u>	-	-	_	HHT		-
	<u>FNM</u> FNQ	13/32" x 1 1/2" 10 mm x 38 mm	<u>1A3400</u>	-	HP		HEB		<u>BMM603</u>
	<u>FNQ-R</u> <u>KTK-R</u> <u>LP-CC</u>	13/32" x 1 1/2" 10 mm x 38 mm	<u>1A3400</u>	-	<u>HP</u>		-		<u>BCM603</u>
	<u>GBA</u> <u>GLD</u>	1/4" x 1 1/4" 6.3 mm x 32 mm	<u>1Axxxx</u>	-	<u>HLD</u>		-		<u>S-4000</u> <u>S-8000</u>
8 8	GBB	1/4" x 1 1/4" 6.3 mm x 32 mm	<u>1Axxxx</u>	<u>HBH-I</u> HBV-I	<u>HTB</u> <u>HK</u> HKP	<u>HMR</u> HGA HTJ	HRK HHB HFA HHK	<u>HHN</u> <u>HFB</u> <u>HHJ</u>	<u>S-4000</u> <u>S-8000</u>
	GDA GDB GDC	5 mm x 20 mm	<u>1Axxxx</u> <u>HTC-2xxM</u>	<u>H15</u> HBH-M HBV-M	HTB HTC		<u>HHT</u>		<u>HTC-15M</u> <u>HTC-5x8M</u> <u>HTC-78M</u>
	GMA GMC GMD	5 mm x 20 mm	<u>1Axxxx</u> <u>HTC-2xxM</u>	<u>H15</u> <u>HBH-M</u> <u>HBV-M</u>	HTB HTC		<u>HHT</u>		HTC-15M HTC-5x8M HTC-78M
	KLKE KLM KTK	13/32" x 1 1/2" 10 mm x 38 mm	<u>1A3400</u>	-	<u>HP</u>		<u>HEB</u>		<u>BMM603</u> EVMFH



Fuse accessory selection guide

	Fuse Family	Size	PCB Fuse Clip	PCB Mount Holder	Panel Mount Holder		In-Line Fuse Holder		Fuse Block
	MDA MDL MDQ	1/4" x 1 1/4" 6.3 mm x 32 mm	<u>1Axxxx</u>	<u>HBH-I</u> HBV-I	<u>HTB</u> <u>HK</u> HKP	<u>HMR</u> HGA HTJ	HRK HHB HFA HHK	<u>HHN</u> HFB HHJ	<u>S-4000</u> <u>S-8000</u>
BUSS -	MDH	1/4" x 1 1/4" 6.3 mm x 32 mm	<u>1Axxxx</u>	HBH-I HBV-I	<u>HTB</u> <u>HK</u> HKP	<u>HMR</u> HGA HTJ	HRK HHB HVI HHK	<u>HHN</u> <u>HFB</u> <u>HHJ</u>	<u>S-4000</u> <u>S-8000</u>
	PCTron	-	-	<u>BK-PCS</u>	-		-		-
	<u>S500</u> <u>S501</u>	5 mm x 20 mm	<u>1Axxxx</u> <u>HTC-2xxM</u>	<u>H15</u> <u>HBH-M</u> HBV-M	<u>HTB</u>		HHT		<u>HTC-15M</u> <u>HTC-5x8M</u> <u>HTC-78M</u>
	<u>S505</u> <u>S506</u>	5 mm x 20 mm	<u>1Axxxx</u> <u>HTC-2xxM</u>	<u>H15</u> HBH-M HBV-M	<u>HTB</u>		HHT		<u>HTC-15M</u> <u>HTC-5x8M</u> <u>HTC-78M</u>
11-1 1	<u>SC-xxA</u>	13/32" x various lengths 1.31" to 2.25"	<u>1A3400</u>	-	<u>HPS-EE</u> <u>HPS-JJ</u> <u>HPS-FF</u>		HEG HEH HEC HEJ		<u>BG3011PO</u>
-	SFE	1/4" x various lengths (5/8" to 1 7/16")	<u>1Axxxx</u>	-	-		HR/HM		-
	<u>SR-5 / SR-5F / SR-5H</u> <u>SS-5 / SS-5F / SS-5H</u>	-	-	<u>BK-PCS</u>	-		-		-
	<u>TDC10/11</u>	1/4" x 1 1/4" 6.3 mm x 32 mm	<u>1Axxxx</u>	<u>HBH-I</u> HBV-I	HTB HK HKP	<u>HMR</u> HGA HTJ	HRK HHB HFA HHK	<u>HHN</u> <u>HFB</u> <u>HHJ</u>	<u>S-4000</u> <u>S-8000</u>
Dustmann L 3A	<u>TDC180</u> TDC600	1/4" x 1"	<u>1Axxxx</u>	-	<u>HJL</u> <u>HJM</u>		HRK HHB HHI		3828-1

Tools & resources

- <u>Webpage</u>
- Parametric search tool
- How to select a fuse holder white paper

Eaton Electronics Division 1000 Eaton Boulevard Cleveland, OH 44122 United States www.eaton.com/electronics

© 2023 Eaton All Rights Reserved Printed in USA Publication No. 10575 BU-ELX22190 February 2023



Eaton is a registered trademark.

All other trademarks are property of their respective owners.